

BOOM!™ BOX

2018 HARLEY-DAVIDSON® OWNER'S MANUAL



Harley-Davidson Motor Company
Service Communications
Milwaukee WI 53208 USA

This publication was produced with 100% renewable energy through the purchase of Renewable Energy Certificates from the non-profit Bonneville Environmental Foundation.



Certified Fiber Sourcing
www.sfiprogram.org

Printed in the USA

2018 HARLEY-DAVIDSON® OWNER'S MANUAL
BOOM!™ BOX - 99464-17A



HARLEY-DAVIDSON

BOOM!™ BOX

2018 HARLEY-DAVIDSON® OWNER'S MANUAL



FRONT COVER GOES HERE

Part No:

Title:

Author:

Output Date:

REGULATORY AND SAFETY INFORMATION

Exposure to Radio Frequency Radiation

The radiated output power of the internal wireless radio is far below the FCC radio frequency exposure limits. Nevertheless, the wireless radio shall be used in such a manner that the radio is 20 cm or further from the human body.

The internal wireless radio operates within guidelines found in radio frequency safety standards and recommendations, which reflect the consensus of the scientific community.

The radio manufacturer believes the internal wireless radio is safe for use by consumers. The level of energy emitted is far less than the electromagnetic energy emitted by wireless devices such as mobile phones. However, the use of wireless radios may be restricted in some situations or environments, such as aboard airplanes. If you are unsure of restrictions, you are encouraged to ask for authorization before turning on the wireless radio.

This device complies with Part 15 of the FCC Rules and with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (a) Increase the separation between the equipment and receiver. (b) Consult the dealer or an experienced radio technician for help.



DECLARATION OF CONFORMITY

The EC Declaration of Conformity is available at www.harman.com/EN-US/ContactUs/Pages/Compliance.aspx.

English

Hereby, Harman Becker Automotive Systems, Inc., declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Česky [Czech]

Harman Becker Automotive Systems, Inc. tímto prohlašuje, že toto zařízení je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Dansk [Danish]

Undertegnede Harman Becker Automotive Systems, Inc. erklærer herved, at følgende udstyr anordning overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Deutsch [German]

Hiermit erklärt Harman Becker Automotive Systems, Inc., dass sich das Gerät in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

Eesti [Estonian]

Käesolevaga kinnitab Harman Becker Automotive Systems, Inc. et käesolev seade vastab direktiivi 1999/5/EÜ põhinõuetele ja teistele asjakohastele sätetele.

Español [Spanish]

Por medio de la presente Harman Becker Automotive Systems, Inc. declara que el dispositivo cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Ελληνική [Greek]

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Ηarman Becker Automotive Systems, Inc. ΔΗΛΩΝΕΙ ΟΤΙ Η ΣΥΣΚΕΥΗ ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Français [French]

Par la présente Harman Becker Automotive Systems, Inc. déclare que ce dispositif est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Italiano [Italian]

Con la presente Harman Becker Automotive Systems, Inc. dichiara che questo dispositivo è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Latviski [Latvian]

Ar šo Harman Becker Automotive Systems, Inc. deklarē, ka ierīce atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Lietuvių [Lithuanian]

Šiuo Harman Becker Automotive Systems, Inc. deklaruoja, kad šis įrenginys atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Nederlands [Dutch]

Hierbij verklaart Harman Becker Automotive Systems, Inc. dat het toestel in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Malti [Maltese]

Hawnhekk, Harman Becker Automotive Systems, Inc., tididjara li dan il-prodott jikkonforma mar-rekwiziti essenzjali u ma' dispozizzjonijiet oħrajn relevanti li hemm fid-Direttiva 1999/5/KE.

Magyar [Hungarian]

Alulírott, Harman Becker Automotive Systems, Inc. nyilatkozom, hogy a készülék megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Polski [Polish]

Niniejszym Harman Becker Automotive Systems, Inc. oświadcza, że urządzenie jest zgodne z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/WE.

Português [Portuguese]

Harman Becker Automotive Systems, Inc. declara que este dispositivo está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Slovensko [Slovenian]

Harman Becker Automotive Systems, Inc. izjavlja, da je ta izdelek v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Slovensky [Slovak]

Harman Becker Automotive Systems, Inc. týmto vyhlasuje, že zariadenie spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Suomi [Finnish]

Harman Becker Automotive Systems, Inc. vakuuttaa täten, että tämä laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Svenska [Swedish]

Härmed intygar Harman Becker Automotive Systems, Inc. att denna apparat står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Íslenska [Icelandic]

Hér með lýsir Harman Becker Automotive Systems, Inc. yfir því að tæki þetta er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

Norsk [Norwegian]

Harman Becker Automotive Systems, Inc. erklærer herved at denne enheten er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

TABLE OF CONTENTS

SAFETY FIRST

Safety Definitions.....	1
Safety Information.....	1
Navigation.....	3
Pre-Ride Checklist.....	4
Emergency Phone Number.....	4
Emergency CB Operation.....	4

FEATURES AND SPECIFICATIONS

Acronyms Used in this Manual.....	5
Features, Options and Specifications.....	5

CONTROLS AND COMPONENTS

Infotainment Controls.....	15
POWER/MUTE Switch.....	15
HOME Switch.....	16
Favorite Switch (FAV).....	16
Navigation Switch: 6.5 Only.....	17
Hard Keys: 4.3 Only.....	17
Touchscreen: 6.5 Only.....	17
Boom! Box Hand Controls.....	18
Left Hand Control Audio Functions.....	18
Right Hand Control Audio Functions.....	19
HOME/VOLUME/PREVIOUS/NEXT Switch.....	19
Voice Recognition Switch.....	20

Push-To-Talk/Squelch Switch.....	20
CURSOR/SELECT Switch.....	20
Vehicle Information Switch.....	21
Rear (Passenger) Controls.....	21
MODE/UP/DN Switch.....	21
Push-To-Talk (PTT)/Volume (VOL) Switch.....	21
Enabling Rear Controls.....	21
Headset Connection.....	22
Microphone Positioning.....	24
Media Compartment: USB Port.....	25
Media Compartment: Fixed Fairing Vehicles.....	25
Media Compartment: Fork Mounted Fairing Vehicles.....	26
USB Hub.....	26
Speakers.....	27
Fairing Speakers.....	28
Fairing Lower Speakers.....	28
Saddlebag Speakers.....	28
Tour-Pak Speakers.....	28
Amplifier.....	28
Antennas and Reception.....	28
Bluetooth.....	29
Turning Motorcycle On, Off or to Accessory Mode.....	30
Disconnecting the Vehicle Battery.....	30

BASIC OPERATION

Home Screen.....	31
------------------	----

TABLE OF CONTENTS

Screen Menu Bar.....	31
Checkboxes.....	32
Multiselect Button.....	32
Scroll Controls.....	32
Keyboard.....	33
Smart Speller.....	35
Volume Controls.....	35
Popup Screens.....	36
Lockout Screens.....	36
Status Bar.....	36

SYSTEM SETTINGS

System Setup.....	39
Setup Menu.....	39
Language.....	40
Screen Brightness.....	41
Button Brightness.....	41
Day/Night Colors Mode.....	42
High Contrast Day Colors.....	42
Background Color: 6.5 Only.....	43
English Units/Metric.....	43
Clock.....	44
Keyboard: 6.5 Only.....	44
Speaker/Headset Selection.....	45
Audio Settings: Bass/Treble.....	45

Fade.....	46
Speed Volume.....	47
Feedback Prompts.....	47
Rear Controls.....	48
Classic Mode.....	48
Global Presets.....	49
Bluetooth.....	50
Ring Tones.....	50
SiriusXM.....	50
Traffic.....	50
System Information.....	50
Software Update.....	52
Privacy Reset.....	53
Factory Restore.....	53

FAVORITES

Favorites.....	55
Setting a Favorite.....	55
Selecting a Favorite.....	55

TUNER

Tuner.....	57
Selecting a Band: Menu Buttons.....	58
Selecting a Band: HOME Hand Control, Classic Mode.....	58
Selecting a Band: Voice Recognition.....	58

TABLE OF CONTENTS

Tune/Seek/Preset Settings.....	58	Play Random Files: Shuffle.....	71
Tuning a Station: Hand Control Switch.....	59	Play Songs From Track List.....	71
Tuning a Station: Voice Recognition.....	59	Media Presets.....	72
Seeking a Station: Hand Control Switch.....	59	Finding a Media File.....	72
Seeking a Station: Voice Recognition.....	59	Finding a Media File: Playlist.....	73
Scanning Stations.....	59	Finding a Media File: Artist, Album or Genre.....	73
Presets.....	60	Finding a Media File: Song Title.....	74
Categories (Cat).....	60	Finding a Media File: Podcast.....	74
Selecting Categories.....	60	Finding a Media File: Audio Book.....	75
Station List.....	62	Finding a Media File: Video, TV Show, Movie, Music Video.....	75
RBDS/RDS.....	63	Selecting Media File: Using Voice Recognition.....	75
RDS Features.....	63	Saving Media File as Favorite.....	76
Weather Band.....	64	Saving Media File as Ring Tone.....	76
Weather Alert.....	64		
MEDIA		CARE AND CLEANING	
Media Screen.....	67	Audio System Care.....	77
Media Devices.....	67	Replaceable Screen Protector.....	77
Connecting Media Device: USB.....	69	Cleaning the Radio.....	77
Connecting Media Device: Bluetooth.....	69	Speaker Care.....	77
Device Players and Applications: Bluetooth.....	69		
Selecting Media Device.....	69	BLUETOOTH	
Play Previous/Next Media File: Previous/Next Preset.....	70	Enabling Bluetooth.....	79
Pause, Rewind, or Fast Forward Media File.....	70	Pairing a Bluetooth Device.....	79
Scanning Media Files.....	70	Connecting/Disconnecting a Bluetooth Device.....	80
Repeat Current File.....	71	Reconnecting After Vehicle Turns On.....	81

TABLE OF CONTENTS

Deleting a Paired Device.....	81
-------------------------------	----

PHONE

Phone Compatibility.....	83
Bluetooth and USB Connections For Phones.....	83
Phone Menu.....	83
Call Screen.....	84
iPhone: Using Siri.....	86
Making a Call: Dialing.....	87
Making a Call: Phone Book Contact.....	88
Making a Call: Navigation POI.....	88
Making a Call: SiriusXM Gas Station.....	88
Making a Call: Emergency Phone Number.....	89
Making a Call: Dialing with Voice Recognition.....	89
Making a Call: Calling a Contact with Voice Recognition... ..	89
Receiving a Call: Accepting/Ignoring.....	89
Receiving a Call: Radio Turned Off.....	90
Ending a Call.....	90
Adjusting Call Volume.....	90
Muting Call Audio.....	90
Routing Call Audio.....	90
Multiple Calls.....	91
Voice Mail.....	91
Phone Book.....	91
Setting Up Contacts in a Phone.....	92

Refresh Phone Book.....	92
Showing Contact Details.....	92
Viewing Saved Contacts and Phone Numbers.....	93
Saving a Phone Book Contact.....	93
Saving a Dialed Phone Number.....	93
Saving Phone Number from Current Call.....	93
Delete Saved Contact.....	93
Call History.....	94
Text Messaging.....	94
Enabling Text Message Service: SMS.....	94
Enabling Text Message Notification: Apple Devices.....	95
Text Message Auto-Reply.....	96
Viewing/Playing a Text Message.....	96
Selecting Ring Tone.....	97
Adding New Ring Tone: Media File Currently Playing.....	97
Adding New Ring Tone: Bluetooth Setup.....	98
Resuming Calls After Vehicle Shutdown.....	98
Transferring a Call Back to the Phone.....	98
Changing the Emergency Phone Number.....	99

WIRELESS HEADSET INTERFACE MODULE (WHIM)

Wireless Headset.....	101
Getting Started.....	101
Powering On and Off.....	101

TABLE OF CONTENTS

Wireless Headset Setup.....	101
Headset to Headset Intercom Pairing.....	104
Headset Configurations.....	104
Headset Software Version.....	107
Unpair Wireless Headset.....	108
Reset Factory Headset Settings.....	108
Fault Reset.....	109
Volume Setup.....	109
Volume Adjustment.....	109
Volume Setup.....	110
Rider and Passenger Headset (HS) Volume.....	110
Wireless Headset Checkbox.....	111

CITIZEN BAND (CB) RADIO

CB Radio.....	113
Turning CB On.....	113
Turning CB Off.....	114
Conflicting Transmissions.....	114
Emergency Operation: Channel 9.....	114
Transmitting on CB.....	114
Receiving CB Audio.....	115
Tuning CB Channels.....	115
CB Presets.....	116
Squelch.....	116
CB Volume.....	117
Passenger CB Operation.....	118

Factors Affecting CB Range.....	118
Adding an Optional CB Module.....	118

INTERCOM

Intercom.....	119
Turning Intercom On/Off.....	120
Adjusting Microphone Sensitivity: VOX.....	120
Speed Volume.....	121
Adjusting Intercom Volume: Rider and Passenger Headsets.....	121
Operating Intercom: Voice Activation, VOX.....	122
Operating Intercom: PTT Switch.....	122

SIRIUSXM

SiriusXM Satellite Radio.....	123
Optional SiriusXM Accessory.....	123
Trial Subscription.....	123
Check Subscription Status.....	123
Subscribing to SiriusXM.....	124
Listening to SiriusXM Radio.....	125
SiriusXM Presets.....	125
Selecting a Channel: Hand Controls.....	126
Selecting a Channel: Channel List.....	126
Selecting a Channel: Direct Tune.....	126
Selecting a Channel: Voice Recognition.....	127
Scanning SiriusXM Channels.....	127

TABLE OF CONTENTS

Tagging an Artist or Song.....	127
Viewing Tagged List.....	128
Tag Alert.....	128
SiriusXM Categories.....	128
Game Zone.....	129
Enabling Sports Alerts.....	129
Adding a Game Zone Favorite.....	129
Setting Game or Score Notification.....	129
Responding To Game Zone Alert.....	130
Removing a Game Zone Favorite.....	130
Displaying Current Weather.....	131
Displaying Daily Forecast: 3 and 6 hour.....	131
Displaying 5 Day Forecast.....	132
SiriusXM Fuel Prices.....	132
Selecting Fuel Type.....	132
Viewing Fuel Prices.....	133
SiriusXM Traffic.....	134
Turning Traffic On.....	134
Traffic Notification Popups.....	135
Traffic Icons.....	135
Traffic Reroute.....	135
Traffic Message List.....	135
SiriusXM Weather Map.....	137
Weather Map Scrolling.....	137
Weather Map Radar and Fronts.....	138

Display Last Weather Update.....	138
----------------------------------	-----

TRADEMARKS

H-D U.S.A., LLC Trademark Information.....	139
Product Registered Marks.....	139

NAVIGATION

Navigation.....	141
Displaying the Map.....	142
Changing Map Display.....	144
Changing Data Fields.....	145
Navigation Option Menu.....	146
Route Preferences and Avoidances.....	146
Compass.....	147
Compass and Heading Indicator on Map.....	147
Full Size Compass.....	147
Auto Zoom.....	148
Auto Zoom.....	148
Map Scrolling: Touchscreen.....	149
Map Scrolling: Hand Controls.....	149
Selecting POI On Map.....	149
Route To Destination: Address.....	151
Route To Destination: Home.....	152
Route To Destination: Recent.....	152
Route To Destination: Phone Book.....	153

TABLE OF CONTENTS

Route To Destination: Saved.....	153	Importing a Route.....	161
Route To Destination: Map Scroll Tool.....	153	Exporting a Ride Planner Route.....	162
Route To Destination: POI.....	153	Maneuvers: Turn-By-Turn Instructions.....	165
Route To Destination: Dealership.....	154	Displaying a Maneuver: Zoom.....	166
Route To Destination: Emergency.....	155	Avoiding a Road.....	166
Route To Destination: Coordinates.....	155	Restoring an Avoided Road.....	167
Route To Destination: SiriusXM Fuel Prices Feature.....	156	Lane Guidance.....	167
Route To Destination: Voice Command.....	156	Saving a Destination: Saved, Preferred or Home.....	168
Canceling a Route: Using Menus.....	156	Saving Current Location.....	168
Canceling a Route: Voice Command.....	156	Showing a Planned Route.....	169
Trips.....	157	Simulating a Route.....	169
Creating a Trip: Using Menus.....	157	Calling a Destination: Route Active.....	169
Creating a Trip: Using Map.....	157	Calling a Destination: Route Not Active.....	169
Round Trip.....	157	Trip Summary.....	170
Editing a Trip: Adding Waypoints in Menu.....	158	Low Fuel Alert.....	170
Editing a Trip: Adding Waypoints On Map.....	158	GPS Information.....	170
Editing a Trip: Reordering Waypoints.....	158	Traffic.....	171
Editing a Trip: Skipping Next Waypoint.....	159	Turning Traffic On/Off.....	172
Editing a Trip: Skipping Waypoints From List.....	159	Traffic Notification Settings.....	172
Trails.....	159	Rerouting.....	173
Record a Trail: Options Menu.....	160	Traffic Event List: RDS Traffic.....	173
Record a Trail: Trails Menu.....	160	Navigation Prompts: Turning On/Off.....	173
Rename a Trail.....	160	Navigation Prompts: Adjusting Volume Using Menus.....	174
Navigating a Trail.....	160	Navigation Prompts: Adjusting Volume with Hand Controls.....	174
Deleting a Trail.....	161	Navigation Prompts: Speaker/Headset Selection.....	174
Exporting a Route.....	161		

TABLE OF CONTENTS

Navigation Database.....	174
Verifying Database Version.....	174
Download Hardware/System Requirements.....	175
Updating Database.....	175
Replacing the Intercontinental Database.....	176
Restoring an Intercontinental Database.....	176

VOICE RECOGNITION

Voice Recognition.....	179
Activating Voice Recognition.....	179
Cancelling Voice Recognition.....	179
Teleprompter.....	180
Command List.....	180
Pick List.....	180
Prompter Responds "Pardon?".....	181
Voice Recognition Commands.....	181

VEHICLE STATUS

Vehicle Status.....	185
Air Temperature.....	185
Engine Oil Pressure.....	185
Engine Idle Temperature Management System (EITMS).....	185
Tire Pressure Monitoring System (TPMS).....	186

Low Tire Pressure Alert.....	187
------------------------------	-----

FCC CITIZENS BAND INFORMATION

What Every Responsible Citizens Band (CB) Station Operator Should Know as Prepared by the Federal Communications Commission, Washington, D.C.....	189
Subpart D-Citizens Band (CB) Radio Service General Provisions.....	189
How to Operate a CB Station.....	191
OTHER THINGS YOU NEED TO KNOW.....	197

LIMITED RADIO WARRANTY

2018 Limited Radio Warranty.....	201
Other Rights.....	202

LIMITED RADIO WARRANTY (AUSTRALIA)

2018 Australia/New Zealand Limited Radio Warranty.....	203
Your Consumer Rights.....	203
Warranty.....	203
Warranty Period.....	203
Exclusions.....	204
Obtaining Warranty Service.....	204

SAFETY DEFINITIONS

Statements in this manual preceded by the following words are of special significance:

▲ WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury. (00119a)

▲ CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. (00139a)

NOTICE

NOTICE indicates a potentially hazardous situation which, if not avoided, may result in property damage. (00140b)

NOTE

Refers to important information and is placed in italic type. It is recommended that you take special notice of these items.

SAFETY INFORMATION

▲ WARNING

Set volume levels and other controls on audio and electronic devices before riding. Distractions can lead to loss of control, resulting in death or serious injury. (00088b)

▲ WARNING

Set CB channel, squelch threshold and volume before riding to minimize adjustments on the road. Distractions can lead to loss of control, resulting in death or serious injury. (00089a)

▲ WARNING

Do not select a volume level that blocks out traffic noise or interrupts the concentration necessary for safe operation of the motorcycle. Distractions or a volume level that blocks out traffic noise could cause loss of control resulting in death or serious injury. (00539b)

NOTICE

There are no serviceable parts inside the unit; leave all servicing to qualified service personnel. Disassembly of the unit could result in equipment damage and/or equipment malfunction. (00172a)

This manual explains the operation of the Boom!™ Box Infotainment system. Investing time to learn about the features and operation of your motorcycle and its infotainment system will lead to safe enjoyable use of its full range of features. Read this manual carefully and keep it with your motorcycle at all times for reference. An online copy of this manual is available at www.h-d.com/boom (or the Boom! Box section on www.h-d.com/touring).

See the owner's manual for your vehicle for important rider safety information.

Follow all the warnings, cautions and safety tips shown throughout this manual and your vehicle manual.

See Figure 1 and Figure 2. Do not use any feature of this system to the extent it becomes a distraction and prevents safe riding. The first priority while riding should always be the safe operation of the vehicle. While riding, observe all traffic regulations.

NOTE

The acceptance screen will clear after 15 seconds if ACCEPT button is not pressed.

Pay attention while riding. Always concentrate on riding by keeping your eyes and mind on the road. To prevent distraction, some features are locked out, unavailable or limited in capability while the motorcycle is in motion. Even if

a feature is available, do not allow it to distract you from operating the motorcycle safely.

For safety, program the system when stopped. Perform system setup and get familiar with the controls and features of the infotainment system before operating the motorcycle on the road.

This system cannot warn about such things as the safety of an area, road conditions and availability of emergency services.

Use this system only in locations where it is legal to do so.

For additional instruction and information for setting up or operating the system, see an authorized Harley-Davidson dealer and online resources at www.h-d.com/boom (or the Boom! Box portion of www.h-d.com/touring).



Figure 1. Acceptance Screen: 4.3 Models



Figure 2. Acceptance Screen: 6.5 Models



Figure 3. Vehicle in Motion Message

NAVIGATION

The navigation, lane guidance and traffic features are intended to assist you when traveling. Always use personal judgment and observation of the actual road conditions while riding. In

some circumstances, information provided in the navigation database may be incomplete, incorrect or outdated. Road conditions, traffic laws and restrictions (such as no left turns, street closures, one way streets, road construction detours, and so on) can frequently change. Before following any instruction from the system, check whether the instruction can be done safely and legally.

If necessary, safely park the vehicle if there is difficulty following the route guidance or if there is a need to program a new route. In some circumstances, the system could temporarily provide an inaccurate position of the vehicle or show errors in distance between objects.

When importing routes from other devices or websites, understand that there may be limitations to the accuracy or reliability of the imported data. There may also be compatibility limitations when importing data files from another device or website.

Program and review navigation routes with the vehicle stopped. When taking a long trip, plan and review the route before riding the motorcycle. Install updates to the navigation database to make sure you have the latest information available.

PRE-RIDE CHECKLIST

To make full use of features and minimize distraction while on the road, configure the system with your personal preferences before riding.

- Set brightness, background color and day/night color mode.
- Configure presets and favorites.
- Select tuning mode (tune/seek/preset).
- Adjust audio settings (volume, tone, fade and headset/speaker selection).
- Pair, connect and set up phone features through Bluetooth.
- Connect USB devices.
- Select station or media.
- Set up trips and navigation.
- Set up CB and intercom.
- Connect and put on headsets.

EMERGENCY PHONE NUMBER

Setting up an emergency phone number can provide access to help when needed. See Making a Call: Emergency Phone Number (Page 89).

Phone numbers and navigation to nearby emergency resources are also available on equipped systems. See Route To Destination: Emergency (Page 155).

EMERGENCY CB OPERATION

For vehicles equipped with a CB, channel 9 is reserved for emergency use in most countries. When using this channel for emergencies or assistance, clearly identify the nature of the problem and your location. If no response is received, try other channels or find another way to get help.

ACRONYMS USED IN THIS MANUAL

See Table 1. explains the acronyms used throughout this manual.

Table 1. Acronyms

ACRONYM	DESCRIPTION
AVC	Automatic volume control
CB	Citizens band
CVO	Custom Vehicle Operations
EITMS	Engine idle temperature management system
GPS	Global positioning system
POI	Point of interest
PTT	Push to talk
RDS	Radio Data System
RBDS	Radio Broadcast Data System
THD	Total harmonic distortion
TMC	Traffic message control
TPMS	Tire pressure monitoring system
VOX	Voice operated transmission
WHIM	Wireless headset interface module

FEATURES, OPTIONS AND SPECIFICATIONS

Not all features are available on all models, destinations or year of manufacture. Most screen illustrations in this manual show the 6.5 radio.

Vehicles are equipped from the factory with the radios and features as described in Table 2 and Table 3. Also see System Information (Page 50) to view the hardware, software and navigation database installed on your vehicle.

Table 2. Boom! Box Radio Identification

MODEL	IDENTIFYING FEATURES *
4.3	Screen measures 109 mm (4.3 in) diagonally. Radio face has eight hard keys.
6.5	Screen measures 165 mm (6.5 in) diagonally. Radio face has four hard keys. Splash screen shows H-D bar & Shield logo.
6.5 (CVO)	Screen measures 165 mm (6.5 in) diagonally. Radio face has four hard keys. Splash screen shows Custom Vehicles Operations logo.
* See Figure 4.	

Table 3. Infotainment System Features

FEATURES	4.3	6.5	6.5 (CVO)
Tuner ¹	X	X	X
Media playback	X	X	X
Phone	X	X	X
Voice commands ²	X	X	X
Vehicle status	X	X	X
Wireless headset interface module (WHIM)			X

Table 3. Infotainment System Features

FEATURES	4.3	6.5	6.5 (CVO)
CB radio ³			X
Rider/passenger intercom ⁴		X	X
Weather alert ^{3,6}			X
Navigation ³		X	X
SiriusXM radio and services ^{3,5}			X
Three free map updates (within 5 years)			X
¹ Frequency bands and RDS features depend on region. ² 4.3 only supports phone commands, in English only. ³ Not available in all regions. ⁴ Models with passenger headset. ⁵ Requires activation. ⁶ CB equipped only.			

Table 4. Display

ITEM	DESCRIPTION
Screen	Weatherproof 4.3-inch QVGA LCD color screen or 6.5-inch QVGA TFT LCD color touchscreen with screen protector
Languages	English (US), English (UK), French (Canada), French (Europe), Spanish (Mexico), Spanish (Castilian), German, Italian, Portuguese (Europe)
Day/night color modes	Day, night or automatic sensor activated
Background colors	6 selectable colors (6.5 only)
High contrast day colors	Selectable in day or automatic color modes
Adjustable brightness	Manual or automatic sensor activated

Table 5. Controls

ITEM	DESCRIPTION
Illuminated face-plate controls	On/off/mute, navigation, favorite, home, screen selection soft keys
Integrated handle-bar controls	Volume, seek/previous/next, home, CB push-to-talk (PTT), voice recognition, vehicle information, squelch, cursor/select, wireless headset interface module (WHIM)

Table 5. Controls

ITEM	DESCRIPTION
Integrated passenger controls	Volume, seek/previous/next, audio source selection, CB push-to-talk (PTT), wireless headset interface module (WHIM)
Keyboard	Full keyboard, alphabetic keypad, smart speller
Screen selection	Hard key (4.3) or touchscreen (6.5)
Hand control configuration	Normal or Classic mode

Table 6. Bluetooth

ITEM	DESCRIPTION
Functions	Media streaming, phone calls, phone book download, text message notifications
Protocols	Hands-Free Calling Profile (HFP, HFPAG/HFPHF services), Phone Book Access Profile (PBAP), A2DP/AVRCP (AV/Music, A2DP sink/source services), Message Access Profile (MAP), HFP+PBAP+AV Profile (simultaneously used), MP3, MPEG-4AAC, WMA, WAV
Paired devices	6 devices maximum
Connections	1 for phone, 1 for media
Range (approximate)	30 ft (9 m)

Table 7. Tuner

ITEM	DESCRIPTION
Tuner bands	FM (mono/stereo), AM, LW, MW, Weather Band (dependent on region)
Tuner presets	15 FM, 6 AM, 6 LW, 6 MW, 6 WB
Global presets	Up to 4 pages with up to 20 total
Tuning modes	Tune, seek, scan, preset scan
Favorites	1 Fav hardkey plus 6 favorites
Category filtering (PTY)	Selectable
Stations list	Dependent on region
RDS/RDBS	Dependent on region
RDS functions	Traffic Announcement/Traffic Program, Alternate Frequency Switching, Regionalization (dependent on region)
Single/dual tuner	Dependent on region
Weather band channels	7 channels, 6 presets
Weather alert	Select regions, requires CB module
Weather band frequency	WB1-162.400MHz, WB2-162.425MHz, WB3-162.450MHz, WB4-162.475MHz, WB5-162.500MHz, WB6-162.525MHz, WB7-162.550MHz
Clock	GPS/RDS/user-selectable time setting, automatic time zone adjustment

Table 8. Media

ITEM	DESCRIPTION
Media presets	20 per device
Media devices supported	USB flash drives, Apple devices (iAP, iUI), PlaysForSure devices, SDRAM card with reader
USB device compatibility	FAT16, FAT32, NTFS, HFS+ (FAT32 required for data import/export and software updates)
Media file playback (USB/PlaysFor-Sure)	MP3, MP4, MPEG-4AAC, M4A, M4B, WAV, WMA
Media file playback (Bluetooth)	MP3, MPEG-4AAC, WMA, WAV
Media file playback (Apple devices)	All iPod supported file types decoded and played from Apple device
USB port	USB 2.0, 5 V, 1.0 A charging current
Media controls	Repeat, shuffle, find, Bluetooth streaming, pause/resume
Playlists supported (Apple)	All playlists native to Apple iPod
Playlists supported (USB/PlaysFor-Sure)	ASX, WPL, M3U, PLS, XML, RMP

Table 9. Audio

ITEM	DESCRIPTION
Speed volume	4 levels of automatic gain based on speed, plus off setting
Audio routing	Adjustable speaker/headset audio routing (tuner, communication device, phone)
Sound adjustment	Audio tone and fade adjustment
Headset connectors	7-pin DIN with protective cap (number of headset ports depends on vehicle configuration)
Headsets (wired)	Helmet-mounted 7-pin DIN headset with microphone boom (non-mounted headset optional)
Headsets (wireless)	Boom Audio 20S EVO Bluetooth helmet headset with microphone (CVO)
Squelch	15 step adjustable, plus full on/off
Output	25 W (4.3/6.5) or 75 W (6.5 CVO) per channel
Speaker configurations	2 sealed and closed front speaker housings, 2 bass port rear speakers (models with Tour-Pak), 2 saddlebag speakers (FLHXSE and FLTRXSE). 2 fairing lower speakers (FLHXSE).
Speakers, fairing: Touring and Trike	6.5 in, 1.7 ohm, 88.9 dB, 75-16.2kHz, 51 W
Speakers, Tour-Pak: Touring and Trike	6.5 in, 1.7 ohm, 88.9 dB, 75Hz-16.2kHz, 51 W

Table 9. Audio

ITEM	DESCRIPTION
Speakers, fairing: FLHTKSE	6.5 in, 1.7 ohm, 91.5 dB, 75Hz-20kHz, 75 W
Speakers, fairing lower: FLHTKSE	6.5 in, 2.0 ohm, 91.5 dB, 75Hz-20kHz, 75 W
Speakers, Tour-Pak: FLHTKSE	6.5 in, 1.7 ohm, 91.5 dB, 75Hz-20kHz, 51 W
Speakers, fairing: FLHXSE	6.5 in, 1.7 ohm, 91.5 dB, 65Hz-20kHz, 150 W
Speakers, saddle- bag: FLHXSE	5 x 7 in, 1.7 ohm, 91 dB, 60Hz-20kHz, 150 W
Amplifiers - Watts per channel	Internal 25 W amplifier (all models, turned off for CVO), 75 W fairing amp- lifier (CVO), additional 75 W amplifier in left saddlebag (FLHXSE and FLTRXSE), third 75W amplifier in RH saddlebag (FLHXSE)
Distortion	1% THD

Table 10. Phone

ITEM	DESCRIPTION
Features	Inbound/outbound calls, call history, mute/unmute, phone book download, emergency phone calling, point of in- terest dialing
Call history	Up to 60 calls (20 received, 20 missed, and 20 dialed calls)
Saved phone num- bers	Up to 200 contacts or phone numbers
Compatible phones	See www.h-d.com/boom for phone list
Calls supported	Only one call at a time. Call waiting and three-way calling not supported
Connections	USB (media and charging only), Bluetooth (calls, text messaging, streaming media)
Text messaging	Inbound SMS messages (with text-to- speech), outbound text message autoreply
Indicators	Signal strength and battery level indicat- ors, low battery indicator, text message notification
Ring tones	4 built-in ring tones, 1 custom ring tone (media file import)

Table 11. Wireless Headset Interface Module (WHIM)

ITEM	DESCRIPTION
Key specifications	Bluetooth 4.1; Supporting profiles: Headset Profile, Hands-Free Profile (HFP), Advanced Audio Distribution Profile (A2DP), and Audio Video Remote Control Profile (AVRCP)
Firmware	Upgradeable
Bluetooth	Dual module communication system, intercom up to 2.0 kilometers (1.2 miles)*, audio recording, pairing for dual mobile phones, hands-free for Bluetooth mobile phones, stereo headset for Bluetooth audio devices such as MP3 players, stereo headset for Bluetooth GPS navigations
Reset to factory settings	Yes
Fault reset	Yes
Certification and safety approvals	FCC, FCC, CE, IC, RoHS, WEEE

Table 11. Wireless Headset Interface Module (WHIM)

ITEM	DESCRIPTION
Features	Bluetooth 4.1, music sharing, playback control, versatile jog control, speed dial, audio booster, use while charging, individual volume control, dual Bluetooth module communication system, audio multitasking, multi-way intercom up to 4 connections, group intercom, Bluetooth intercom up to 2.0 kilometers (1.2 miles)*, smartphone app for iPhone and Android, universal intercom, advanced noise control, Intuitive voice prompts and voice commands, Bluetooth audio recording, all-in-one helmet clamp kit, built-in FM radio tuner with a station scan and save function, Bluetooth pairing for dual mobile phones, Bluetooth hands-free for Bluetooth mobile phones, Bluetooth stereo headset for Bluetooth audio devices such as MP3 players, Bluetooth stereo headset for Bluetooth GPS navigations
*In open terrain	

Table 12. CB Radio: Bike-To-Bike Communications

ITEM	DESCRIPTION
CB channels	40
Frequency range	26.925 to 27.405 MHz
Transmitter output	4 W
Modulation	AM or FM (depending on region)
Squelch	15 step adjustable, plus full on/off

Table 13. Intercom

ITEM	DESCRIPTION
Communication	Rider/passenger headset communication
Operation	Push-to-talk (PTT) or voice activation (VOX)
Adjustments	VOX sensitivity, automatic speed sensitivity adjustment

Table 14. Voice Recognition

ITEM	DESCRIPTION
Functions	Tuner, media, phone, SiriusXM, navigation commands (only phone for 4.3)
Languages (one-shot destination entry)	<ul style="list-style-type: none"> English (US), French (CA), Spanish (MX) (for North America 49ST/CAL/CAN configurations). English (US/UK), French (FR/CA), Spanish (MX/ES), German, Italian, Portuguese (for ENG/HDI-Europe configurations). Not supported for other destinations.
Languages (other commands)	English (US/UK), French (FR/CA), Spanish (MX/ES), German, Italian, Portuguese (English-only for 4.3)

Table 15. SiriusXM

ITEM	DESCRIPTION
Subscription	Free 3-month trial subscription for 6.5 CVO, optional module and subscription required for other 6.5 systems
Channels	Over 200 channels
Radio features	Channel list, direct tune, scanning, song/artist tagging, program categories
Specialty services	Game Zone, fuel prices, weather, traffic

Table 15. SiriusXM

ITEM	DESCRIPTION
Game Zone	Game and score alerts, up to seven teams
Fuel prices	Up to 30 nearest stations within 100 miles, sort by price/distance/brand, navigate/call station
Weather forecast	Current, daily (3 hour and 6 hour), and 5-day forecast
Weather map	Radar, weather fronts, atmospheric pressure
Traffic	Traffic navigation mapping, rerouting, traffic alerts

Table 16. Navigation

ITEM	DESCRIPTION
Map display	Two data fields, next turn guidance, current street, POI icons, navigation routing, traffic flow/events (requires RDS or SiriusXM traffic service), 3D terrain and landmarks (6.5 CVO only)
Map orientation	North up, 2D heading up, 3D heading up
Points of interest (POIs)	Over 80 POI types
Navigation route selection	Address, recent destination, home destination, phone book contact, POI, dealership, emergency facility, coordinates

Table 16. Navigation

ITEM	DESCRIPTION
Trips	Up to 17 trips
Waypoints per trip	Up to 100 destinations per trip
Trails	Up to 20 trails
File export	GPS Exchange Format (GPX) export of trips, trails and saved destinations
File import	GPX and V-card contact files (VCF)
Maneuvers (turn-by-turn instructions)	Next turn, list of turns, view turn location, avoid turns and roads
Lane guidance	Lane guidance arrows, signpost and junction view
Saving destinations	Current location, preferred POI, home location
Traffic (requires RDS or SiriusXM Traffic)	Traffic flow (green/yellow/red), traffic event icons, traffic event list, rerouting
GPS coordinates	Current location or route guidance to coordinates
Touchscreen selection	On screen scrolling and destination selection
Avoidances	Selectable
Detours	Automatic or manually selectable
Compass	Full screen compass and directional heading markers
Voice prompts	Selectable (on/off), adjustable volume

Table 16. Navigation

ITEM	DESCRIPTION
Other features	Round trip guidance, trip summary, phone contact navigation, route simulation, low fuel navigation alert, graphical signpost display
Map database	North American map (for North America 49ST/CAL/CAN configurations). European map (for ENG/HDI-Europe configurations). Map optional (other destinations).

Table 17. Vehicle Status

ITEM	DESCRIPTION
Air temperature	Temperature of the surrounding environment measured by a sensor in the fairing
Engine oil pressure	Displays status as, OK or CHECK OIL
Engine Idle Temperature Management System (EITMS)	Displays status as disabled, enabled or active
Tire pressure monitoring system (TPMS) (CVO only)	Displays tire pressure, low-pressure alert and low sensor battery

NOTES

INFOTAINMENT CONTROLS




Figure 4. Boom! Box Infotainment System

POWER/MUTE SWITCH

When turning the motorcycle on, the radio resumes its previous state (radio on or off).

Power On: With the motorcycle turned on or in accessory mode, press POWER/MUTE switch to turn on the system. The system returns to the last state as when it was last turned off (media file, station, and so on).

Power Off: Press and hold the POWER/MUTE switch for three seconds to turn the system off. The screen goes black and the clock is displayed. The radio remains in sleep mode and continues to draw current while the motorcycle is turned on or in accessory mode. The radio does not reinitialize unless the vehicle is turned off for up to 30 seconds.

Mute/Pause: Briefly press POWER/MUTE to mute audio. Radio stations, CB, intercom, navigation audio and prompts are muted. Media devices are paused.

Unmute/Resume: To resume audio or media files, briefly press POWER/MUTE switch again.

NOTE

- *Audio can also be unmuted by pressing the volume switches on the left hand control.*
- *Media can also be resumed by pressing the PREVIOUS/NEXT switch on the left hand control.*
- *The POWER/MUTE switch does not mute phone call audio. Use the Mute function in the phone menu to mute inbound/outbound phone audio during a call. See Muting Call Audio (Page 90).*

HOME SWITCH

Press the HOME switch to display the Home screen. Press the switch again to show the current audio source (tuner station, media file, or phone screen).

FAVORITE SWITCH (FAV)

The favorite (FAV) switch can be set to one audio source (radio station, tuner band, media file, or media player). After the FAV switch has been set, briefly press the switch to begin playing the selected audio source.

Setting FAV switch (tuner band): Press and hold FAV switch. Select **Tuner**. Select desired band (AM, FM, WB, and so on).

Setting FAV switch (radio station): Tune to a desired station (such as 105.7 FM or WB1). Press and hold FAV switch. Select the desired station on the screen.

Setting FAV switch (media player): With media player connected to the USB port, press and hold FAV switch. Select the media player on the screen.

Setting FAV switch (media file): With a media file playing, press and hold the FAV switch. Select the media file on the screen.

Listening to favorite: Briefly press the FAV switch. The band, station, or media will begin playing. Any media files or devices stored as a favorite must be connected to the USB port.

NOTE

- *The FAV switch only stores one audio source. The Favorites list on the Home screen is a separate feature which can store multiple presets. See Favorites (Page 55).*
- *To overwrite the currently stored favorite, repeat the procedure for setting the favorite.*
- *The FAV switch cannot be set to navigation locations, phone features or CB channels.*

NAVIGATION SWITCH: 6.5 ONLY

Navigation Menu/Map: Press the NAVIGATION switch to display the navigation menu (or navigation map, if active). Press the switch again to toggle between the map and navigation menu.

Display Audio Source on Map: While map is displayed, press and hold the NAVIGATION switch. The current audio source (radio station or media file) will be displayed along the bottom of the map screen. Press and hold the switch again to hide the audio source.

Compass: For 6.5 radios without navigation, press the NAVIGATION switch to display the compass.

See Navigation (Page 141) to configure and operate the navigation features.

HARD KEYS: 4.3 ONLY

See Figure 4. Press the hard keys along the left and right side of the screen to select menu items and operate the system. Press the hard key that aligns with the desired function on the screen as shown.

TOUCHSCREEN: 6.5 ONLY

See Figure 4. Press on the touchscreen to select menu items and operate the radio. The touchscreen can be operated while wearing riding gloves.

The screen is designed to minimize glare, be viewable in all lighting conditions and be operable in wet weather conditions. The touchscreen is covered with a replaceable protective film. Keep this screen protector on the screen at all times to prevent damage to the screen. Damage to the screen due to use without the screen protector will not be covered under warranty. Remove and replace the protector if it becomes dull, scratched or worn.

To properly care for the radio faceplate and touchscreen, see Care and Cleaning (Page 77).

BOOM! BOX HAND CONTROLS

Some features and functions shown are model and/or region-specific.

See the vehicle owner's manual for functionality of other hand control switches.

Left Hand Control Audio Functions




Figure 5. Left Hand Control Audio Functions (typical)

Table 18. Left Hand Control Audio Functions

ITEM	ICON	NAME	FUNCTION
1		Home	Toggles between current screen and Home screen
2		Previous /Seek Down	Media: Previous media file. Tuner: Tune/seek/next preset down.
3		Next/Seek Up	Media: Next media file. Tuner: Tune/seek/next preset up.
4		Volume Up	Increases volume
5		Volume down	Decreases volume
6		Voice Recognition	Initiates a voice recognition session

Right Hand Control Audio Functions




Figure 6. Right Hand Control Audio Functions (typical)

Table 19. Right Hand Control Audio Functions

ITEM	ICON	NAME	FUNCTION
1		Information	Press: Display vehicle status Hold: Display high contrast day colors
2	SQ +	CB Squelch +	Increases CB squelch level (if equipped).

Table 19. Right Hand Control Audio Functions

ITEM	ICON	NAME	FUNCTION
3	SQ -	CB Squelch -	Decreases CB squelch level (if equipped).
4	PTT	CB Push to Talk	Press and hold to transmit on CB/intercom (if equipped).
5		Cursor Up	Moves the highlighting up through the selections.
6		Cursor Right	Moves the highlighting right through the selections.
7		Cursor Down	Moves the highlighting down through the selections.
8		Cursor Left	Moves the highlighting left through the selections.
9		Select /Enter	Selects highlighted item.

HOME/VOLUME/PREVIOUS/NEXT SWITCH

See Figure 5. The HOME/VOLUME/PREVIOUS/NEXT five-way switch operates radio features on equipped vehicles.

The operation of the HOME switch depends on whether the Classic Mode setting is enabled. To enable or disable Classic Mode, see Classic Mode (Page 48).

HOME (normal mode): Press the HOME switch to display the Home screen. Press the switch again to display the current audio source (tuner station, media file, or phone screen).

HOME (Classic Mode): Press the HOME switch to toggle through available audio sources (tuner bands, media player connected through USB, or Bluetooth connected device). This operates similar to the MODE SEL switch on previous Harley-Davidson motorcycles. To display the Home screen, press and hold the HOME switch on the handlebar or use the HOME switch on the radio faceplate.

PREVIOUS/NEXT: Press the switch to the left or right to seek up/down for a radio station or to select the previous/next media file. Within the Tuner menus, this switch can be configured to advance to the next frequency (tune), the next station (seek) or the next preset. See Tune/Seek/Preset Settings (Page 58).

VOLUME: Press the switch up to increase volume or down to decrease volume to the speakers or rider headset. The volume control can also unmute audio and resume media.

NOTE

- *Unlike the MUTE switch, decreasing volume to zero does not pause media.*
- *The volume output is also affected by the speed volume setting. See Speed Volume (Page 47).*
- *CB, intercom, phone calls and system prompts have independent volume levels. Adjust the volume for these different audio sources while they are active. See the sections for each of these functions for operation.*

VOICE RECOGNITION SWITCH

See Figure 5. This switch activates the voice recognition features on equipped vehicles. With a headset connected, press the VOICE RECOGNITION switch. The radio beeps and shows a list of available commands. Speak the desired command into the headset microphone. See Voice Recognition (Page 179).

To cancel voice recognition, press and hold the VOICE RECOGNITION switch for three seconds, or press the HOME hand control switch.

PUSH-TO-TALK/SQUELCH SWITCH

PTT: See Figure 6. Press the PTT switch to transmit over CB or intercom. Both the rider and passenger microphones are live. Intercom can also be operated by voice activation (VOX).

Squelch (SQ+/SQ-): Raise squelch (SQ+) to prevent noise or unwanted weak signals from unmuting the CB. Lower squelch (SQ-) to a level that allows desired CB signals to unmute the CB.

CURSOR/SELECT SWITCH

See Figure 6. The CURSOR/SELECT five-way switch can be used to select items on the radio screen.

CURSOR: Press the switch in the desired direction to move the highlighted cursor to another selection on the radio screen.

SELECT: Press the switch straight in to select a highlighted item or toggle a feature on the radio screen.

VEHICLE INFORMATION SWITCH

Vehicle status: See Figure 6. Press the VEHICLE INFORMATION switch to display or exit the vehicle status screen. See Vehicle Status (Page 185).

High contrast day colors: Press and hold the VEHICLE INFORMATION switch to toggle the screen to high contrast day colors. See High Contrast Day Colors (Page 42).

REAR (PASSENGER) CONTROLS

See Figure 7. Some vehicles have passenger controls on the right side of the Tour-Pak. These controls allow the passenger to operate functions in the radio.

MODE/UP/DN Switch

MODE: Press switch straight in to select the next available audio source.

UP/DN: Press switch up/down to select the previous/next radio station or media file.

Push-To-Talk (PTT)/Volume (VOL) Switch

PTT: Press switch to transmit over CB or intercom.

VOL+/VOL-: Press switch up (or down) to raise (or lower) the volume to the passenger headset. This switch does not affect the rider headset volume or speaker volume.

Enabling Rear Controls

The PTT/VOL switch is always enabled. However, the MODE/UP/DN switch can be enabled or disabled through the setup screens. See Rear Controls (Page 48) to enable these rear controls.




Figure 7. Passenger Controls

Table 20. Rear (Passenger) Control Audio Functions

ITEM	ICON	NAME	FUNCTION
1	MODE	Mode	Cycles to next available audio source.
	UP	Next/Seek Up	Tuner: Seek up. Media: Next file.
	DN	Previous /Seek Down	Tuner: Seek down. Media: Previous file.
2	PTT	CB Push-to-Talk	If Equipped: Press and hold to transmit on CB/intercom.
	VOL+	Volume Up	Increases volume.
	VOL-	Volume Down	Decreases volume.

HEADSET CONNECTION

⚠ WARNING

Do not select a volume level that blocks out traffic noise or interrupts the concentration necessary for safe operation of the motorcycle. Distractions or a volume level that blocks out traffic noise could cause loss of control resulting in death or serious injury. (00539b)

NOTICE

Do not pull on the cord to remove the headset from the socket. Pull on the headset jack to disconnect the headset from the socket. (00174a)

See Figure 8 and Figure 9. Some vehicles have a rider headset connector on the fuel tank panel and a passenger headset connector on the left speaker pod. The headsets are used to operate the CB, intercom, voice recognition commands and other features on equipped models.

Use the Harley-Davidson 7-pin DIN headset that is supplied with equipped models or purchased from a Harley-Davidson dealer. Other headset microphones are not compatible. See the instructions that are included with the headset to install in a helmet. Connect the headset by aligning the ridge on the headset with the slot on the connector as shown in Figure 8. The headset only works if the connector is properly installed.

When using headsets, set the volume to a level where traffic and sounds from the surrounding environment can still be heard.

The socket caps remain shut when not in use to prevent dirt and water from entering the socket. Close both socket caps before washing the motorcycle.




Figure 8. Rider Headset Connector (typical)




Figure 9. Passenger Headset Connector

Microphone Positioning

Full face helmets: See Figure 10. Route the boom below the helmet, with the microphone oriented upright inside the helmet, so the boom does not touch the chin.

Open face or half helmets: See Figure 10 and Figure 11. Position the microphone lightly touching or directly to the left of the mouth.




Figure 10. Microphone Positioning




Figure 11. Headset and Microphone Positioning

MEDIA COMPARTMENT: USB PORT

See Figure 12 and Figure 13. The media compartment has a USB port to connect with a phone, media device or USB drive. An interface cable may be needed to connect with devices. The USB port is powered and operational when the vehicle is turned on or in accessory mode. Connected devices may be used for the following purposes.

Phone: Charges the phone and plays media files from the phone. However, phone calling and text messaging features are achieved only through Bluetooth connection.

Media device: Charges the device and plays media files.

USB drive: Plays media files, imports/exports navigation files, loads software updates, and imports ring tones.

Memory card: Some types of memory cards can be connected to play media files. Connection requires an adapter or reader.

NOTE

Do not use media players with hard drives. Vibration may cause internal damage.

Devices can be added or removed while the radio is on. However, when importing/exporting files or installing updates to the radio, do not disconnect the USB device until the task has completed.

Keep the compartment door closed while riding to prevent items from falling out. Remove valuable items from the media compartment before leaving the vehicle unattended.

Media Compartment: Fixed Fairing Vehicles

See Figure 12. Fixed fairing vehicles have a media compartment in the right side of the fairing.

Open: Pull up on the front of the compartment door to open as shown.

Cleaning: The rubber or fabric insert in the compartment is attached with hook and loop fastening tape and can be removed for cleaning.

Media Compartment: Fork Mounted Fairing Vehicles

See Figure 13. Other vehicles have a media compartment on the right side of the radio as shown. Insert the phone or media device into the foam cradle to secure the device and isolate it from vibration.

Open: Push lower portion of door and release to open.

Close: Firmly push the door shut until the latch engages.

Reset door latch: If compartment door was forced open or is not latching properly, the door latch may need to be reset. Push the door shut. Open the door. Close the door again to engage the latch mechanism.

Cleaning: The cradle can be removed for cleaning or to assist with installing or removing a device from the compartment.

USB Hub

A USB hub (not included) can be used to connect multiple USB devices to the radio simultaneously. The radio automatically begins playing media from the last connected device.

In the radio, select **Home > Media** to display a list of all connected devices. Music players are identified with a musical note icon. Other USB devices are identified with a USB icon.

NOTE

- *Do not use a hub when installing software or map updates.*
- *Connecting too many items through a hub can exceed the charging current available through the USB port. Insufficiently powered hubs can impact radio compatibility.*




Figure 12. Storage/Media Compartment: Fixed Fairing Models




Figure 13. Media Compartment: Other Models

SPEAKERS

The speaker types and arrangements are different across models. All speakers are weatherproof and sealed for use in all riding weather conditions. See Care and Cleaning (Page 77) to properly care for speakers. See www.h-d.com/store for available speaker options.

Fairing Speakers

Front speakers are designed into a ported enclosure in the fairing for additional bass response and higher fidelity. Models include different speaker specifications and arrangements within the inner fairing.

Fairing Lower Speakers

Fairing lower speakers are equipped on some models to provide more volume for the sound system. These are also available as accessories for vehicles with air-cooled engines.

Saddlebag Speakers

Saddlebag speakers are equipped on some models to provide additional surrounding volume for the sound system. These speakers use the saddlebag enclosure to provide enhanced bass response. A small amount of water may occasionally collect in the speaker cavities while parked outdoors. The saddlebag speakers are weatherproof, and the heat from speaker operation would soon evaporate the water, but there could be a temporary effect on sound quality. To promptly empty the speaker cavities, lift the saddlebag lids. Saddlebag speakers are also available as accessories.

Tour-Pak Speakers

These forward-facing speakers direct sound to the rider and passenger. The bass boost ports use the enclosed space in

the Tour-Pak to provide an enhanced bass response with reduced distortion. The bass response of these ports may be affected when items are stored in the Tour-Pak or when the Tour-Pak lid is open.

AMPLIFIER

Some vehicles include an additional amplifier to drive greater sound output to the speakers. Boom! audio amplifiers bypass the internal amplifier in the radio to provide increased volume, reduced clipping, lower Total Harmonic Distortion (THD), optimized equalization and a fuller sound that cuts through wind and road noise. The amplifier is also available as an accessory.

Additional amplifiers may be needed when adding speakers to a vehicle.

ANTENNAS AND RECEPTION

NOTICE

Operating the CB radio without an antenna or with a broken antenna cable can result in damage to the transmitter circuitry. (00176a)

Tuner and CB antennas: See Figure 14. Antennas on the rear of the vehicle may be removed during vehicle storage. Make sure to install antennas before operating the radio. To install, hand tighten the antennas to the mounts. Antennas

for the tuner and CB are different. For vehicles with a CB, always install the CB antenna (marked with the letters "CB" at the base of the mast) on the right side of the motorcycle. The antenna marked "AM/FM" is for tuner reception. Installing the incorrect antenna for the tuner or CB will result in degraded reception.

Hidden tuner antenna: Some vehicles have an antenna installed in the fairing for tuner reception (AM/FM/WB).

Satellite antennas: SiriusXM and GPS antennas are mounted within the fairing on equipped models. These antennas require no maintenance. SiriusXM satellite radio and GPS reception may be weaker when the vehicle is indoors.




Figure 14. Antennas

BLUETOOTH

The system has Bluetooth capability for accessing media files and phone operation. See the Bluetooth (Page 79) section to set up and connect devices.

TURNING MOTORCYCLE ON, OFF OR TO ACCESSORY MODE

Turning on motorcycle: When the motorcycle is turned on, the radio returns to its previous state before shutdown. Features such as CB, intercom, current station or media playing resume as before the vehicle was turned off. A Bluetooth connection to the phone will attempt to resume.

Starting the engine: When starting the engine, the audio mutes and the screen turns off momentarily.

Radio on/off: If the radio is turned off before the vehicle is shutdown, it will remain turned off when the vehicle is turned back on.

Restart radio: To reinitialize the radio, allow the vehicle to remain turned off for up to 30 seconds before turning the vehicle back on.

Accessory mode: When the vehicle is in accessory mode, operation of the radio will result in some battery drain. The motorcycle will automatically turn off after two hours in accessory mode. Keyed vehicles enter/exit accessory mode by turning the ignition switch to the appropriate position. Keyless vehicles enter/exit accessory mode by holding the trigger switch.

Turning off motorcycle: If turning off the motorcycle while in an active phone call, the radio will prompt to transfer the

call back to the phone. If the prompt is not accepted, the radio will continue to support the call for approximately five minutes before automatically transferring the call back to the phone and shutting down. See Resuming Calls After Vehicle Shutdown (Page 98).

DISCONNECTING THE VEHICLE BATTERY

The system retains user data and system settings when the vehicle battery has been disconnected or main fuse is removed. Features such as navigation routes, paired devices, phone books, favorites, presets and system settings are retained in memory. The radio returns to its previous functionality after the battery is reconnected to the vehicle.

HOME SCREEN

See Figure 15. The Home screen provides access to all the features available for the system. The layout of items on this screen may be different depending on radio type and installed features.

According to the radio type, use the touchscreen, soft keys or CURSOR/SELECT hand control switch to make selections and operate the system.

During initialization and startup, some features may be unavailable for a short time (such as navigation, SiriusXM, media and voice recognition).




Figure 15. Home Screen (6.5 with SiriusXM shown)

SCREEN MENU BAR

See Figure 16. Many screens have a menu bar at the top of the screen. The menu bar and its components change according to the screen being displayed.

Title: The title of the screen or function is located in the center of the menu bar. The screen title is not a selectable button.

Buttons: Some menu bars contain a selectable button on the right, left or both sides of the screen title.



Figure 16. Screen Menu Bar

CHECKBOXES

See Figure 17. Some options are selected or enabled with a checkbox as shown.




Figure 17. Checkbox - Function Enabled (typical)

MULTISELECT BUTTON

See Figure 18. Multiselect buttons have a plus sign (+) with an arrow symbol on the button. The text shown on the button is the currently active setting.

Repeatedly press the multiselect button until the desired selection is displayed.




Figure 18. Multiselect Button (typical)

SCROLL CONTROLS

See Figure 19. Scroll controls are displayed on the side of the screen when there is more than one page of available options. Use the soft keys, touchscreen or CURSOR/SELECT hand control switch to scroll through multiple pages of options. Press and hold the scroll controls to rapidly scroll through long lists.

Refer to Table 21. Some lists have a center button for functions such as letter jump, information, editing or reordering of the list.




Figure 19. Scroll Controls

Table 21. List Function Buttons

BUTTON	NAME	DESCRIPTION
	Option menu	Opens a menu of additional options. Select the button again to return to the original screen.
	Letter jump	Jumps to a selected location within the list. For example, to jump to entries starting with the letter 'S', select the letter jump button, then select 'S' from the keyboard.
	Reorder	Changes the order of the list (such as sorting by distance or listing by alphabetical order).
	Edit	Select this button to view or edit information related to the list contents.
	Information	Displays more information related to the list contents.
	Delete	Deletes data associated with the list (such as all recent destinations).

KEYBOARD

The keyboard is used for selecting navigation destinations, searching media files, saving contact information or entering other data into the radio when needed. The keyboard is operated by touchscreen or by using the CURSOR/SELECT hand control switch to select letters.

The 6.5 radio supports a full size keyboard and a large keyboard. See Keyboard: 6.5 Only (Page 44) to select the keyboard type. The 4.3 radio uses a screen similar to the full keyboard for entering data.

The large keyboard may be more suitable for use when wearing riding gloves. When using the keyboard, some letters may be blanked out. This is a feature of the smart speller, which only enables valid strings of letters according to the entries in the database.

Input is displayed in the title bar. Select the buttons for numbers, symbols or extended characters to display keypads with additional characters as needed. When finished with a keyboard entry, select OK.

Full Keyboard: See Figure 20. When input is required, the screen displays a full keyboard with alphabetically arranged characters A-Z.

Large Keyboard: See Figure 21. When input is required, the screen displays a keypad with larger buttons. Use the keypad selectors on the right side to display different portions of the alphabet (A-I, J-R or S-Z).




Figure 20. Full Keyboard




Figure 21. Large Keyboard

SMART SPELLER

The smart speller assists you when entering information into the radio. When entering information (such as a search for a

navigation address), the keyboard only enables strings of letters that match the entries in the database.

After a number of letters have been entered, the system will predict the word or location that you are trying to enter by providing matching data from the database. For example, entering "ROCH" could cause the system to suggest "ROCHESTER".

The smart speller can also accept partial entries. If pressing OK with only a partial string of text, the radio will provide a list of items that begin with that text. For example, entering "SAN" and pressing OK could provide a list including "SAN FRANCISCO" and "SANTA ANA".

The smart speller can also assist when entering multiple words. Entering the first few letters of each word, separated by a space, will cause the system to respond with matching words. For example, entering "N D" (including space) could cause the system to respond with "NORTH DAKOTA".

VOLUME CONTROLS

A volume indicator is shown when the rider or passenger presses the volume control switch.

Rider (controls on handlebar): Adjusts the volume level for the speakers and the rider headphones (if active).

Passenger (on Tour-Pak equipped models): Adjusts the volume level for the passenger headphones only.

If the volume controls are pressed during a prompt or a specific function (such as during voice recognition, navigation prompt, CB or intercom activity), the volume for that particular function will be changed and displayed on the screen.



Figure 22. Adjusting Headset Volume

POPUP SCREENS

The radio displays popup screens to explain when a feature is unavailable, display a low fuel message, indicate an incoming phone call, and so on. These screens may interrupt normal system operation. Some screens require a choice (Yes/No) or require confirmation (OK). Press the button to acknowledge the message or activate the feature.

LOCKOUT SCREENS

Some screens, features or menu items may be locked out or unavailable, such as when the vehicle is in motion.

To operate the features, follow the guidance that is provided on the popup screen. If necessary, use hands-free voice recognition commands or safely park the vehicle to perform the task.

STATUS BAR

See Figure 23. The status bar is at the bottom of most screens. It displays the clock and status icons. The icons are informational and are not selectable.



Figure 23. Status Bar

Table 22. Status Bar Icons

ICON	NAME	FUNCTION
	Speakers not muted	Music/media is playing through the speakers.
	Speakers muted	Music/media is routed to the speakers. Speakers are muted.
	Headsets not muted	Music/media is playing through the headsets.
	Headset is Bluetooth connected	Bluetooth device is connected. Music/media is routed to the wireless headset speakers.
	Headsets muted	Music/media is routed to the headsets. The rider headset is muted.
	Traffic Announcement	The tuned RDS station is actively broadcasting an audio traffic announcement (select markets only).
	Traffic Program	The tuner is set to an RDS station that regularly broadcasts traffic bulletins (select markets only).
	SiriusXM Signal Strength	SiriusXM satellite signal strength (3 bars).
	Intercom microphone idle	Intercom is turned on, but not currently in use.
	Intercom microphone active	Intercom is actively in use (PTT switch pressed or VOX activated).
	Harley-Davidson Bar & Shield	Symbol is displayed in the center of the status bar.
	Citizen Band (CB) idle	CB is turned on. Not currently transmitting. No CB signals are being received (squelch not broken).
	CB active	CB is transmitting or incoming CB signal is being received (squelch has been broken).

Table 22. Status Bar Icons

ICON	NAME	FUNCTION
	Bluetooth	Bluetooth device is connected. Not displayed when Roaming, New Messages, Low Battery or Phonebook icons are shown.
	Roaming	Bluetooth-connected phone is in a roaming area.
	New Messages	Bluetooth-connected phone has received a text message.
	Low Battery	Bluetooth-connected phone has a low battery.
	Phonebook	Bluetooth-connected phone is downloading phonebook data to the infotainment system.
	Voice Recognition active	Voice recognition switch has been pressed. System is prompting or processing voice commands.
	Voice Recognition not ready	Voice recognition system is initializing.
	Media paused	Media is paused. Press POWER/MUTE switch to resume audio.
	Scan up	System is scanning up, briefly dwelling on each active frequency or media file.
	Scan down	System is scanning down, briefly dwelling on each active frequency or media file.
	Seek up	Tuner is seeking up for the next active frequency.
	Seek down	Tuner is seeking down for the next active frequency.
	Phone Signal Strength	Bluetooth-connected phone signal strength (3 bars).

Table 22. Status Bar Icons

ICON	NAME	FUNCTION
N	North (direction)	Navigation system has determined the vehicle is traveling north.
S	South (direction)	Navigation system has determined the vehicle is traveling south.
E	East (direction)	Navigation system has determined the vehicle is traveling south.
W	West (direction)	Navigation system has determined the vehicle is traveling west.
NE	Northeast (direction)	Navigation system has determined the vehicle is traveling northeast.
NW	Northwest (direction)	Navigation system has determined the vehicle is traveling northwest.
SE	Southeast (direction)	Navigation system has determined the vehicle is traveling southeast.
SW	Southwest (direction)	Navigation system has determined the vehicle is traveling southwest.

SYSTEM SETUP

Configure the system settings before riding the motorcycle, with the motorcycle stationary and set to accessory mode. Adjust the options to match your personal riding style, and to make best use of any features or devices that you may be using. If there are problems with any features in the radio, first check the relevant settings.

Most settings are similar for all radios. However, some features or selections may be unique or unavailable on some vehicles. Some settings may also be specific for particular countries or regions. See Features and Specifications (Page 5) for more information about the features available on your motorcycle and in your region.

If audio accessories have been added to the motorcycle, see the instruction sheets for proper configuration and operation of those accessories.

SETUP MENU

See Figure 24. Select **Home > Setup**. Some of the settings may be disabled or not displayed, depending on the radio type and region. For a list of all the categories that can be configured, refer to Table 23.



Figure 24. Setup Menu

Table 23. Setup Menu

ITEM	SETTINGS
Speaker/Headset	Music/Media Communication Prompts
Audio Setup	Bass Treble Fade Speed Volume
Display	Screen Brightness Button Brightness Colors (Day/Night Color Mode, Background Color*, High Contrast Day Colors)
Global Presets	Global Presets On/Off Number of Pages
Full/Large Keyboard*	---
Feedback Settings	Prompt Volume Beep volume Nav Prompts (On/Off)

Table 23. Setup Menu

ITEM	SETTINGS
Bluetooth Setup	Bluetooth On/Off List Paired Devices (Add New Device) Ring Tones
English Units/Metric	---
Clock	User Time/GPS Time 12 Hour/24 Hour Daylight Savings Time (DST) On/Off Zone (Auto) or varied by region
SiriusXM Setup*	Subscription (Radio) Subscription (Specialty Services)
Traffic*	Traffic On/Off Re-route (Off/Auto/Manual) Notification
Navigation Setup*	Route Calculation Appearance
Rear Controls On/Off*	---
System Information	Software Hardware EQ Navigation
Language	English (US) English (UK) French (CA) French (FR) German (DE) Italian (IT) Spanish (ES) Spanish (MX) Portuguese (PT)
Classic Mode On/Off*	---

*Features are only available or enabled on some vehicles or regions.

LANGUAGE

See Figure 25. The system can be configured for any of the languages shown in Table 24. The selected language affects the text displayed on the screen, voice prompts from the system, and voice recognition features. To make sure that the system works properly for your use, select the proper language and dialect as applicable.



Figure 25. Language Setting

Table 24. Language Settings

SETTING	LANGUAGE/REGION
English (US)	American English
English (UK)	British English
French (CA)	Canadian French
French (FR)	France
German (DE)	Germany

Table 24. Language Settings

SETTING	LANGUAGE/REGION
Italian (IT)	Italy
Spanish (ES)	Castilian Spanish (Spain)
Spanish (MX)	Mexican Spanish
Portuguese (PT)	European Portuguese (Portugal)

SCREEN BRIGHTNESS

1. See Figure 26. Select **Home > Setup > Display > Screen Display**.
2. To switch between manual and automatic:
 - a. **Automatic:** Check the **Automatic** checkbox. The screen brightness will automatically adjust according to the ambient light measured by the sensor in the speedometer.
 - b. **Manual:** Uncheck the **Automatic** checkbox. Adjust the brightness level.



Figure 26. Display Feature

BUTTON BRIGHTNESS

1. See Figure 27. Select **Home > Setup > Display > Button Brightness**.
2. Adjust the brightness level.

NOTE

- *The brightness settings do not affect the brightness of vehicle instruments, illuminated hand control switches (on select models) or other accessories.*
- *The faceplate button lighting remains off when the radio is in Day Colors mode.*



Figure 27. Button Brightness



Figure 28. Colors

DAY/NIGHT COLORS MODE

1. Select **Home > Setup > Colors**.
2. Press the multiselect button until the desired color mode is displayed.
 - a. **Day Colors:** Screen shows brighter colors.
 - b. **Night Colors:** Screen shows darker subdued colors. Navigation map is also shown in night color scheme. No other background colors can be selected while in night color mode.
 - c. **Automatic Colors:** Screen automatically adjusts day/night color modes according to ambient light measured by the sensor in the speedometer.

HIGH CONTRAST DAY COLORS

High contrast day colors can be activated to enhance visibility of the screen in bright sunlight.

This feature is activated through the color settings, or by holding the VEHICLE INFORMATION switch. The feature cannot be activated while the display is showing night colors.

1. See Figure 29. Select **Home > Setup > Colors**.
2. With **Day Colors** or **Automatic Colors** selected, check the **High Contrast Day Colors** checkbox.




Figure 29. High Contrast Day Colors

BACKGROUND COLOR: 6.5 ONLY

1. See Figure 30. Select **Home** > **Setup** > **Colors** > **Backgrounds**.
2. Select one of the listed colors or Default (orange).




Figure 30. Backgrounds

ENGLISH UNITS/METRIC

1. Select **Home** > **Setup**.

NOTE

The English unit/metric selection also affects how units are displayed in the odometer.

2. Press the multiselect button until the desired unit type is displayed.
 - a. **English Units:** Measurements are displayed as miles, yards, feet, mph, gallons, degrees F and PSI.
 - b. **Metric:** Measurements are displayed as kilometers, meters, km/h, liters, degrees C and bar.

CLOCK

1. See Figure 31. Select **Home > Setup > Clock**.
2. **12/24 hour:** Select 12-Hour or 24-Hour clock mode.
3. Press the multiselect button to choose GPS, RDS or User Time.
 - a. **GPS:** Automatically synchronizes the clock with data from incoming GPS signals. GPS time is only available on radios with navigation.
 - b. **RDS:** Automatically synchronizes time with radio stations broadcasting RDS data. RDS is only available on radios within regions that support RDS operation.
 - c. **User Time:** Time is manually entered.
4. **Time zone:** Select the time zone. For GPS time, AUTO causes the clock to adjust to the time zone for the vehicle location. The clock updates as the motorcycle passes into other time zones.
5. **Daylight savings time (DST):** GPS time does not automatically account for daylight savings time. For GPS or user time, select **DST On** to advance the clock one hour (during spring in the northern hemisphere). Select **DST Off** to return to the original time.

6. Manually adjusting time:
 - a. **Manually adjusting time (User Time selected):** Manually adjust the clock to the current time with the + and - controls.
 - b. **Manually adjusting time (GPS Time selected):** An offset can be applied to the GPS time. The offset is shown next to the time setting.




Figure 31. Clock Settings

KEYBOARD: 6.5 ONLY

1. See Figure 32. Select **Home > Setup**.

2. Select **Full Keyboard** (which displays all characters) or **Large Keyboard** (which displays a larger keypad). See Keyboard (Page 33) for keyboard types.



Figure 32. Keyboard Setting: Full/Large

SPEAKER/HEADSET SELECTION

1. See Figure 33. Select **Home** > **Setup** > **Speaker/Headset**.

2. For each category shown, select whether the audio routes through the headsets or speakers.
 - a. **Music/Media:** Tuner stations, SiriusXM channels and media files.
 - b. **Communication:** CB, intercom and phone.
 - c. **Prompts:** Voice recognition, navigation prompts, text-to-speech and other audio feedback from the radio.



Figure 33. Speaker/Headset Selection

AUDIO SETTINGS: BASS/TREBLE

1. See Figure 34. Select **Home** > **Setup** > **Audio Setup**.
2. Adjust the Bass and Treble settings using the + and - controls. The tone settings are applied for all audio output through the speakers and headsets.



Figure 34. Audio Setup Screen

FADE

The fade setting adjusts the balance of volume between the front and rear speakers. By default, the fade is set at the center with an equal balance of volume. Some vehicles have a fade adjuster as shown in Figure 35. Other vehicles have a graphical fade adjuster as shown in Figure 36.

The fade setting does not affect headset or microphone audio levels. Fade does not apply to models without rear speakers.

1. Select **Home > Setup > Audio Setup**.
2. Select **Fade/Speed Volume**.

3. Adjust the front to rear fade.
 - a. **Fade adjustment (typical):** Press the R (rear) or F (front) controls to adjust the balance of the speaker volume between the front and rear speakers. The center circle indicates an equal balance of volume to both front and rear speakers.
 - b. **Graphical fade adjustment (select models):** Adjust the front to rear sound balance by pushing left or right cursor controls. The fade adjustment line displays the balance of sound between the front and rear speakers. The center dashed line represents the equal balance of volume for front and rear speakers. Vehicles with lower speakers will have a horizontal line to adjust balance between the upper and lower speakers.



Figure 35. Fade/Speed Volume Adjustment Screen




Figure 36. Graphical Fade Adjustment: Select Models

SPEED VOLUME

The speed volume setting adjusts the volume according to vehicle speed. This function allows the volume to be set to a comfortable level while the motorcycle is stopped or traveling slowly. The volume automatically increases to compensate for engine, wind and other ambient noise factors as vehicle speed increases.

The speed volume setting also affects the voice activation (VOX) of the intercom. This prevents ambient noise from activating VOX transmissions when at greater speeds. It also prevents the need to continually adjust the VOX sensitivity setting.

Speed volume is also known as automatic volume control (AVC) on previous Harley-Davidson sound systems.

1. Select **Home > Setup > Audio Setup**.
2. See Figure 35. Select **Fade/Speed Volume**.
3. Adjust speed volume to one of four different levels. Each level defines the amount of gain that is added to the volume as vehicle speed increases.

NOTE

- *Setting speed volume to the lowest level effectively turns off this feature. The volume remains constant while riding. However, the radio has equalizers with dynamic filters which modify certain frequency bands depending on speed. So there may still be a change in sound as the speed changes, even with speed volume turned off.*
- *The effects of the speed volume will be less noticeable under certain conditions, such as when the volume is already turned up near its maximum setting.*

FEEDBACK PROMPTS

The prompt volume affects audible feedback, such as navigation prompts, voice recognition prompts, text-to-speech features and so on. Prompt volume can also be adjusted by the volume hand controls while the prompt is playing.

1. See Figure 37 Select **Home > Setup > Feedback**.

2. **Prompt volume:** Adjust prompt volume.
3. **Navigation prompts:** Check the **Enable Nav Prompts** checkbox to enable audible navigation guidance. Uncheck to turn this feature off.
4. **Beep volume:** Adjust beep volume.



Figure 37. Feedback Settings

REAR CONTROLS

1. See Figure 38. Select **Home** > **Setup**.

2. Select the **Rear Controls** checkbox.
 - a. **Checked:** All passenger controls on the side of the Tour-Pak function normally.
 - b. **Unchecked:** The passenger volume and PTT controls continue to operate normally. However, the MODE/UP/DN switch is disabled. The passenger cannot change audio sources or tune/seek to other channels or songs.



Figure 38. Rear (Passenger) Controls

CLASSIC MODE

When Classic Mode is selected, the HOME hand control switch will toggle through available audio sources, rather than displaying the Home screen. This operates similar to the MODE SEL switch on previous Harley-Davidson motorcycles. For example, repeatedly pressing the HOME switch on the

handlebar will toggle through tuner bands (AM, FM, WB and so on) and through media devices.

To display the Home screen while in Classic Mode, press and hold the HOME hand control switch or use the HOME switch on the radio faceplate.

1. See Figure 39. Select **Home > Setup**.
2. Check the **Classic Mode** checkbox to enable.



Figure 39. Classic Mode Setting

GLOBAL PRESETS

The global preset feature shows a common set of presets for all audio sources. Presets for all tuner band stations (AM, LW, MW, FM, WB), media files and SiriusXM channels are commonly displayed on all audio source screens. This allows easier access to the most commonly used channels and

media, without having to manually change to different devices or audio sources. When enabled, the system supports up to 20 global presets.

When global presets are not enabled, each tuner band or media device will only display its own unique presets. The total number of presets is different when global presets are not enabled. CB channels, phone contacts and navigation destinations cannot be stored as global presets. See Presets (Page 60) for more information.

1. See Figure 40. Select **Home > Setup > Global Presets**.
2. **Enable/disable global presets:** Check (or uncheck) the **Enable** checkbox.
3. **Set pages:** Refer to Table 25. Select up to four pages of global presets.
4. **To set a global preset:** Select the desired audio source (tuner station, media file or SiriusXM channel). Press and hold the desired preset button to store the new preset.
5. **To select a global preset:** While displaying any audio source, select the desired preset. The system changes to the necessary band or media device to play the selected preset.



Figure 40. Global Presets



Figure 41. Global Preset Example: Multiple Preset Types On Page

Table 25. Global Presets: Page Setting

PAGES	TOTAL PRESETS
1 page	6 presets
2 pages	10 presets
3 pages	15 presets
4 pages	20 presets

BLUETOOTH

See the Bluetooth (Page 79) section and other applicable sections for configuration and operation of Bluetooth devices.

RING TONES

See Selecting Ring Tone (Page 97) for setting up or installing a new ring tone.

SIRIUSXM

See SiriusXM (Page 123) for setting up and subscribing to SiriusXM on equipped vehicles.

TRAFFIC

See Traffic (Page 171) to set up and operate traffic features.

SYSTEM INFORMATION

1. Select **Home > Setup > System Information**.

2. Select the information to display.
 - a. **Software:** See Figure 42. Shows the current software version installed on the radio. Software updates are available on www.h-d.com/boom (or the Boom! Box portion of www.h-d.com/touring). See Software Update (Page 52) for instructions.
 - b. **Hardware:** See Figure 43. Shows the Harley-Davidson part number, supplier part number and a unique serial number for the radio. Use the Harley-Davidson part number along with the information in Features and Specifications (Page 5) to determine the features available on this radio.
 - c. **EQ:** Shows the equalizer (EQ) file installed in the radio. This is based on the vehicle, fairing type and speaker configuration. The EQ may be updated by the dealer when adding new accessory speakers to the motorcycle.
3. Select **Navigation**.
4. Select the navigation information to display.
 - a. **Software:** Shows the current software version for the navigation software engine.
 - b. **Database:** See Figure 44. Shows the current map database version that is installed in the radio.
 - c. **Export for Update:** Used when updating or purchasing new map sets. See Navigation Database (Page 174) to install or update maps.



Figure 42. Software Version




Figure 43. Hardware Information



Figure 44. Navigation Database Version

SOFTWARE UPDATE

Harley-Davidson periodically provides software updates for the radio on www.h-d.com/boom. Check if you are using the latest version of software and update the software when a

newer version is available. Updates can be done by using the following procedure or by bringing the vehicle to an authorized Harley-Davidson dealer.

1. See Figure 42. Select **Home > Setup > System Information > Software**.
2. Compare the software version in the radio with the latest version of software available on www.h-d.com/boom (or www.h-d.com/touring > Owners > Software Downloads).
3. **Versions are the same:** You have the latest software available. There is no need to update. **Higher software level is available on website:** Continue with procedure to update your radio software.

NOTE

Do not interrupt the installation process. Leave the vehicle and radio turned on, and keep the USB drive installed until the installation process is complete.

4. Download the latest software version from the website. Select the proper update for your radio type (4.3, 6.5 or 6.5 CVO) and the proper region/vehicle configuration, if applicable.
5. Unzip the software package to a folder. The folder includes an installation file with an .ISO extension.

6. Copy the .ISO file to the root directory (the first or top directory) of a USB drive. Some updates require up to an 8 GB USB drive.
7. **Keyed ignition motorcycle:** Turn the vehicle ignition switch to ACCESSORY. **Keyless ignition motorcycle:** With the OFF/RUN switch turned off, press and hold the trigger switch until the vehicle enters accessory mode.
8. Turn on the radio.
9. Connect the USB drive to the vehicle USB port. The radio detects the new software and prompts for the update.
10. See Figure 45. Select **Yes**. The software installation begins. The display prompts to remove the USB drive when the update is complete.

NOTE

If the incorrect file is on the USB drive, the radio displays the error message "The ISO image on the attached USB is corrupt or incompatible".



Figure 45. Software Update

PRIVACY RESET

A privacy reset can be performed by the dealer to remove all personal information from the radio memory. This can be useful when selling the motorcycle or when completely reconfiguring the radio with new personal settings. The reset will remove information and history from the radio such as phone pairing, downloaded phone books, call history, navigation history, favorites and presets. A privacy reset does not affect other basic settings like the clock or audio configuration. See an authorized Harley-Davidson dealer to have this service performed.

FACTORY RESTORE

A factory restore can be performed by the dealer to restore the radio to its original factory settings. This removes all user

settings in radio. See an authorized Harley-Davidson dealer to have this service performed.

FAVORITES

The system stores up to six favorites, plus an additional favorite for the FAV switch on the radio faceplate. Favorites can be used to quickly access a tuner band, frequency, media device, media file or SiriusXM channel that is commonly used.

Navigation destinations, phone contacts, CB channels and files from a Bluetooth-connected device cannot be saved as favorites.

SETTING A FAVORITE

1. Tune to a radio station, weather band channel, SiriusXM channel or file from USB-connected device.
2. **Store to FAV switch (on radio faceplate):** Press and hold the FAV switch. **Store to Favorite screen:** Select **Home > Fav.** Press and hold one of the favorite preset buttons from the list.
3. See Figure 46. Select one of the following from the list:
Currently playing audio source: Shown at the top of the list. **Tuner:** Sets the favorite to a selected tuner band (AM, FM, WB, LW or MW as applicable). **Media:** Sets the favorite to a USB-connected device. **Satellite:** Sets the favorite to SiriusXM tuner.

NOTE

The tuner, media and satellite options only set the favorite to the selected device, rather than to a particular station or media file.




Figure 46. Setting a Favorite

SELECTING A FAVORITE

If selecting a file from a removable media device, the radio will do nothing unless the media device is connected.

FAV switch (on radio faceplate): Briefly press FAV switch to select the audio source.

Favorite screen: See Figure 47. Select **Home** > **Fav.** Select a favorite from the list.



Figure 47. Favorites List

TUNER

The radio has a multi-band stereo receiver with tune, seek and scan functions. The tuner supports RDS or RBDS data display (according to vehicle configuration). The tuner can be configured to search for particular program types (such as

country music or news programming). In some radios, the system can accumulate a list of stations within range, along with the current song or program being played.

See Figure 48 for a description of the Tuner screen components. See Features and Specifications (Page 5) for features supported for your vehicle or region.




Figure 48. Tuner Screen

SELECTING A BAND: MENU BUTTONS

Radios support different frequency bands according to region and radio type. See Features and Specifications (Page 5).

1. Select **Home > Tuner**.
2. Select the desired band (AM, LW, MW, FM or WB, as applicable).

SELECTING A BAND: HOME HAND CONTROL, CLASSIC MODE

When Classic Mode is enabled, repeatedly press the HOME hand control switch to rotate through all available bands and audio sources.

SELECTING A BAND: VOICE RECOGNITION

1. Press the VOICE RECOGNITION switch.
2. Speak the band into the microphone (**AM, FM, WEATHER BAND, MEDIUM WAVE** or **LONG WAVE**).

TUNE/SEEK/PRESET SETTINGS

The PREVIOUS/NEXT hand control switch can be configured to tune, seek or select the next preset in the tuner.

When tuning or seeking, the tuner continues to wrap around at the beginning or end of the frequency range.

1. With a tuner band displayed, select **Menu**.
2. See Figure 49. Press the Tune/Seek/Preset multiselect button until the desired function is displayed.
 - a. **Tune:** The PREVIOUS/NEXT hand control switch will advance to the next frequency increment. Holding the PREVIOUS/NEXT switch accelerates through frequencies.
 - b. **Seek:** The PREVIOUS/NEXT hand control switch will seek the next station. Holding the switch accelerates through the frequencies. The tuner then seeks the next available station upon releasing the switch.
 - c. **Preset:** The PREVIOUS/NEXT hand control switch will select the previous or next preset.




Figure 49. Tuner Menu

TUNING A STATION: HAND CONTROL SWITCH

When configured for tuning, use the PREVIOUS/NEXT hand control switch to advance to another frequency.

Short press: Advances to the next frequency increment.

Long press: Accelerates through the frequencies until the switch is released.

TUNING A STATION: VOICE RECOGNITION

1. Press the VOICE RECOGNITION switch.

2. Say **TUNE TO** along with the frequency into the microphone (such as **TUNE TO NINETY-SEVEN POINT ONE**). The radio automatically tunes to the appropriate band (such as AM or FM) according to the frequency selected.

SEEKING A STATION: HAND CONTROL SWITCH

When configured for seeking, use the PREVIOUS/NEXT hand control switch to find the next station.

Short press: Seeks the next station. The seek icon is displayed in the status bar.

Long press: Accelerates through the frequencies. The tuner then seeks the next available station upon releasing the switch.

SEEKING A STATION: VOICE RECOGNITION

1. Press the VOICE RECOGNITION switch.
2. Speak **SEEK UP** or **SEEK DOWN** into the microphone.

SCANNING STATIONS

1. With a tuner band displayed, select **Menu**.

2. Select **Scan**. The radio begins scanning through the frequencies. The radio remains on each station for five seconds before continuing the scan. The scan icon is shown in the status bar during this process. If the scan does not find any strong station within two complete passes through the band frequencies, the scan automatically cancels.
3. To select a station, press the CURSOR/SELECT switch on the right hand controls.

PRESETS

Presets can store preferred radio stations for easy access. The radio has 15 presets for FM band, and 6 presets for other bands. The radio can also be configured with global presets. See Global Presets (Page 49).

1. Tune to a station.
2. Press and hold one of the preset buttons until a beep sounds. The frequency is stored to the selected preset button.
3. To tune the preset in the future, select the preset button.

CATEGORIES (CAT)

The FM band can be configured to seek or scan for particular types of radio programming (such as news, sports or classical music). When categories are selected, the radio only seeks or scans for the stations that are broadcasting programs with

the selected category codes. Not all stations broadcast these codes. When categories are selected, the FM band displays CATEGORIES with a filter symbol as shown in Figure 50.

Categories are also known as program types (PTYs).



Figure 50. Categories Symbol

SELECTING CATEGORIES

Refer to Table 26 for categories available in North America.

Refer to Table 27 for categories available in other regions.

1. While in the FM band, select **Cat** to access a list of all available categories. For some radios, the Categories button is on the Stations screen.

2. See Figure 51. Select categories from the list.
 - a. **Individual categories selected:** Radio seeks or scans only stations from the selected categories. The FM screen shows the category filter icon.
 - b. **Clear All (or no categories selected):** Radio seeks or scans all stations.
 - c. **Set All:** Radio seeks or scans for stations that are broadcasting any of the program types. The radio does not stop on any station unless it is broadcasting a program type code. The FM screen shows the category filter icon.




Figure 51. Setting Categories

Table 26. FM Categories: RBDS, North America

OPTION	OPTION
• Set/Clear All	• Nostalgia
• News	• Jazz
• Information	• Classical
• Sports	• Rhythm & Blues
• Talk	• Soft Rhythm & Blues
• Rock	• Foreign Language
• Classic Rock	• Religious Music
• Adult Hits	• Religious Talk
• Soft Rock	• Personality
• Top 40	• Public
• Country	• College
• Oldies	• Weather
• Soft	

Table 27. FM Categories: RDS, Other Regions

OPTION	OPTION
• Set All	• Other Music
• News	• Weather
• Current Affairs	• Finance
• Information	• Children's Programs
• Sport	• Social Affairs
• Education	• Religion
• Drama	• Phone-in
• Culture	• Travel
• Science	• Leisure
• Varied	• Jazz Music
• Pop Music	• Country Music
• Rock Music	• National Music
• Easy Listening	• Oldies Music
• Light Classical	• Folk Music
• Serious Classical	• Documentary

STATION LIST

Radios equipped with the station list feature will have a Stat button in the upper left corner on the FM screen. The radio scans and creates a list of all available stations in the FM band. Radios with a dual tuner will continually update the list as stations come in and out of range.

Accessing station list: See Figure 52. For equipped radios, press the **Stat** button in the upper left corner of the FM band screen.

Selecting a station: See Figure 53. Use the scroll controls. Select the desired station from the list.



Figure 52. FM Tuner (Station List)



Figure 53. Station List

RBDS/RDS

Some radio stations broadcast data which can be used to display station identification, program information and support other features in the radio (depending on the region).

Radio Broadcast Data System (RBDS) is primarily used in North America. Stations broadcasting RBDS typically provide information such as radio station name, artist and song title to the radio.

Radio Data System (RDS) is primarily used in Europe. Stations broadcasting RDS data may also include time updates, weather, traffic and other regional information.

Not all radio stations transmit RBDS or RDS data. When RBDS or RDS is unchecked, or if the service is not available, only the radio frequency is displayed.

Enable RDS/RBDS: From FM tuner screen, select **Menu**. Check the **RDS** or **RBDS** checkbox.

RDS Features

For dual tuner radios with RDS capability, three separate RDS features can be enabled.

Alternate Frequency Switching (AF): The radio monitors the signal strength of other stations playing the same program. The radio automatically switches to another station if the signal quality is better.

Regionalization (REG): Some radio stations split their program into separate regional programs on different frequencies. Regionalization automatically uses frequencies of regional related stations for alternate frequency jumps.

Traffic Program/Traffic Announcement (TP/TA): The radio monitors stations for traffic announcements. When a traffic announcement is discovered, the radio automatically tunes to the station playing the announcement. The Traffic Announcement icon (TA) is displayed in the status bar. When finished, the tuner returns to its previous operation. The status bar displays the Traffic Program (TP) icon when tuned to a station that regularly plays traffic announcements. When

enabled, the radio also monitors stations for Enhanced Other Networks (EON) transmissions.

WEATHER BAND

Weather band is supported on radios for North America. Equipped radios can tune to any of the seven weather band frequencies. The six weather band presets are originally set to the first six weather band frequencies.

In the US, the National Oceanic and Atmospheric Administration (NOAA) operates National Weather Radio (NWR) stations across the country. These stations continually broadcast weather announcements using the seven different frequencies designated for weather band use as shown in Table 28.

In Canada, Weatherradio Canada broadcasts weather information on the same set of frequencies.

Listen to weather band: Select **Home > Tuner > WB**.

Tune to weather band frequency: Use the PREVIOUS/NEXT hand control switch to advance through the seven weather band frequencies.

Using weather band presets: Refer to Table 28. Select preset (1-6).

Changing weather band preset: Tune to a weather band frequency. Press and hold a preset to store the channel.

Table 28. Weather Band Channels

PRESET	CHANNEL	FREQUENCY
1	WB1	162.400 MHz
2	WB2	162.425 MHz
3	WB3	162.450 MHz
4	WB4	162.475 MHz
5	WB5	162.500 MHz
6	WB6	162.525 MHz
N/A	WB7	162.550 MHz

WEATHER ALERT

The weather band alert feature is only available on radios built for North America with a CB module.

When the weather alert feature is turned on, the CB module continuously scans the weather band for an alert tone from the weather band stations. The rider can continue to play media, listen to other stations or use other features on the radio. When an alert tone is detected, the radio changes to the weather band and tunes to the channel with the alert announcement. The alerts indicate extreme weather conditions such as tornados, storms, floods or other environmental warnings. See www.weather.gov/nwr for weather band and alert broadcast information.

Turn weather alert on: See Figure 54. On weather band screen, press button in upper left corner to display **On**.

Turn weather alert off: On weather band screen, press button in upper left corner to display **Off**.



Figure 54. Weather Band Screen

NOTES

MEDIA SCREEN

current playing song. On 6.5 radios, the media screen also displays the cover art for the song, if available.

See Figure 55. The Media screen shows the status of the




Figure 55. Media Screen

MEDIA DEVICES

The radio supports various types of USB and Bluetooth-connected media devices. As a general guideline, support for devices is listed in Table 29. Some features or

menus may not be available depending on device, file type or connection type.

For mass storage devices (such as USB drives), the file organization on the device can impact performance. For best performance and indexing of files, store media files at the root

directory of the USB device, rather than in multiple levels of folders.

Table 29. Media Device Support

DEVICE	DEVICES SUPPORTED	CONNECTIONS	FILES SUPPORTED	FEATURES OR LIMITATIONS
iPod	iPod supporting iAP	Apple proprietary connector.	All iPod supported file types	Supports all find features. Ring tone files cannot be downloaded. iPods with a hard drive can be damaged and are not recommended.
USB mass storage device	USB drive (FAT16, FAT32, NTFS, HFS+) or SD card	Direct connection to USB port. USB connector and reader required for SD card.	MP3, MP4, MPEG-4 AAC, M4A, M4B, WAV, WMA	May support find features. NTFS-formatted drives can only be used for read-only functions (such as playing media). NTFS drives will not support functions like trip/trail exports or navigation database updates.
Media player	USB-connected phone. PlaysForSure compatible device. Media Transfer Protocol (MTP) compatible device.	USB cable.	MP3, MP4, MPEG-4 AAC, M4A, M4B, WAV, WMA	May support find features.
Bluetooth device	Varies. Requires minimum Bluetooth profile interoperability.	A2DP/AVRCP profiles.	Bluetooth device dependent. Bluetooth audio is streamed by the device and not decoded by radio.	No find, browse, shuffle, track list, or preset capability. File metadata may not be displayed. Audio from an app or internal player can be streamed to radio.

CONNECTING MEDIA DEVICE: USB

1. With motorcycle stopped, connect the media device to the USB port. Use a connector or reader as needed.
2. If the media device is not automatically recognized, check the device settings. Some devices need to be configured to connect as a hard drive or as a media device before media files can be accessed. See the device manual.

NOTE

- *If connecting a device for the first time, the radio begins playing the first song found on the device. If reconnecting a previously used device, the radio attempts to resume the last played file.*
- *The radio will begin collecting file information from the device. Some information and features may not be available until the radio has finished synchronizing with the device. The radio will play remaining files in alphabetical order.*

CONNECTING MEDIA DEVICE: BLUETOOTH

1. With motorcycle stopped, pair the device. See Pairing a Bluetooth Device (Page 79).
2. Select **Home > Media**.
3. Select the device from the list.

DEVICE PLAYERS AND APPLICATIONS: BLUETOOTH

Streaming audio can be played from an internal player or application on a connected Bluetooth device. The radio can control some features, such as previous or next file selections within some players or applications.

1. With motorcycle stopped, connect with the Bluetooth device.
2. Start the media application or internal player within the Bluetooth-connected device. The audio begins playing through the motorcycle speakers or headsets.
3. Use the PREVIOUS/NEXT hand control switch and POWER/MUTE switch on the radio faceplate to operate the application or internal player, as applicable.

NOTE

The volume level and equalization within the device can affect the streaming volume to the radio. If sound cannot be heard or is distorted, check the volume within the application or device.

SELECTING MEDIA DEVICE

1. See Figure 56. Select **Home > Media**. A list of paired or connected devices is displayed. Items are marked with either a USB or Bluetooth symbol.

2. Select device from the list. If connected, the first song from the device begins playing.



Figure 56. Selecting Media Device

PLAY PREVIOUS/NEXT MEDIA FILE: PREVIOUS/NEXT PRESET

Depending on the configuration, the PREVIOUS/NEXT hand control switch will either advance through each song individually, or through each preset that is programmed for the device.

1. Select **Home** > **Media** > **Menu**.

2. Press the multiselect button to show **Seek** (to advance through each song) or **Preset** (to advance through each preset).
3. Press the PREVIOUS/NEXT hand control switch to advance to the previous or next song (or preset) in the device.

PAUSE, REWIND, OR FAST FORWARD MEDIA FILE

Pause: Press the POWER/MUTE switch to pause or unpause media.

Rewind: Press and hold PREVIOUS/NEXT switch to the left. Rewinding will accelerate as switch continues to be held.

Fast Forward: Press and hold PREVIOUS/NEXT switch to the right. Fast forwarding will accelerate as switch continues to be held.

SCANNING MEDIA FILES

1. Select **Home** > **Media** > **Menu**.
2. See Figure 57. Select **Scan**. The radio begins playing each song on the device sequentially, dwelling on each song for five seconds. The Scan icon is displayed on the screen.
3. Press the SELECT/ENTER hand control switch to continue playing the current song.




Figure 57. Media Menu

REPEAT CURRENT FILE

1. Select **Home > Media > Menu**.
2. Check the **Repeat** checkbox. The Repeat icon is displayed and the current file will play repeatedly until unselected.

PLAY RANDOM FILES: SHUFFLE

1. Select **Home > Media > Menu**.

2. Check the **Shuffle** checkbox. The Shuffle icon is displayed. The radio will randomly select files from the device.

NOTE

An iPod may exclude audio books and podcasts from shuffle selection.

PLAY SONGS FROM TRACK LIST

The track list shows a full list of all songs on the connected device. When selecting a song from the list, the radio remains in the track list and does not transition back to the media screen. Track lists are not available for Bluetooth streaming media devices.

1. Select **Home > Media > Menu**.
2. See Figure 58. Select **Track List**. A complete list of all songs from the currently selected device, playlist, artist or album are displayed.
3. Select a song from the list to play.
4. Select the information button ("i") to display information for the selected song or the entire track list (such as the album for the currently displayed tracks).



Figure 58. Media Track List

MEDIA PRESETS

The radio stores up to 20 presets for each connected device. The screen only shows media presets for the currently connected device. The media presets are retained in memory and are available the next time the media device is connected. Presets are only available for USB connected devices.

Set media preset: With song playing, press and hold one of the presets. The radio beeps and the preset is stored.

Select media preset: Press desired preset. Song will begin playing.

Seeking presets: In the media screen, select **Menu**. Select **Presets**. The PREVIOUS/NEXT hand control switch will advance through each of the presets, rather than through every song on the device.

FINDING A MEDIA FILE

See Figure 59. The Find feature can be used to browse for different types of media files on USB-connected media devices as shown in Table 30. File browsing features are not available for Bluetooth streaming media devices.




Figure 59. Finding a Media File

Table 30. Finding a Media File

CATEGORY	DESCRIPTION
Artist	Lists all songs by selected artist. Radio will play a selected song, then plays remaining songs by the artist.
Album	Lists all songs on selected album. Radio will play a selected song, then plays remaining songs on the album.
Genre	Lists songs by selected genre.

Table 30. Finding a Media File

CATEGORY	DESCRIPTION
Song Title	Searches for song by title.
Playlist	List of all playlists on device.
Podcast	List of all podcasts on device (Apple devices only).
Audio Book	List of all audio books on device (Apple devices only).
Video, TV Show, Movie or Music Video	List of video files on device (only audio portion is played).

FINDING A MEDIA FILE: PLAYLIST

A playlist is a file stored on the device which includes a sequential list of songs. All playlists native to the iPod are supported. The radio also supports the following playlist types for other USB-connected devices.

- Windows Media Player Advanced Stream Redirector format (*.asx)
- Windows Media Player Playlist (*.wpl)
- M3U Moving Pictures Expert Group Audio Layer 3 Uniform Resource Locator (*.m3u)
- PLS file (*.pls)
- iTunes XML (*.xml)

- RealPlayer Metadata Package (*.rmp)

NOTE

- *M3U, PLS and WPL playlists only allow relative pathnames to files. Absolute pathnames are not supported.*
- *All XML files on USB mass storage media will be displayed, even if the files are not actually XML-formatted playlists.*

1. Select **Home > Media > Find**.
2. Select **Playlist**.
3. Select item from list.
4. Select song from the playlist. To play the entire playlist, select the first song.

FINDING A MEDIA FILE: ARTIST, ALBUM OR GENRE

1. Select **Home > Media > Find**.
2. Select **Artist, Album or Genre** to browse.
3. Select item from list.
4. Select song from the list. The radio begins playing files for the artist, album or genre, starting at the selected file. To play all songs for this artist, album or genre, select the first song from the list.

FINDING A MEDIA FILE: SONG TITLE

1. Select **Home > Media > Find**.
2. See Figure 60. Select **Song**. A full list of all songs on the device is displayed.
3. Select a song from the list. If necessary, select the letter jump button between the scroll controls and type the first letter of the song name.



Figure 60. Finding a Media File: Song

FINDING A MEDIA FILE: PODCAST

The Podcast category is displayed in the Find menu when a properly configured podcast is identified on the device. An audio file (ID3 tag) must be coded properly to display on the radio as a podcast. If needed, right-click on the file in iTunes

and select the proper option for characterizing the file (movie, music, video, podcast, and so on).

Some files identified as podcasts are not actually podcast files, but just media files. These files may be listed with other song files.

1. Select **Home > Media > Find**.
2. Select **Podcast**.
3. Select a podcast from the list.
4. See Figure 61. Select an episode from the list.



Figure 61. Podcast

FINDING A MEDIA FILE: AUDIO BOOK

The audio book option is displayed when audio book files have been discovered on the device. Some audio books are MP3 files which may be listed with other song files.

1. Select **Home > Media > Find**.
2. Select **Audio Book**. A list of audio books is displayed.
3. Select an audio book from the list.
4. See Figure 62. Select a chapter from the audio book, if applicable.




Figure 62. Audio Book

FINDING A MEDIA FILE: VIDEO, TV SHOW, MOVIE, MUSIC VIDEO

The radio can play some types of video files. To minimize distraction, the radio only plays the audio portion of the files.

Files from Apple devices may be categorized as TV Show, Movie or Music Video. Supported video files from a USB device are categorized as Video.

1. Select **Home > Media > Find**.
2. Select **Video, TV Show, Movie or Music Video**.
3. Select a file from the list. Audio from the video file will begin playing.

SELECTING MEDIA FILE: USING VOICE RECOGNITION

See Voice Recognition (Page 179) for detailed instructions on all voice recognition commands.

1. Press the VOICE RECOGNITION hand control switch.
2. Say **ARTIST, ALBUM, GENRE, PLAYLIST** or **SONG** followed by the name or title to be played.
3. The radio may prompt for more information. Respond to any remaining prompts to select and play the media.

SAVING MEDIA FILE AS FAVORITE

See Favorites (Page 55).

SAVING MEDIA FILE AS RING TONE

Media from an iPod and files larger than 2 MB cannot be downloaded as a ring tone.

1. With media file playing, select **Menu**. If the current file type is compatible for use as a ring tone, a Ring Tone button is displayed.
2. Select **Ring Tone**. The radio will attempt to download the media file for use as a ring tone. The radio allows only one ring tone to be downloaded into the radio. Replace the existing file if necessary.
3. Select **OK**.

AUDIO SYSTEM CARE

Use only Harley-Davidson recommended products and methods to keep the radio, speakers and other audio system components clean and in good condition. Do not use any abrasives, polishes or rubbing compounds to clean the screen or other components. Do not use any ammonia-based cleaners on the screen. Use of other products or methods may cause damage to components.

Replaceable Screen Protector

Boom! Box 6.5GT radios have a replaceable screen protector. Keep the protector on the screen at all times. Damage to the screen due to use without the protector will not be covered under warranty. Remove and replace the protector if it becomes dull, scratched or worn.

Cleaning the Radio

Spray a light amount of HARLEY GLOSS on a MICROFIBER DETAILING CLOTH. Be careful to gently remove any sediments without rubbing them into the screen. Apply circular motions from the center and outwards. Use a dry MICROFIBER DETAILING CLOTH to dry the screen. Repeat the process as necessary.

NOTE

Do not use any screen enhancing chemicals or products. These can damage the screen surface.

Speaker Care

If a haze develops on speakers with a protective grille, use HARLEY SEAT, SADDLEBAG, AND TRIM CLEANER and a SOFTCLOTH or SOFT DETAILING PAD to clean. Do not apply wax or any other similar products on speaker grilles.

Do not use compressed or forced air on speakers.

Vehicles with saddlebag speakers are designed to prevent water intrusion and to allow water to drain during washing or riding in all weather. To remove any standing water from saddlebag speakers, open the saddlebags and gently shake any remaining water from the speakers.

NOTES

ENABLING BLUETOOTH

Bluetooth must be enabled before pairing or connecting with Bluetooth devices.

1. Select **Home > Setup > Bluetooth Setup**.
2. See Figure 63. Check the **Bluetooth** checkbox to enable.



Figure 63. Bluetooth Setup Menu

PAIRING A BLUETOOTH DEVICE

A maximum of six devices can be paired with the radio at one time. However, the radio only maintains an active Bluetooth connection with up to one device for phone service and one device for media at a time.

The motorcycle identifies itself as "H-D Radio". The name for the Bluetooth device is specified within the settings for your device.

NOTE

Phones may request permission to share information with "H-D Radio" (such as phone book contacts and text messages). These requests may occur during the pairing process or on other occasions when the phone is connecting with the radio.

1. In the Bluetooth-compatible device, enable Bluetooth and set the device as discoverable. See the manual for your device.
2. In the radio, select **Home > Setup > Bluetooth Setup**.
3. See Figure 64. Select **List Paired Devices > Add a New Device**. All discoverable devices within range appear in the list of found devices.
4. Select the device to be paired from the list.
5. The device displays a PIN code and prompt for permission to pair with "H-D Radio". Allow the pairing within the device.
6. See Figure 65. In the radio, select **Yes**. The radio attempts to pair and connect with the device.
7. The system prompts for an emergency phone number if one is not already stored in the system. Enter a phone number to call in the event of an emergency (such as 911 in the US).
8. Select **Save** in lower right corner of the screen.

9. The system begins downloading the phone book from the device. The Phone Book icon is displayed in the status bar during the download process. During this process, the phone may prompt for permission to share the phone book.



Figure 64. Adding a New Device



Figure 65. Pairing a Device: iPhone Example Shown

CONNECTING/DISCONNECTING A BLUETOOTH DEVICE

A Bluetooth device can be connected for phone service, media, or both. The system only allows one device to be connected for each Bluetooth service (phone or music).

The radio will automatically try to connect with the phone or media device after pairing. For some devices, a setting is required within the device before it will automatically connect. See the manual for the device.

To manually connect or disconnect with a Bluetooth device after pairing, use the following procedure. Also see Connecting Media Device: Bluetooth (Page 69).

1. In the radio, select **Home > Setup > Bluetooth Setup**.
2. Select **List Paired Devices**. A device with a highlighted phone icon is connected for phone service. A device with a highlighted media icon is connected for media.
3. Select a device from the list to connect or disconnect.
4. See Figure 66. Select the appropriate button to connect or disconnect the device for phone service.
5. Select the appropriate button to connect or disconnect the device for music.



Figure 66. Connecting or Disconnecting Phone or Music

RECONNECTING AFTER VEHICLE TURNS ON

When the motorcycle is turned on, the radio will automatically try to establish a Bluetooth connection with the phone from the last vehicle shutdown.

Allow a few moments for the radio to initialize and the phone connection to complete. The status bar displays the Bluetooth icon when the phone is connected.

The radio will not automatically reconnect with media devices over Bluetooth. Manually reconnect the phone and other media devices as necessary.

DELETING A PAIRED DEVICE

A device will typically remain paired with the radio until deleted.

1. In the radio, select **Home > Setup > Bluetooth Setup**.
2. Select **List Paired Devices**.
3. Select the device from the list.
4. See Figure 67. Select **Delete Pairing**. Select **OK** to confirm.



Figure 67. Deleting a Paired Device

NOTES

PHONE COMPATIBILITY

Some phones may not be compatible with all the features and services in the radio. See the phone compatibility information at www.h-d.com/boom (or the Boom! Box section of www.h-d.com/touring). Some features may vary by region or carrier.

At a minimum, the phone must support the Bluetooth profiles shown in Table 31 to be compatible with various features in the radio. Even with these basic requirements, the phone may not necessarily be compatible with all features.

Table 31. Required Bluetooth Profiles

PROFILE	DESCRIPTION
A2DP/AVRCP Profile (AV/Music)	Connect media, media controls, metadata
Hands-Free Calling Profile (HFP)	Pairing, connecting, call features, battery indicator, signal strength indicator
HFP+PBAP+AV Profile	Calls and connection

Table 31. Required Bluetooth Profiles

PROFILE	DESCRIPTION
Message Access Profile (MAP)	SMS text message features
Phonebook Access Profile (PBAP)	Phonebook download, call history download

BLUETOOTH AND USB CONNECTIONS FOR PHONES

Phone services are only achieved through a Bluetooth connection. Connecting a phone to the USB port will allow the phone to charge and may provide additional media features. However, a USB connection alone will not operate the phone features.

The phone must be paired and connected through Bluetooth before operation. See Bluetooth (Page 79).

PHONE MENU

See Figure 68. Select **Home > Com > Phone** to access the phone features.



1. Phone book contacts
2. Dial phone number
3. Call history

4. Text messages
5. Emergency phone number
6. Bluetooth settings


Figure 68. Phone Menu

CALL SCREEN

When a call is initiated or accepted, the Call screen is displayed as shown in Figure 69. This screen shows information for the current call.

While in an active phone call, you can change to other screens and use other features (such as navigation). However, other audio sources remain muted, paused or inaccessible until the phone call is finished.

Return to the Call screen to end the call or use other phone features. To return to the Call screen at any time during a call, press the HOME switch twice.



- | | |
|---|----------------------------------|
| 1. End call | 8. Roaming icon |
| 2. Menu (microphone mute/unmute, keypad, call history, contacts, emergency call) | 9. Phone battery (5 bars) |
| 3. Contact name (if available) | 10. Bluetooth connected |
| 4. Phone number | 11. New message icon |
| 5. Contact type (home, mobile or work) | 12. Phone signal strength |
| 6. Elapsed time in call | 13. Microphone muted |
| 7. Phone carrier | |

Figure 69. Call Screen

Table 32. Call Screen Functions

ITEM	DESCRIPTION
End	Press to end the current call.
Menu	Press to display other phone features (keypad for touch tones, mute/unmute, and so on).
Mute	Displays when microphones are muted.
Phone battery icon	Battery power for the phone (ranging 0 to 5).
Phone Book	Indicates when the phone book is being downloaded from the phone.
Phone signal strength icon	Signal strength (ranging 0 to 3).
New Message	Indicates a new text message has been received.
Roaming	Indicates that the phone is current in roaming mode.

IPHONE: USING SIRI

See Figure 70 and Figure 71. After pairing the iPhone, the touchscreen will display two instructions confirming operation of the voice command button.




Figure 70. Activate SIRI




Figure 71. Disconnect SIRI

1. See Figure 72. Press and hold voice command button to activate Siri.

2. **Siri** will display on the touchscreen followed by **How may I help you?** Speak your command.
3. Press and hold voice command button to disconnect Siri.




Figure 72. Voice Command Button

MAKING A CALL: DIALING

1. Select **Home** > **Com** > **Phone**.
2. Select **Keypad**.

3. See Figure 73. Type the full phone number using the keypad. Use the backspace/delete button or other characters as needed.
4. To add the phone number to the Saved list, select the **Save** button.
5. Select **Dial** in upper left corner.




Figure 73. Phone Keypad

MAKING A CALL: PHONE BOOK CONTACT

1. Select **Home** > **Com** > **Phone**.
2. Select **Contacts** > **Phone Book**.

3. Select the contact name from the list. The letter jump feature can be used by pressing the center button in the scroll controls.
4. Select the desired phone number.

MAKING A CALL: NAVIGATION POI

Some points of interest in the navigation database include contact information.

1. Select **Home** > **Nav** > **POI**.
2. Select a POI destination.
3. Select the option menu button.
4. Select **Call**.

MAKING A CALL: SIRIUSXM GAS STATION

Some gas stations in the SiriusXM Fuel Prices feature include contact information.

1. Select **Home** > **SiriusXM** > **Specialty Services**.
2. Select **Fuel Prices**.
3. Select a gas station from the list.
4. Select **Call**.

MAKING A CALL: EMERGENCY PHONE NUMBER

An emergency phone number must be entered into the radio before using this feature. This is done when the phone is paired. See Changing the Emergency Phone Number (Page 99).

1. Select **Home** > **Com** > **Phone**.
2. Select **SOS**.
3. Select **Dial**.

MAKING A CALL: DIALING WITH VOICE RECOGNITION

See Voice Recognition (Page 179) for more voice recognition instructions.

1. Press the VOICE RECOGNITION switch.
2. Say **DIAL** and speak the phone number into the microphone.

MAKING A CALL: CALLING A CONTACT WITH VOICE RECOGNITION

1. Press the VOICE RECOGNITION switch.
2. Say **CALL** and speak the contact name from the phone book or saved list.

3. If a contact has more than one phone number (home, mobile or work), the system will prompt for the correct phone number to use. Select the phone number to dial.

RECEIVING A CALL: ACCEPTING/IGNORING

When a call is received, the radio plays the ring tone and displays the incoming call information as shown in Figure 74. The call can either be accepted or ignored. Other audio sources are muted until the phone call ends.

Accepting the call: Select **Accept**. The call screen is displayed and the call begins.

Declining the call: Select **Ignore**. The phone declines the call and sends it to voicemail (or other function as determined by the phone manufacturer or carrier). The previous audio source resumes. See Call History (Page 94) to display a list of missed calls.



Figure 74. Incoming Call

RECEIVING A CALL: RADIO TURNED OFF

Phone calls can be received while the radio is turned off. When a call is received, the radio displays the call information and plays the ring tone. If the call is accepted, the phone features operate normally. The radio turns off when the call ends.

ENDING A CALL

Selecting the End button: The call terminates. The caller can then be added to the saved list by selecting the Save button.

Making a new call: Initiating a new call will terminate the current call.

Accepting a new call: Accepting a new call will terminate the current call.

ADJUSTING CALL VOLUME

During a call, use the volume hand control switch to adjust the incoming call audio. The passenger can use the volume controls on the Tour-Pak to adjust volume in the passenger headset.

MUTING CALL AUDIO

Muting microphones: While in a call, select the **Menu** button. Select the **Mute/Unmute** button until **Mute** is displayed. The call screen displays a Mute icon in the lower right corner. Audio from the rider and passenger microphones will not be sent over the phone.

Unmuting microphones: Press the **Mute/Unmute** button until **Unmute** is displayed. The Mute icon is removed and the microphones resume normally.

Muting inbound audio: Use the volume hand control switch to adjust incoming audio to minimum volume. The POWER/MUTE button does not mute incoming phone audio.

ROUTING CALL AUDIO

Outbound call audio is always spoken into the rider and passenger microphones. However, the inbound call audio

can be received through either the speakers or headsets. See Speaker/Headset Selection (Page 45).

MULTIPLE CALLS

The radio only allows one active phone call at a time. When choosing to initiate or accept a new call, the other existing phone call is dropped.

New incoming call (while call is in progress): The system will prompt to either accept or ignore the new incoming call. If the new call is accepted, the existing call is dropped. If the new call is ignored, the current call continues.

Starting a new call (while call is in progress): Using the keypad, contacts list or emergency phone number, initiate the new call. When prompted, decide whether to continue with the existing call, or to start the new call (terminating the current call).

VOICE MAIL

The radio does not indicate voicemail status. For most phone carriers, voice mail can be accessed by dialing the phone number for the mobile phone that you are using.

If a dial tone passcode is required to access voice mail, press the VOICE RECOGNITION switch during the call. Speak the passcode numbers and other special characters as needed. For example, to enter a passcode as "1234#", speak **ONE-TWO-THREE-FOUR-POUND** into the microphone.

PHONE BOOK

Contacts in a device's phone book can be used to initiate calls, display incoming caller information and navigate to a contact address. While multiple phone books can be stored in the radio from different paired phones, only the phone book from the currently connected phone is made available for use.

See Figure 75. The phone book displays entries for home, mobile, work or other phone numbers, according to the entries in the connected phone. If a contact does not have a phone number stored, the contact will not be displayed in the list.

When a paired phone is removed, the phone book is deleted. Pairing the phone again will require the phone book to be downloaded.



Figure 75. Phone Book

SETTING UP CONTACTS IN A PHONE

Consider setting up contacts such as "Emergency", "Work", "Voicemail", "HOG" and "Dealer" in the phone. Use simple names so it will be easy to pronounce with the voice recognition commands. Include as much information as possible, such as alternate phone numbers and address information. With these items properly set up in the phone book, it becomes much easier to use voice recognition to say "Call Work" or to use phone book entries to route to a destination.

REFRESH PHONE BOOK

The radio first downloads the phone book during initial pairing, and typically synchronizes with the connected phone when the vehicle is turned on. The phone book can be manually refreshed from the connected phone at any time.

1. Select **Home > Com > Phone**.
2. Select **Contacts > Refresh Phone Book**. The system begins downloading the current phone book from the device.
3. During the download process, the phone may prompt for permission to share the phone book. Allow the phone book to be downloaded.

SHOWING CONTACT DETAILS

1. Select **Home > Com > Phone**.
2. Select **Contacts > Phone Book**.
3. Select a contact from the list.
4. Select **Show Details**. The name, phone numbers and address for the contact are displayed as shown in Figure 76. Selecting the address will begin navigation to that destination.




Figure 76. Contact Details

VIEWING SAVED CONTACTS AND PHONE NUMBERS

The radio can locally store up to 200 contacts or phone numbers. After a phone number is saved, it can be used with any phone that is connected with the radio. Saved contacts which include addresses can also be used for navigation routing, even when the phone is not connected.

1. Select **Home > Com > Phone**.
2. Select **Contacts > Saved**.
3. Select a saved contact or phone number from the list.
4. Select the phone number to begin a call, or select the address to route navigation to the address.

SAVING A PHONE BOOK CONTACT

1. Select **Home > Com > Phone**.
2. Select **Contacts > Phone Book**.
3. Select a contact from the list.
4. Select **Add to Saved Contacts**.

SAVING A DIALED PHONE NUMBER

A phone number can be saved while dialing the number.

1. Select **Home > Com > Phone**.
2. Select **Keypad**.
3. Enter a phone number.
4. Select the **Save** button.

SAVING PHONE NUMBER FROM CURRENT CALL

When a call is finished, the Save button is briefly displayed. Select the **Save** button to store the phone number to the saved list.

DELETE SAVED CONTACT

1. Select **Home > Com > Phone**.
2. Select **Contacts > Saved**.

3. Select a contact from the list.
4. Select the edit button (pencil).
5. Select the trash can button. Select **Yes** to confirm.

CALL HISTORY

1. Select **Home > Com > Phone**.
2. Select **Calls**. A list of all call activity for the current phone is displayed as shown in Figure 77. The radio can display up to 60 total calls (20 missed, 20 received and 20 dialed calls).
3. To display only the missed, received or dialed calls, repeatedly select the button in the right corner.




Figure 77. Call History

TEXT MESSAGING

The radio can be used to read and listen to incoming text messages (using the text-to-speech feature). An auto-reply feature can also be configured. For safety purposes, the radio cannot be used to send text messages. Not all phones are compatible for text messaging features.

ENABLING TEXT MESSAGE SERVICE: SMS

1. Select **Home > Com > Phone > Message** to access text messaging features.
2. See Figure 78. Check the **Enable SMS** checkbox.



Figure 78. Text Message Menu

ENABLING TEXT MESSAGE NOTIFICATION: APPLE DEVICES

Notification settings need to be configured in Apple devices before the radio can receive text messages.

1. In the phone, select **Settings > Bluetooth**.
2. Select **H-D Radio**.
3. See Figure 79. Enable **Show Notifications**.
4. Select **Settings > Notifications > Messages**.
5. Select **Banners**.

6. Turn off the vehicle. Allow up to 30 seconds for the radio to completely shut down.
7. Turn on the vehicle. The system should now be able to receive text messages from the phone.

NOTE

If the alert style is set to Alerts, only the first text message received from another number will be shown on the radio.




Figure 79. Enabling Text Message Notification: Apple Device Settings

TEXT MESSAGE AUTO-REPLY

1. Select **Home > Com > Phone > Message**.
2. Select **SMS Setup**.
3. Check the **Enable Auto-Reply** checkbox.
4. Select **View Reply Message** to view the current reply. Select **OK**.
5. See Figure 80. Select **Edit Reply Message**.
6. Enter new message. Select **OK**. The auto-reply feature will respond to incoming messages with a heading "Auto Generated Text" along with the contents of the personal message setting.




Figure 80. Auto-Reply Message

VIEWING/PLAYING A TEXT MESSAGE

When a new message is received, the New Message icon is displayed in the status bar. This icon clears after the text message inbox has been viewed.

Text message viewing is locked out while the motorcycle is in motion. Instead, the text-to-speech feature will read the selected text message through the speakers or headsets.

NOTE

On the 4.3 radio, the text-to-speech feature is only available while the radio is set to American English.

1. Select **Home > Com > Phone > Message**. The Inbox button shows the number of unread text messages.
2. Select **Inbox**. A list of messages displays the sender and the first portion of each text message.
3. See Figure 81. Select a message from the list. The full message is displayed. The text-to-speech feature reads the message over the speakers or headset.
4. To listen to the message again, select the **Repeat** button.
5. To display information about the text (sender, date and time stamp), select the information ("i") button.



Figure 81. Viewing a Text Message

SELECTING RING TONE

The radio has four built-in ring tones available (Rain, Suspense, Rave and Xylo). An additional ring tone can also be loaded into the radio.

1. Select **Home** > **Setup** > **Bluetooth Setup**. (Bluetooth Setup can also be selected in the phone menu.)
2. Select **Ring Tones** > **Select Ring Tone**.
3. See Figure 82. Select from the list of ring tones.

4. Select **OK**. A sample of the ring tone is played. The system will use the selected ring tone for all incoming calls.



Figure 82. Selecting Ring Tone

ADDING NEW RING TONE: MEDIA FILE CURRENTLY PLAYING

1. With media file playing, select **Menu** button in upper right corner of the media player.
2. Select **Ring Tones**. The radio stores the current file as a ring tone. The radio will prompt if the file is too large or when replacing an existing ring tone.
3. Select **OK**. The ring tone is stored in the radio and configured as the current ring tone.

ADDING NEW RING TONE: BLUETOOTH SETUP

1. With motorcycle stopped, connect device (with ring tone file) to USB port.
2. Select **Home > Setup > Bluetooth Setup**. (Bluetooth Setup can also be selected in the phone menu.)
3. Select **Ring Tones > Load Ring Tones**.
4. Select device.
5. Find and select the file. The radio will prompt if the file is too large or when replacing an existing ring tone.
6. Select **OK**. The file is stored in the radio and configured as the current ring tone.

RESUMING CALLS AFTER VEHICLE SHUTDOWN

If a call is active while the motorcycle is being turned off, the radio will request to transfer the call back to the phone as shown in Figure 83.

Selecting Yes: The call transfers back to the phone. The Bluetooth connection terminates and the radio shuts down.

Selecting No (or not acknowledging the prompt): The radio continues to support the call for approximately five

minutes. At the end of this period, the radio attempts to transfer the call back to the phone and the radio shuts down.

NOTE

Phone audio can only continue through the headset during this shutdown period. If the phone audio is routed through the speakers, the call will continue but the incoming audio will not be heard.



Figure 83. Transfer Call to Phone After Shutdown

TRANSFERRING A CALL BACK TO THE PHONE

Only use the phone handset manually while the motorcycle is stopped.

1. In the radio, select **Home > Setup > Bluetooth Setup**.
2. Select **List Paired Devices**.

3. Select the phone from the list.
4. Select **Disconnect Phone**. The Bluetooth phone connection terminates and the phone call transfers back to the phone handset.

CHANGING THE EMERGENCY PHONE NUMBER

When the first phone is paired, the radio prompts for an emergency phone number. One emergency phone number can be stored in the radio. This same phone number is used for any phone connected to the radio.

1. Select **Home > Com > Phone**.
2. Select **SOS**.
3. See Figure 84. Select **Edit #** (to change the phone number) or **Clear** (to delete the current phone number).
4. Enter the new phone number to contact during an emergency (such as 911).
5. Select the **Save** button.



Figure 84. Dialing or Editing Emergency Number

NOTES

WIRELESS HEADSET

Please read the Sena User's Guide for additional information pertaining to the wireless headset. Also check Harley-Davidson.com > **Owners** > **Infotainment** for the latest version of User's Guide and related information to Boom! Audio Bluetooth products.

Getting Started

Charge the wireless headset by connecting the supplied USB power & data cable into a computer USB port or USB wall charger. You can use any standard micro-USB cable to charge. The LED turns red while the headset is charging and turns blue when it is fully charged. It takes about 2.5 hours to be completely charged.

Powering On and Off

Press the Jog Dial and the Phone Button at the same time to power the headset either on or off. When powering on the headset, press the Jog Dial and the Phone button at the same time until the blue LED appears while hearing the ascending beeps. When powering off the headset, press the Jog Dial and the Phone Button at the same time until the red LED appears briefly and the headset turns off completely while hearing descending beeps.




Figure 85. Boom Wireless Headset

Wireless Headset Setup

Before using the wireless headset with any Bluetooth devices for the first time, you will need to pair them together. For example, it can be paired with Bluetooth mobile phones, Bluetooth stereo devices such as MP3 players, or motorcycle specific Bluetooth GPS navigation, and with other Boom!

Audio Bluetooth headsets. This pairing operation is only required once for any Bluetooth device. The headset remains paired with the devices and automatically reconnects to them when they are within range. You will hear a high tone single beep and a voice prompt when the headset connects to the paired device automatically:

When a headset is paired to the motorcycle, it will say **Your Headset is Paired, Boom Audio Connected**. After this initial pairing, every time the headset connects to the motorcycle you will hear **Boom Audio Connected**.

When a headset is paired to a phone, it will confirm the pairing by saying **Your Headset is Paired**.. After this initial pairing, every time the headset reconnects to the phone it will say **Phone Connected**.

1. Turn on wireless headset.
2. From the Home screen, select Setup on the touchscreen.

3. See Figure 86. Use the scroll control and scroll to Wireless Headset.



Figure 86. Scroll to Wireless Headset

4. See Figure 87. Select Wireless Headset.



Figure 87. Select Wireless Headset

NOTE

Place headset in pairing mode before selecting **Pair Rider Headset**. Press phone button for 5 seconds until red and blue LED's alternately flash.

5. Put **Headset** into pairing mode.
 - a. Touchscreen will display **Pairing in Process with Headset**.

NOTE

Rider's headset should be paired first followed by the passenger.

6. See Figure 88. Select Pair Rider Headset.



Figure 88. Pair Rider Headset

NOTE

Harley Davidson headsets will show up as Boom Audio and the version of its software. See owner's manual of non-Harley Davidson headset products for display options.

7. See Figure 89. Confirm wireless headset display information on the touchscreen. Select the model of wireless headset to pair.



Figure 89. Place Headset Into Pairing Mode

8. See Figure 90. Touchscreen will display confirmation status that the wireless headset has been Connected.



Figure 90. Paired Headset

9. Perform the same procedure for pairing the wireless headset for a passenger.

Headset to Headset Intercom Pairing

NOTE

When in pairing mode, do one device at a time in the area of the motorcycle and headset.

Please read the Sena User's Guide for information pertaining to the wireless headset to headset intercom set up and usage.

Headset Configurations

NOTE

The wireless headset must be turned on and paired with the system for the following configurations to appear on the touchscreen.

The headset configurations only affect headset performance when it is paired to a phone or other headset. They do not directly impact the performance of the headset when it is paired to the vehicle. The Sidetone setting is the only configuration option that will directly impact the headset when it is paired to a vehicle.

The 12 configuration modes can be accessed through the Boom! Box Infotainment system.

Select **Home > Setup > Wireless Headset > Manage Rider or Passenger Headset > Config** to manage headset configurations.



Figure 91. Headset Configuration

Smart Vol. Control: Smart Volume Control automatically changes the level of the speaker volume based on the level of the environmental noise. When it is disabled, volume is controlled manually. You can enable it by setting the sensitivity to low, medium, or high. Smart Volume Control responds to smaller environmental noises as the sensitivity level becomes higher. This factory setting is disabled.

SideTone: Sidetone is the sound of your own voice as picked up by your headset's microphone and reproduced in your own ear, by your own speaker. It helps you to naturally speak at the correct level according to varying helmet noise conditions. If this feature is enabled, you can hear what you are speaking during an intercom conversation or a phone call. This factory setting is disabled.

Voice Prompt: You can disable voice prompts, but the following voice prompts are always on:

- Voice prompts for configuration setting menu
- Voice prompts for battery level Indicator
- Voice prompts for factory reset
- Voice prompts for speed dial
- Voice prompts for FM radio functions



Figure 92. Headset Configuration

Adv. Noise Control: When Advanced Noise Control is enabled, the background noise is reduced during an intercom conversation. When it is disabled, the background noise is mixed with your voice during intercom. This factory setting is enabled.

Motion Sensitivity: Motion Sensor Sensitivity determines the sensitivity when you double tap on the surface of the Boom! Audio 20S EVO to enter voice command mode. The factory setting is low, but you may change it to high, or disable the feature.

VOX Phone: If this feature is enabled, you can answer incoming calls by simply saying a word loudly enough, unless you are connected to intercom. For example, when you hear a series of beeps for an incoming call, you can answer the phone by saying **Hello** or any other word loudly. However, the VOX Phone feature does not work if you are connected to the intercom. This feature is enabled from the factory but can be disabled through the configuration menu, Device Manager, or the Sena Smartphone App. If this mode is disabled, you have to tap the Jog Dial or the Phone Button to answer an incoming call.



Figure 93. Headset Configuration

HD Intercom: HD Intercom enhances the two-way intercom audio from normal quality to HD quality. HD Intercom will become temporarily disabled when you enter into a multi-way intercom. If this feature is disabled, the two-way intercom audio will change to normal quality. This factory setting is enabled.

Audio Multitasking: Audio Multitasking allows you to have an intercom conversation while simultaneously listening to music, FM radio, or GPS instructions. The overlaid audio is played in the background with reduced volume whenever there is an intercom conversation and will return to normal volume once the conversation is finished. If this feature is disabled, any incoming or outgoing intercom will interrupt your audio channel. This factory setting is enabled.

INT-Audio Sensitivity: When the Audio Multitasking setting is enabled, if you talk over the intercom while music is playing, then the music volume will be lowered to play in the background. You can adjust the intercom sensitivity to activate this background music mode. Level 1 has the lowest sensitivity and level 10 has the highest sensitivity. The factory setting is 6.



Figure 94. Headset Configuration

Nav. App Support: When Audio Multitasking is enabled, your smartphone's GPS application reduces in volume whenever there is an ongoing intercom conversation. To listen to your smartphone's GPS navigation clearly without this volume reduction, enable Navigation App Support. This factory setting is disabled.

Eight-way Intercom: Disabling the Eight-way Intercom optimizes the intercom performance for a small group up to four participants. Enabling the Eight-way Intercom optimizes the intercom performance for a larger group up to eight participants. This factory setting is disabled.

FM Station Guide: When FM Station Guide is enabled, FM station frequencies are given by voice prompts as you select preset stations. When FM Station Guide is disabled, the voice

prompts on FM station frequencies will not be given as you select preset stations. This factory setting is enabled.

Headset Software Version

NOTE

The Boom! Audio 20S EVO supports firmware upgrade function. Visit www.harley-davidson.com to check for the latest software downloads.

The information given in this topic is only informational. The exact Model/Software Version and Address will vary upon the product that is paired to the vehicle.

See Figure 95. When the wireless headset is properly paired it will confirm:

- Model/Software Version:
- Bluetooth Address:
- Status: Connected




Figure 95. Paired Headset

Unpair Wireless Headset

1. Select **Home > Setup > Wireless Headset**
2. Select Manage **Rider** or **Passenger** headset.
3. See Figure 96. Press **Forget** to unpair rider or passenger wireless headset from the Boom system.




Figure 96. Delete Paired Headset

Reset Factory Headset Settings

NOTE

When performing this procedure, the link between the Boom Infotainment system and headset will be broken. The wireless headsets must be paired again for system communications to operate properly.

1. To restore the Boom! Audio 20S EVO to factory default settings, press and hold the Phone Button for 12 seconds until the LED shows solid red and you hear double beeps. You will hear a voice prompt saying **Factory reset**.

2. Within 5 seconds, press the Jog Dial to confirm reset. The headset will be restored to factory settings and switched off automatically. You will hear a voice prompt saying **Headset reset, good-bye.**
3. If you press the Phone Button or don't press the Jog Dial within 5 seconds, the reset attempt is canceled and the headset returns to stand-by mode. You will hear a voice prompt saying **Canceled.**
4. Unpair current wireless headset(s) in Boom system. See Unpair Wireless Headset in this section.
5. Perform pairing procedure. See Wireless Headset Setup in this section.

Fault Reset

When the Boom! Audio 20S EVO is not working properly or is in faulty status for any reason, you may reset by pushing the pin-hole reset button at the back of the headset main unit. Insert a paper clip into the reset pin-hole and press the reset button for a second with light pressure. The Boom! Audio 20S EVO will be switched off, and you have to turn the system back on and try again. However, this will not restore the headset to factory default settings.




Figure 97. Fault Reset

VOLUME SETUP

Volume Adjustment

NOTE

Use of the product at a high volume for a long period of time may damage your eardrums or hearing ability. Keep the volume at a modest level to prevent damage.

The operator can easily adjust the volume by rotating the Jog Dial. You will hear a beep when the volume reaches maximum or minimum level. The volume is set and maintained independently at different levels for each audio stream even when you turn off and on the headset. So you can always maintain the preferred optimum volume level for each audio source.

Volume Setup

See Figure 98. Select **Home > Setup > Speaker Volume** to make adjustments for the following volume streams:

- Tuner/Media
- Prompt
- Phone
- CB
- Beep



Figure 98. Speaker Volume

Rider and Passenger Headset (HS) Volume

See Figure 99 and Figure 100. Select **Home > Setup > Rider or Passenger Headset Volume** to make adjustments for the following volume streams:

- Tuner/Media
- Prompt
- Phone
- Intercom
- CB

Press **More** to display the next screen of volume adjustments.




Figure 99. Headset Volume Page 1




Figure 100. Headset Volume Page 2

Wireless Headset Checkbox

NOTE

Wireless headset must be turned on and paired with the system for the checkbox to appear.

This will only happen for Harley-Davidson headsets. Aftermarket headsets will not have this option.


See Figure 101. Press the checkbox to enable the **Volume Controls Wireless Headset**.



Figure 101. Checkbox for Wireless Headset Volume

See Figure 102. This feature will use the vehicle's master left hand audio control to adjust the volume in the riders wireless headset. **Also, it will no longer adjust the volume streams to the headset, however the volume streams can still be manually adjusted in the Volume Setup menu.**

NOTE



1. Volume control

Figure 102. Left Hand Audio Control

Once the system has synced, all volume options can be controlled from the vehicle.

See Figure 103. Select **Home > Setup > Speaker/Headset** to adjust. When the wireless headset is Bluetooth connected and the operator decides to switch from headset to speaker, the master control on the vehicle will be inoperative until the wireless headset has been disabled or turned off.



Figure 103. Speaker/Headset Selection

CB RADIO

▲ WARNING

Set CB channel, squelch threshold and volume before riding to minimize adjustments on the road. Distractions can lead to loss of control, resulting in death or serious injury. (00089a)

NOTICE

Operating the CB radio without an antenna or with a broken antenna cable can result in damage to the transmitter circuitry. (00176a)

NOTICE

There are no adjustments internal to the CB transceiver chassis that can be performed without risking non-compliance with Federal Communications Commission (FCC) rules. Refer to the original equipment manufacturer for any service required during the warranty period. For transmitter service after the warranty period, refer to a certified repair service. Any frequency determining components, such as crystals, or power determining semi-conductors, etc., should only be replaced with the original component manufacturer's part or equivalent. Substitutes can result in violation of FCC rules. (00175a)

Some models in select regions have a CB module. The CB radio can be used to communicate with other CB-equipped motorcycles (or other CB users) on any of the 40 Citizen Band channels.

Regulations for CB operation, specific frequencies or power output may be unique for different regions. Check local laws and regulations before operating the CB radio. In the United States, read **Part 95, FCC Rules and Regulations** before operating your transmitter.

TURNING CB ON

The CB must be turned on before using. After the CB is turned on and a channel has been selected, you can leave the CB screen and use other radio features (such as listening to tuner stations, making phone calls, using navigation features, or listening to media files). The CB remains muted but continues operating in the background. The rider and passenger can transmit or receive CB audio at any time while on any screen.

1. Select **Home > Com > CB**.
2. See Figure 104. Press the button in the upper left corner of the CB screen until it displays **On**. The middle of the screen shows the current channel and CB On. The CB icon is displayed in the status bar while the CB remains on.




Figure 104. CB Screen

TURNING CB OFF

See Figure 104. On the CB screen, press the button in the upper left corner until it displays **Off**. The CB presets will be disabled, the middle of the screen will show CB Off and the CB icon in the status bar will turn off.

CONFLICTING TRANSMISSIONS

CB channels are mutually shared among many users. Interruptions and conflicting transmissions from multiple users

on a channel can make it difficult for your intended recipient to understand your message. To make sure that your transmission is received well, and as a courtesy to others, wait until the channel is clear before pressing the PTT switch.

If too many users are actively using a channel, try to specify another possible channel to your intended recipients so you can resume your conversation together on that channel.

For important communications, make sure that your recipient acknowledges that they have received and understand your message.

EMERGENCY OPERATION: CHANNEL 9

In the US, the FCC has reserved channel 9 for emergency or traveler assistance use only. Use of this channel should only be for issues involving personal safety, damage to property or other required assistance. Channel 9 is also reserved for emergency use in most other countries that allow Citizen Band radio.

When using this channel for emergencies or assistance, clearly identify the nature of the problem and your location. If no response is received, try other channels or find another way to get help.

TRANSMITTING ON CB

Start transmitting: While on any screen, wait until other active CB transmissions are finished and the channel is clear.

Press and hold the PTT switch to begin transmitting on the current CB channel. Any sound picked up from the rider and passenger microphones will be transmitted. While the PTT switch is held, all other audio is muted, including any inbound CB messages that may be coming in. The CB Active icon will be displayed in the status bar during the transmission.

Stop transmitting: Release the PTT switch to stop transmitting. The status bar will show the CB Idle icon. Audio will be resumed, and any CB audio that breaks squelch will be received.



Figure 105. CB Active

RECEIVING CB AUDIO

The radio will receive inbound CB audio while on any screen. When an incoming CB signal breaks squelch, the CB audio interrupts (or mixes) with the current audio source in the radio.

While CB audio is being received, the CB Active icon is displayed in the status bar.

If necessary, adjust the squelch level so noise does not break squelch, but desired CB audio is still received.

CB audio is received through the speakers or the headsets, depending on the audio routing settings. See Speaker/Headset Selection (Page 45). Both rider and passenger headsets will receive inbound CB audio.

TUNING CB CHANNELS

The CB radio can access all 40 channels. While on the CB screen, press the PREVIOUS/NEXT hand control to advance through the CB channels individually. Channels can only be changed while in the CB screen.

Refer to local regulations for any further restrictions or recommendations on local channel use. For some of the popular CB channels used, refer to Table 33.

Table 33. CB Channels: Popular or Reserved

CHANNEL	DESCRIPTION
Channel 8	Unofficial travelers channel (Australia)
Channel 9	Reserved for emergency and traveler assistance use only (most countries)
Channel 13	Unofficial travelers channel (Greece)
Channel 15	Unofficial travelers channel (Russia)

Table 33. CB Channels: Popular or Reserved

CHANNEL	DESCRIPTION
Channel 17	North-south freeway trucker channel (US)
Channel 19	East-west freeway trucker channel (US) Unofficial travelers channel (most countries)

CB PRESETS

The CB screen stores six preset channels. Save your most commonly used channels as presets so they can be easily accessed. Some recommended presets include channel 9 (emergency channel) and channel 19 (unofficial travelers channel).

Setting CB preset: Tune to a CB channel. Press and hold a CB preset button until the system beeps and the channel is saved.

Recalling CB preset: With the CB turned on, press the desired CB preset button.

NOTE

CB channels cannot be configured as global presets or favorites.

SQUELCH

The squelch level determines the minimum signal strength that will unmute CB reception. When a CB signal exceeds

the selected threshold, the radio will "break squelch". The current audio source (such as a radio station or media file) mutes and the CB channel is unmuted.

Adjusting squelch: See Figure 106. With the CB turned on, push down the squelch switch (SQ-) until noise and static are heard. The CB Active icon will be displayed. Then push up the squelch switch (SQ+) one or two levels. This eliminates noise while allowing any stronger signals to break squelch.

Intermittent noise: If intermittent noise or undesired weak CB signals continue to break squelch, consider raising the squelch further. However, setting the squelch too high can prevent desired CB audio from being received.

Maximum squelch: At maximum squelch, the radio will not break squelch for any signal. All inbound CB signals are effectively muted.




Figure 106. Squelch (Conceptual Illustration)



Figure 107. CB Squelch Level

CB VOLUME

CB audio routing: CB audio can be routed to the speakers or the rider/passenger headsets. See Speaker/Headset Selection (Page 45).

Adjusting CB volume (while on CB screen): Use rider volume controls to adjust speaker or rider headset volume. Use passenger volume controls to adjust passenger headset volume.

Adjusting CB volume (while not on CB screen): See Figure 108. While CB audio is being received, use the rider or passenger volume controls. If necessary, first reduce the squelch until CB audio breaks squelch, then adjust the volume. Raise the squelch to its original level.




Figure 108. CB Volume

PASSENGER CB OPERATION

The passenger can also transmit over the current CB channel, adjust CB volume for the passenger headset and listen to inbound CB audio in the passenger headsets. The passenger cannot adjust speaker volume, adjust squelch or change CB channels.

Initiating CB transmission (passenger): When channel is clear, press and hold the passenger PTT switch on side of Tour-Pak. Both the rider and passenger microphones become active. Release PTT switch when finished.

Adjusting CB volume (passenger): While on CB screen (or while CB is in operation), use UP/DN switch on side of

Tour-Pak to adjust passenger headset volume. The volume switch does not affect the speakers or rider headset volume.

FACTORS AFFECTING CB RANGE

Adverse weather, buildings, hills and valleys can affect the maximum range for the CB radio. Degraded reception or transmission capability can also occur in tunnels or parking garages. The CB transmitter is the most powerful allowed under US federal law. However, since there is no large steel area to create a ground plane, the CB may not transmit as strongly as CBs mounted in a car or truck.

ADDING AN OPTIONAL CB MODULE

Bike-to-bike (CB) communication is standard on some vehicles in select locations. For vehicles not equipped with a CB, the optional CB accessories can be purchased at www.h-d.com/store or at an authorized Harley-Davidson dealer.

Installation of the CB module may only be allowed in particular regions. See www.h-d.com/store or your authorized Harley-Davidson dealer for fitment and requirements. Follow the instruction sheet procedures or have an authorized Harley-Davidson dealer install the accessory. For set up and operation, use the instructions in this manual.

INTERCOM

The intercom allows the rider and passenger to talk with each other through the headsets. The intercom can be operated by pressing the PTT switch or by using voice operated transmission (VOX). When voice input is picked up by the rider or passenger microphone, the intercom is automatically activated. This process is known as "breaking VOX".

The rider or passenger can initiate intercom communication. When the intercom is active, tuner and media volume are automatically reduced so the intercom can be heard through the headsets.

For privacy, the intercom is only heard through the rider and passenger headsets. It is not heard through the speakers.

Microphone sensitivity and headset volume can be adjusted. The microphone sensitivity (VOX) applies to both rider and passenger microphones. The rider and passenger headset volumes are adjusted independently.

NOTE

Some local governments prohibit or restrict the use of headset (helmet-mounted) speakers. Check with local authorities and obey all applicable laws and regulations.



- | | |
|---|--|
| 1. Intercom on/off button | 4. Maximum level (open microphone, intercom on continuously) |
| 2. Voice activation (VOX) sensitivity level | 5. Intercom state (on/off) |
| 3. Minimum level (PTT activation only) | 6. Intercom active/idle |

Figure 109. Intercom Screen

TURNING INTERCOM ON/OFF

1. Select **Home > Com > Intercom**.
2. Select the button in upper left corner until it displays **On** or **Off**. When turned on, the intercom is available for use and the intercom icon is displayed in the status bar. The intercom can be used while on any screen.

ADJUSTING MICROPHONE SENSITIVITY: VOX

VOX sensitivity should be adjusted so the microphones break VOX at normal voice volume. The sensitivity level applies to both the rider and passenger microphones.

Adjust the sensitivity as needed if the microphone breaks VOX from unintended sounds, such as road or background noise.

1. Select **Home > Com > Intercom**.
2. While speaking into the microphone, use the controls (+ and -) to adjust the sensitivity until your normal voice volume breaks VOX. The intercom icon in the status bar should be white (active) when speaking at a normal tone.
 - a. **Raise sensitivity:** Move the level to the right. The microphone becomes more sensitive. The intercom will activate (break VOX) with quieter sounds through the microphone.
 - b. **Reduce sensitivity:** Move the level to the left. The intercom will only activate (break VOX) with louder voice or sounds.
 - c. **Fully open microphone:** Raising the sensitivity to the maximum level will keep the intercom microphone open continually.
 - d. **PTT only:** Reducing the sensitivity to the minimum level will prevent any VOX operation. The intercom can only be activated with the PTT switch.

SPEED VOLUME

Speed volume is applied to the intercom to compensate for engine noise, wind and road input. As the motorcycle speed increases, the sensitivity of the microphones will automatically decrease. This prevents road noise from breaking VOX. It

also prevents unnecessary adjustments to the microphone sensitivity while riding.

ADJUSTING INTERCOM VOLUME: RIDER AND PASSENGER HEADSETS

1. Activate the intercom (press the PTT switch or speak loud enough to break VOX).
2. Adjust the volume while the intercom is active. The intercom volume displays on the screen while the intercom is activated. Rider and passenger headset volumes are independently controlled.
 - a. **Rider:** Press the volume controls on the left handlebar.
 - b. **Passenger:** Press the VOL+/VOL- switch on the side of the Tour-Pak.



Figure 110. Intercom Volume

OPERATING INTERCOM: VOICE ACTIVATION, VOX

Speak into the microphone at an adequate level to break VOX. The tuner or media volume will reduce into the background so the intercom can be heard. The intercom icon will turn white (active).

The intercom audio will be heard in the headsets. VOX activated communication is not broadcasted over the CB.

OPERATING INTERCOM: PTT SWITCH

1. Press and hold the PTT switch (rider or passenger) to activate the intercom. The intercom icon will turn white (active). The tuner or media volume will mute so the intercom can be heard.
2. Speak into the microphone. While the PTT switch is held, the microphones will remain active regardless of the VOX setting or sound level.

NOTE

- *If the CB is turned on, pressing the PTT switch will also activate the CB. Any sound in the microphones will be shared over the current CB channel. Turn off the CB or use the voice activation (VOX) feature if there is a need to communicate privately.*

- *To activate the intercom with only the PTT switch (rather than VOX), reduce the VOX sensitivity to its lowest level. See *Adjusting Microphone Sensitivity: VOX* (Page 120).*

SIRIUSXM SATELLITE RADIO

SiriusXM radio is equipped on select vehicles in North America. See Features and Specifications (Page 5). The radio includes over 200 digital channels of music, news, talk, entertainment and sports. The radio broadcast is over satellite (with ground repeaters) to provide consistent programming and signal quality nationwide without a break in coverage.

SiriusXM specialty services provide weather mapping, weather forecast data, fuel price information and traffic data service. SiriusXM traffic provides information for traffic events and road conditions. This data is integrated with the navigation system to provide speed flow along selected routes and notifications of traffic situations (such as accidents or lane closures).

OPTIONAL SIRIUSXM ACCESSORY

SiriusXM functionality is standard on select vehicles in covered regions. For vehicles not equipped with SiriusXM, the optional SiriusXM accessory can be purchased at www.h-d.com/store or at an authorized Harley-Davidson dealer. See dealer or website for fitment and requirements when adding this accessory.

Follow the instruction sheet procedures or have an authorized Harley-Davidson dealer install the accessory. After installation, use the instructions in this manual to set up, subscribe and operate the SiriusXM features.

TRIAL SUBSCRIPTION

New vehicles equipped with SiriusXM from the factory include a three-month trial subscription for SiriusXM Radio, Traffic and Travel Link service in regions where service is available. This trial subscription is only available to the original purchaser of a new SiriusXM equipped vehicle, and is not included with SiriusXM modules that may be subsequently purchased or installed by the customer or dealer. Terms and conditions of service may be modified from time to time by SiriusXM. See www.siriusxm.com.

CHECK SUBSCRIPTION STATUS

1. Select **Home > Setup > SiriusXM Setup**.
2. Select **Subscription**.
3. **Radio subscription:** See Figure 111. Select **Radio**. The Radio Services subscription status is displayed with an ESN number and SiriusXM phone number for assistance or activation. **Specialty services:** See Figure 112. Select **Specialty Services**. The subscription status for each service (traffic, fuel, weather and forecast services) is displayed with an ESN number and SiriusXM phone number for assistance or activation.



Figure 111. Radio Service Subscription Screen



Figure 112. Specialty Services Subscription Information

SUBSCRIBING TO SIRIUSXM

1. See Figure 113. Turn on the radio. SiriusXM starts up with a preview channel (channel 1) until subscription is active.

2. Get the ESN number for the radio. See Check Subscription Status (Page 123).
3. Verify that the SiriusXM signal is being received. Check the SiriusXM Signal Strength icon in the status bar. Channel 1 (preview channel) should be playing audio.
4. **Subscribe by internet:** Go to www.siriusxm.com. Click the subscription link. **Subscribe by phone:** Call the phone number on the ESN screen. See Check Subscription Status (Page 123).
5. Keep the radio turned on until the subscription process is complete. Activation may take up to an hour. Since the vehicle will automatically turn off after 20 minutes in accessory mode, it may be necessary to start up and ride the motorcycle.



Figure 113. SiriusXM Preview Channel

LISTENING TO SIRIUSXM RADIO

SiriusXM features may take a few moments to be displayed after the motorcycle is first started.

1. Select **Home** > **SiriusXM**.
2. See Figure 114. Select **Radio**.




Figure 114. SiriusXM Radio Screen

SIRIUSXM PRESETS

Channel presets can be programmed to quickly access favorite channels. The radio includes 20 SiriusXM presets.

1. Select a channel.
2. Press and hold a preset until the system beeps.

SELECTING A CHANNEL: HAND CONTROLS

Advancing through channels: Press the PREVIOUS/NEXT hand control switch to change the channel.

Changing seek/preset mode: From the SiriusXM screen, select **Menu**. Press the multiselect button to choose **Seek** (PREVIOUS/NEXT switch will advance to next channel) or **Preset** (PREVIOUS/NEXT switch will advance to next preset).

SELECTING A CHANNEL: CHANNEL LIST

1. See Figure 115. From the SiriusXM screen, select **Channel**. A list of channels are displayed. If specific categories have been selected, the list only displays channels that apply to those categories. See SiriusXM Categories (Page 128).
2. Use the scroll controls to advance through the list.
3. Select the middle button to toggle the list between channel name, artist, current song.
4. Select a channel from the list.




Figure 115. Channel List

SELECTING A CHANNEL: DIRECT TUNE

1. See Figure 116. From the SiriusXM screen, select **Menu**.
2. Select **Direct Tune**.
3. Use the keypad to enter a channel number.
4. Select **Tune** to change to the selected channel.




Figure 116. Direct Tune

SELECTING A CHANNEL: VOICE RECOGNITION

See Voice Recognition (Page 179) for more commands and instructions.

1. Press the VOICE RECOGNITION switch.

2. Speak one of the following commands into the microphone:
 - a. **Listen to SiriusXM radio:** X M
 - b. **Select a channel:** CHANNEL (followed by the channel name or number)
 - c. **Select next channel up:** CHANNEL UP
 - d. **Select next channel down:** CHANNEL DOWN
 - e. **Scan channels:** CHANNEL SCAN

SCANNING SIRIUSXM CHANNELS

1. From the SiriusXM screen, select **Menu**.
2. Select **Scan**. The radio will advance through each channel, dwelling for five seconds on each channel.
3. Press the CURSOR/SELECT hand control switch to select a channel.

TAGGING AN ARTIST OR SONG

Tagging allows you to be alerted when a tagged artist or song is playing on any SiriusXM channel. Up to 20 song or artist tags can be saved.

1. From the SiriusXM screen, select **Menu**.
2. While the song or artist is playing, select **Tag This**.

3. The system prompts to tag the song or the artist. Once tagged, the system will confirm your selection.

VIEWING TAGGED LIST

1. From the SiriusXM screen, select **Menu**.
2. Select **Tagged**.
3. See Figure 117. To turn off alerts for a particular song or artist, uncheck the item in the list. To resume alerts, check the item again.




Figure 117. Tagged List

TAG ALERT

An alert pops up when a tagged song or artist plays on any channel. Select **Listen** or **Ignore**.

Listen: Changes to the channel with the tagged song or artist playing.

Ignore: Remains on the current channel.

SIRIUSXM CATEGORIES

The radio can be configured to seek or scan for particular types of programming (such as news, sports or classical music). When seeking or scanning, the radio only stops on stations with the selected categories. The channel list will include only stations with the selected categories.

1. From the SiriusXM screen, select **Channel**.
2. Select **Cat**.
3. See Figure 118. Select the desired categories from the list.



Figure 118. SiriusXM Categories

GAME ZONE

Game Zone can be set up to trigger an alert when games are broadcasting or score changes occur for your favorite teams. The alerts provide an opportunity to tune to the channel and listen to the game.

ENABLING SPORTS ALERTS

Sports Alerts must be enabled before the radio provides game or score notifications.

If Sports Alerts is disabled, all the game and score settings configured for your favorite teams are still retained. However, the system will not provide notifications until Sports Alerts is enabled again.

1. From the SiriusXM screen, select **Menu > Game Zone**.
2. Check the **Sports Alerts** checkbox. Game and score alerts that have been set for any favorite teams will be displayed as they occur.

ADDING A GAME ZONE FAVORITE

Up to seven teams can be added as Game Zone favorites.

1. From the SiriusXM screen, select **Menu > Game Zone**.
2. Select the type of team (MLB, NBA, and so on). A list of teams within the selected league are shown.

3. Select a team from the list.
4. To display an alert whenever a game is being broadcast for this team, check the **Game** checkbox.
5. To display an alert whenever a score changes in a game for this team, check the **Score** checkbox.
6. Select **Add to Favorites**. If either of the checkboxes are selected, the team automatically becomes a favorite.

SETTING GAME OR SCORE NOTIFICATION

1. From the SiriusXM screen, select **Menu > Game Zone**.
2. Check the **Sports Alert** checkbox (if unchecked).
3. Select **Favorite Teams**.
4. See Figure 119. Select a team from the list.
5. **Game notification:** To display an alert whenever a game is being broadcast for this team, check the **Game** checkbox.
6. **Score notification:** To display an alert whenever a score changes in a game for this team, check the **Score** checkbox.




Figure 119. Setting Game or Score Notification

RESPONDING TO GAME ZONE ALERT

See Figure 120. Depending on the settings, a Game Zone alert pops up when a game is being broadcasted or a score change has taken place for a favorite team.

Listen: The radio tunes to the channel that is broadcasting the game.

Ignore: The radio continues with its current audio source.




Figure 120. Game Zone Alert

REMOVING A GAME ZONE FAVORITE

1. From the SiriusXM screen, select **Menu > Game Zone**.
2. Select **Favorite Teams**.
3. Select the team to be removed from the list.
4. Select **Clear from Favorites**. The team will be removed from the Game Zone favorites list.

DISPLAYING CURRENT WEATHER

1. From the SiriusXM screen, select **Specialty Services > Forecast**.
2. Select **Current Location** or **Other Location**.
3. If selected Other Location, select the state and location to view.
4. See Figure 121. Select **Current**. The screen shows the current weather conditions.
5. See Figure 122. Select **Details** to display a detailed list of weather conditions.



Figure 121. Current Weather



Figure 122. Current Weather Details

DISPLAYING DAILY FORECAST: 3 AND 6 HOUR

1. From the SiriusXM screen, select **Specialty Services > Forecast**.
2. Select **Current Location** or **Other Location**.
3. If selected **Other Location**, select the state and location to view.
4. See Figure 123. Select **Daily**. The screen shows the forecasted weather conditions in 3 hours and 6 hours.



Figure 123. Daily Weather Forecast




Figure 124. 5 Day Weather Forecast

DISPLAYING 5 DAY FORECAST

1. From the SiriusXM screen, select **Specialty Services > Forecast**.
2. Select **Current Location** or **Other Location**.
3. If selected **Other Location**, select the state and location to view.
4. See Figure 124. Select **5 Day**. The screen shows the forecasted weather conditions for today and tomorrow.
5. Use the scroll controls to scroll through the next five days of weather data.

SIRIUSXM FUEL PRICES

The fuel feature provides the fuel prices at stations within a specified distance of the motorcycle. This feature can be used to route to a selected station, or add stations to an existing route.

SELECTING FUEL TYPE

The radio shows locations and prices according to the fuel type that is selected (regular, medium, super or diesel).

NOTE

Use only unleaded gasoline with the fuel type and octane specified for your motorcycle. Do not use diesel or other inappropriate fuels for the motorcycle. See the vehicle owner's

manual. Using the wrong type of fuel can damage the engine, fuel system and other components.

1. From the SiriusXM screen, select **Specialty Services > Fuel**. The radio displays the fuel type that is currently selected.
2. Select **Fuel Type**.
3. Select the fuel type from the list. This fuel type will be used when searching for prices.

VIEWING FUEL PRICES

NOTE

Fuel prices are shown per gallon or liter, depending on the English/Metric setting.

1. From the SiriusXM screen, select **Specialty Services > Fuel**.
2. Check that the fuel type is appropriate.
3. See Figure 125. Select **View Prices**. A list of up to 30 nearest stations within 100 miles are displayed. The stations are listed by distance from the current location.
4. **Sort by brand/price/distance**: Select the middle scroll button to sort the list by brand (station name), fuel price, or distance to the station.
5. Select a station from the list.

6. See Figure 126. Options for the station are displayed.
 - a. **Route to station**: Select **Route/View**. To add the station to an existing route, select **Add**. Otherwise, select **OK**.
 - b. **Call station**: With phone connected, select **Call**. The phone dials the gas station (to confirm prices, check operating hours, and so on).
 - c. **See all prices at station**: Select **Fuel Prices** to display the prices for all fuel types at the station. A date stamp for the price data is also displayed.




Figure 125. Fuel Prices



Figure 126. Gas Station Selected

SIRIUSXM TRAFFIC

SiriusXM Traffic displays a list of messages regarding traffic, construction, accidents or other events nearby that may impact your chosen route. The system can be configured to provide popups of traffic events, and provide new routes to avoid traffic obstructions.

TURNING TRAFFIC ON

When using the traffic feature, the system will automatically prompt to turn on traffic if necessary. Traffic can also be enabled in the system settings. See Turning Traffic On/Off (Page 172).

TRAFFIC NOTIFICATION POPUPS

The system can be configured to automatically display traffic alerts that affect the current navigation route. The system will only display the notification when a route is currently active and an alternative route would reduce the current ride time by five minutes or more.

See Rerouting (Page 173).

TRAFFIC ICONS

A description of all traffic icons is displayed in the Setup menu. Select **Setup > Traffic > Legend**.

Also see Traffic Event List: RDS Traffic (Page 173).

TRAFFIC REROUTE

See Rerouting (Page 173).

TRAFFIC MESSAGE LIST

1. From the SiriusXM screen, select **Specialty Services > Traffic**.
2. If prompted to turn on traffic, select **Yes**.
3. See Figure 127. A list of nearby traffic events is displayed. Each item displays the direction and distance to the traffic event. Road signs and traffic icons are also displayed.

4. To toggle between all nearby events or only events along the route, select the circular arrow button on the right side of the screen.
5. See Figure 128. Select an item from the list to display a detailed traffic message. The radio reads the text message over the speakers or headset by using the text-to-speech feature. While riding, the scroll feature for the message is locked out.
6. See Figure 129. Select the Map icon to display the incident location on the map.




Figure 127. Traffic Message List



Figure 128. Traffic Message



Figure 129. Traffic Incident Displayed on Map

SIRIUSXM WEATHER MAP

SiriusXM weather displays a map with radar and weather front information. The map is displayed in north up orientation and is typically updated every 12 minutes. The weather map displays major roadways, but it is not designed as a tool for navigation.

1. See Figure 130. From the SiriusXM screen, select **Specialty Services > Weather**. The radio displays a large scale map with the current location of the vehicle.
2. Select the map options button to configure the display of the map.




Figure 130. Weather Map

WEATHER MAP SCROLLING

See Map Scrolling: Hand Controls (Page 149).

1. With the weather map displayed, press a location on the touchscreen, or press and hold the CURSOR/SELECT hand control switch.

2. Use the cursor arrows to scroll across the map. Use the zoom controls to zoom in or out.

WEATHER MAP RADAR AND FRONTS

The radar displays patterns of precipitation on the map. The intensity of rain, snow or mixed precipitation is indicated by the legend on the bottom of the map. The map can also display weather fronts, atmospheric pressure and isobars.

1. While in the weather map, select the option button on the right side of the screen.
2. **Turn on radar:** Check the **Radar** checkbox.
3. **Turn on weather fronts:** Check the **Fronts** checkbox.
4. Select the **Back** button. Radar formations and weather fronts are displayed on the map.

Table 34. Radar Information

PRECIPITATION TYPE	INTENSITY
Rain	Seven color levels ranging from light rainfall (light green) to severe (red)
Snow	Light snowfall (light blue), heavy snowfall (dark blue)
Mixed	Light mixed precipitation (light pink), heavy mixed (dark pink)

Table 35. Weather Front Information

INDICATOR	DESCRIPTION
Cold front	Shown as a blue line with triangles. Displays the leading edge of a cold air mass. The triangles show the forward direction of the front.
High pressure (H)	Shows center of high atmospheric pressure.
Isobar	Thin line which indicates equal or constant atmospheric pressure.
Low pressure (L)	Shows center of low atmospheric pressure.
Stationary front	Shown as an alternating red-blue line with triangles and semi-circles. Displays a boundary between warm and cold air masses.
Warm front	Shown as a red line with red semi-circles. Displays the leading edge of a warm air mass. The semi-circles show the forward direction of the front.

DISPLAY LAST WEATHER UPDATE

1. With the weather map displayed, select the option button on the right side of the screen.
2. Select **Update Information**. The radio shows the date and time for the last update to the radar and weather front information.

H-D U.S.A., LLC TRADEMARK INFORMATION

Bar & Shield, Boom!, Cross Bones, Cruise Drive, CVO, Digital Tech, Digital Technician, Digital Technician II, Dyna, Electra Glide, Evolution, Fat Bob, Fat Boy, Forty-Eight, Glaze, Gloss, H-D, H-Dnet.com, Harley, Harley-Davidson, HD, Heritage Softail, Iron 883, Low Rider, Milwaukee-Eight, Night Rod, Nightster, Night Train, Profile, Reflex, Revolution, Road Glide, Road King, Road Tech, Rocker, Screamin' Eagle, Seventy-Two, Softail, Sportster, Street Glide, Street Rod, Sun Ray, Sunwash, Super Glide, SuperLow, Supersmart, Switchback, SYN3, TechLink, TechLink II, Tour-Pak, Tri Glide, Twin Cam 88, Twin Cam 88B, Twin Cam 96, Twin Cam 96B, Twin Cam 103, Twin Cam 103B, Twin Cam 110, Twin Cam 110B, Twin-Cooled, Ultra Classic, V-Rod, VRSC and Harley-Davidson Genuine Motor Parts and Genuine Motor Accessories are among the trademarks of H-D U.S.A., LLC.

PRODUCT REGISTERED MARKS

Apple, Alcantara S.p.A., Allen, Amp Multilock, Bluetooth, Brembo, City Navigator, Delphi, Deutsch, Dunlop, Dynojet, Fluke, G.E. Versilube, Garmin, Gunk, Hydroseal, Hylomar, iPhone, iPod, Kevlar, Lexan, Loctite, Lubriplate, Keps, K&N, Magnaflux, Marson Thread-Setter Tool Kit, MAXI fuse, Molex, Michelin, MPZ, Multilock, nano, NGK, Novus, Packard, Pirelli, Permatex, Philips, PJ1, Pozidriv, Road Tech, Robinair, S100, Sems, SiriusXM, Snap-on, Teflon, Threadlocker, Torca, Torco,

TORX, Tufoil, Tyco, Ultratorch, Velcro, X-Acto and XM Satellite Radio are among the trademarks of their respective owners.

NOTES

NAVIGATION

Navigation features are available on 6.5 systems in select regions. To prevent distraction while riding, plan trips and select destinations before riding the motorcycle.

The navigation system can route to address entries, phone book contacts, point of interest (POI) destinations in the navigation database, destinations imported by Ride Planner (www.h-d.com/rideplanner) or by manually selecting locations on the touchscreen map.

See Figure 131. Press the NAVIGATION switch on the faceplate or select **Home** > **Nav** to access the navigation menu.

Map: Shows map with current location.

POI: Search for points of interest (gas stations, restaurants, entertainment, and so on).

Dealership: Search for dealerships and other Harley-Davidson facilities.

Where To...: Navigate to a selected address, saved location, home address, phone book contact, trips, trails or geographical coordinates.

Recent: Navigate to a recently selected destination.

Emergency: Search for a nearby hospital, police station or fire department.

Menu: Display current GPS information. Import and export navigation files.

NOTE

- *There will be a slight delay after the vehicle or the radio has been powered on while the navigation system initializes. Wait until the system has finished the initialization process before using the navigation system.*
- *There may be some limitations when operating the navigation system in buildings or underground structures (such as tunnels or underground parking).*




Figure 131. Navigation Menu

DISPLAYING THE MAP

Display map (using faceplate switch): Press the NAVIGATION switch on the radio faceplate to display the

navigation menu. Press the NAVIGATION switch again to toggle between the navigation menu and the map.

Display map (using menus): Select **Home > Nav > Map**.

Display map (using voice recognition): Press the VOICE RECOGNITION switch. Say **SHOW MAP** into the microphone.

Map options: Select option button to show menu of navigation options.

Data fields: Select left or right data fields to change the information shown in these fields.

Current audio source: Select the bar to access current audio source screen (tuner or media). Press and hold the NAVIGATION switch on the radio faceplate to toggle the audio source field on or off.

Next turn guidance: Shows distance and turn information. Press the field to display a list of guidance instructions or avoid an upcoming road.

NOTE

See *Changing Map Display (Page 144)* for additional adjustments to the map display.



- | | |
|-----------------------------|---|
| 1. Current street | 7. Heading indicator/current position icon |
| 2. Lane guidance | 8. Next turn guidance |
| 3. Repeat voice instruction | 9. Next turn maneuver |
| 4. Compass | 10. Distance to next turn |
| 5. Map/navigation options | 11. Left data field (or current audio source) |
| 6. Right data field | 12. Zoom controls |

Figure 132. Navigation Map

Table 36. Map Components

ICON	COMPONENT	DESCRIPTION
	Yellow flag	Waypoint (intermediate destination)
	Checkered flag	Destination
	Bright orange line	Active highlighted route
	Bright green trailing line	Recorded trail
	Blue caption	Point of interest (zoomed in)
	Blue dot	Point of interest (zoomed out)
	Boxed arrows	Lane guidance (larger orange arrows show suggested lanes)
	Road signs	Shows highway number or road name

Table 37. Roads and Transportation

COMPONENT	DESCRIPTION
Blue line	Ferry
Dashed line (gray/white)	Train tracks

Table 37. Roads and Transportation

COMPONENT	DESCRIPTION
Orange-yellow line (thick)	Freeway or tollway
Red line	Bridge or overpass
White line	Minor road
Yellow line (medium thickness)	Major road

Table 38. Terrain

COLOR	DESCRIPTION
Blue	Water
Light gray	Airport/seaport
Dark gray	Industrial/business
Light green	Park
Dark green	Forest
Orange	Desert
Red	Hospital/medical facility
Yellow	Mountain or desert

CHANGING MAP DISPLAY

Map features can be turned on, off or adjusted.

1. Select **Home > Setup > Navigation Setup > Appearance**.
2. **POI icons:** Check the POI items to be displayed on the map.

3. **2D/3D map:** Select 2D map (top-down view) or 3D map (orientation is angled behind the motorcycle).
4. **North up/heading up (2D view only):** Displays the map with north toward top or rotates the map so the vehicle heading is always oriented upward in the map. 3D view is always shown in a heading up orientation.
5. **Auto zoom:** When auto zoom is enabled, the navigation system will automatically zoom the map view as the vehicle is approaching predetermined locations. Upon passing the location, the navigation system will automatically zoom out to the rider's selected Near/Normal/Far zoom level. When disabled the map zoom level will remain fixed at the rider's last setting regardless of the current or approaching locations along the route.
6. **Current street:** Displays the current street along the top of the map.
7. **Next street:** Displays the next turn at the bottom of the map.
8. **Lane guidance:** Displays lane guidance arrows along the highlighted route. When a turn is required on a multi-lane highway, the map displays bright orange arrows to suggest the proper lanes. Graphical representations of signposts and junctions are displayed.
9. **Audio info:** Displays the current audio source along the bottom of the map.

10. **Left and right data fields:** Displays the left and right data fields.
11. **Speed and flow (traffic only):** Displays traffic overlay colors on the map.
12. **Motorcycle icon:** Changes the icon used for the current position.

NOTE

The current audio source can also be toggled on and off by pressing and holding the NAVIGATION switch on the faceplate.

CHANGING DATA FIELDS

1. With the map displayed, select the left or right data field.
2. Refer to Table 39. Choose an option from the list to display in the field. Many of the data field settings (such as Time to Via or Arrival Distance) are only relevant during an active route.
3. Select **Back** to display the map.

Table 39. Data Field Options

DATA FIELD OPTIONS		
Arrival Distance	Moving Time	Time To Turn
Arrival Time	Overall Average Speed	Time To Via

Table 39. Data Field Options

DATA FIELD OPTIONS		
Clock	Speed	Total Time
GPS Accuracy	Stopped Time	Via Distance
Heading	Temperature	

NAVIGATION OPTION MENU

The navigation option menu button is displayed on the right side of the map. The following options are available when selecting this button.

POIs Near: Equivalent to selecting POIs from Navigation Main menu.

Appearance: Equivalent to selecting Appearance from the Navigation Setup menu.

Trip Summary: This screen provides information for a current trip (start and end time, average speed, fuel used and mileage, if available).

Record On: Records a trail of the current ride. See Trails (Page 159).

Compass: Displays the Compass screen.

Weather (if available): Displays a weather overlay on the map (requires SiriusXM module with subscription to weather map service).

ROUTE PREFERENCES AND AVOIDANCES

Preferences can be chosen for the path and type of roads to be used during route calculation (scenic, fastest, shortest or twisty). Selections can also be made to avoid specific types of roads or routes during a calculation (such as ferries or toll roads).

1. Access the route calculation preferences. Any of the three following methods may be used.
 - a. **Navigation setup menu:** Select **Home > Navigation Setup > Route Calculation**.
 - b. **During route calculation:** Select option button. Select **Route Calculation**.
 - c. **During active route:** Select option button on the map. Select **Preferences**.
2. Select the type of path (scenic, fastest, shortest or twisty).
3. Select **Avoidances**. Check the items to avoid. Refer to Table 40.

Table 40. Avoidances

SELECTIONS
Highway
Toll road
Ferry
In-process data (IPD)

Table 40. Avoidances

SELECTIONS
Car/train
Unpaved road
Time restriction
Seasonal restriction
Border

COMPASS

Compass and Heading Indicator on Map

See Figure 133. The compass is displayed in the upper right corner of the map. The heading indicator is displayed in the center of the map. The icons operate differently according to the map orientation setting (north up or heading up).

NOTE

The compass needle is divided into two sections. The red section is the part of the needle that points north. And the white section is the part of the needle that points south.

North Up: The map is always orientated with north up (top of screen). And the compass is always pointed up (north).

Heading Up: The heading directional display will now operate as a traditional compass with the top representing the direction ahead and the rotating needle shall point to the direction of North.

NOTE

While on other screens, the system displays the current heading in the status bar.

Full Size Compass

A full sized compass can also be displayed to show vehicle heading.

1. With map displayed, select the options button.
2. See Figure 134. Select **Compass**.

NOTE

- *For some regions that do not support navigation or mapping features on the 6.5 radio, pressing the NAVIGATION switch on the faceplate will display the full size compass.*
- *The motorcycle must be in motion to determine the current heading. If the current heading is not known, the full size compass will display question marks.*




Figure 133. Compass/Vehicle Heading Indicator



Figure 134. Compass

AUTO ZOOM

Auto Zoom

Auto zoom can be setup one of four ways when the rider's touchscreen map approaches it predetermined location.

NOTE

Keep pressing **Auto Zoom** until the option appears on the touchscreen.

1. Select **Home > Setup > Navigation Setup > Appearance >**
 - a. **Auto Zoom: Off** - Auto zoom is disabled

- b. **Auto Zoom: Near** - Will return to narrow scale
- c. **Auto Zoom: Normal** - Will return to middle scale
- d. **Auto Zoom: Far** - Will return to wide scale

MAP SCROLLING: TOUCHSCREEN

1. With the map displayed, press on the touchscreen. The scrolling tool (circle with arrows) is shown on the map. The title bar displays the name of the street that is currently being viewed.
2. **Scroll:** Press and hold the screen arrows to scroll. **Jump:** Press another location on the map to jump.
3. **Route to location:** Select the center circle to route to the location on the map. **End scrolling:** Select the Back button to end scrolling and return to the current position on map.

MAP SCROLLING: HAND CONTROLS

1. See Figure 135. With the cursor in the top title bar, press and hold the CURSOR/SELECT hand control switch until the scrolling tool is displayed.
2. Select an arrow with the CURSOR/SELECT switch. Press and hold to begin scrolling.
3. **Route to location:** Select the center circle to route to the location on the map.

4. **End scrolling:** Select the **Back** button to end scrolling and return to the current position on map.




Figure 135. Map Scrolling

SELECTING POI ON MAP

POI icons are only visible on the map at closer zoom levels. See Changing Map Display (Page 144) to change the types of POI icons that are displayed on the map.

1. See Figure 136. Scroll to a POI icon on the map. Zoom close to the icon.
2. Refer to Table 41. With the POI in the circle, select the POI location. The radio calculates a route to the selected POI. If multiple POIs are in the same location, the system will prompt with a list of POIs.
3. Select the option button to show more options for the POI. Otherwise, select **Go** to begin route.




Figure 136. Selecting POI On Map

Table 41. POI Icons

ICON	DESCRIPTION
	ATM/Banking
	Automotive

Table 41. POI Icons

ICON	DESCRIPTION
	Coffee shop
	Community
	Entertainment
	Gas station
	Harley-Davidson
	Health and beauty
	Highway exit
	Hospital
	Hotel/motel
	Other
	Parking
	Recreation

Table 41. POI Icons

ICON	DESCRIPTION
	Restaurant
	Shopping
	Travel
	Truck stop

ROUTE TO DESTINATION: ADDRESS

1. See Figure 137. Select **Home > Nav > Where To**.
2. Select **Address**.
3. See Figure 138. Enter the address into the fields.
4. Select **OK**.

NOTE

- The system uses the smart speller to narrow entries according to the contents of the navigation database.
- The system provides lists of possible destinations based on the input. For example, entering "Birch Street" generates a list of all cities with a "Birch Street" in the database.

- As a minimum, the system requires either a postal code or a city and state. If a street address is not entered, the system navigates to the city center. Requirements may vary slightly according to region.




Figure 137. Where To Screen



Figure 138. Address Screen

ROUTE TO DESTINATION: HOME

The Home destination can be used to quickly set up a route back to home from any location.

1. Select **Home > Nav > Where To**.
2. Select **Home**.
3. **Home has been programmed:** The system calculates a route to the home destination. Select **Go**. **Home has not been programmed:** Select a home destination (address, recent destination, or so on). The destination will be used for all future home routing. To save your current destination as home, see Saving Current Location (Page 168).

NOTE

- To delete or change the home destination, activate a route to home and select the option button on the map. Select **Delete Destination**. Repeat steps to program a new home destination.
- Once a home address has been saved, a voice command can also be used to navigate home. Press the **VOICE RECOGNITION** switch and say **HOME** into the microphone.

ROUTE TO DESTINATION: RECENT

1. Select **Home > Nav > Where To**.
2. Select **Recent**. The system displays a list of up to 99 recent destinations (without including duplicates).
3. Select a recent route from the list.
4. Select **Go**.

NOTE

- To delete all recent destinations from the list, select the trash can button.
- To add a recent destination to the saved list, select the option button and select **Save**.

ROUTE TO DESTINATION: PHONE BOOK

The system can navigate to phone book addresses stored on a connected phone or saved locally in the radio.

1. Select **Home > Nav > Where To**.
2. Select **Book**.
3. Display saved contacts:
 - a. **If phone connected:** Select **Saved on Radio** (to display phone contacts from the saved list) or **On Connected Phone** (to use the phone book on a connected phone).
 - b. **If phone is not connected:** The radio displays contacts that have been saved to the radio. See Saving a Phone Book Contact (Page 93).
4. If prompted, enter any missing information in the address.
5. Select **OK** to calculate the route. Select **OK** again to start navigation.

ROUTE TO DESTINATION: SAVED

After a destination has been saved, it can be used for future rides. See Saving a Destination: Saved, Preferred or Home (Page 168).

1. Select **Home > Nav > Where To**.

2. Select **Saved**.
3. Select saved destination from the list.
4. Select **Route/View**.
5. Select **Go**.

ROUTE TO DESTINATION: MAP SCROLL TOOL

1. With the map displayed, press on the touchscreen to activate the scrolling tool.
2. Scroll to a location or POI.
3. Select the center circle to route to the location or POI on the map.
4. Select **Go**.

ROUTE TO DESTINATION: POI

The system can route to points of interest stored in the navigation database.

1. Select **Home > Nav > POI**.
2. See Figure 139. Select the location for the POI. Choose from the following options:
 - a. **Near Location:** shows POIs near your current location.

- b. **Around a City:** shows POIs near a particular city. Enter the city name.
 - c. **Along Route:** shows POIs along the active route.
 - d. **Near Destination:** shows POIs near the destination (during active route).
3. Select one of the following options to find the POI.
- a. **Category:** Browses through a list of categories. Refer to Table 41.
 - b. **Preferred:** Displays a list of POIs that have been saved as preferred destinations (such as a particular restaurant chain or gas station brand). The system will search for the same preferred chain or brand within the selected area. See Saving a Destination: Saved, Preferred or Home (Page 168).
 - c. **Spell Name:** Use the keyboard to enter a full or partial name of the POI. The system displays matching POIs in the selected area.
 - d. **Phone Number:** Enter a phone number for the destination. The system will display POIs with that phone number in the selected area.
4. **Toggle distance/name:** The list of POIs is displayed in order of distance. Select the reorder button on the right side of the screen to display the list by alphabetical order or by distance from current location.

- 5. Select a POI from the list.
- 6. Select **Go**.




Figure 139. Route To Destination: POI

ROUTE TO DESTINATION: DEALERSHIP

The navigation database includes dealerships and other Harley-Davidson facilities (such as the Harley-Davidson Museum).

- 1. Select **Home > Nav > Dealerships**.
- 2. Select a location from the list.

3. Select **Go**.

ROUTE TO DESTINATION: EMERGENCY

NOTE

In case of emergency, contact the facility to verify their availability before proceeding.

1. Select **Home > Nav > Emergency**.
2. Select **OK** to acknowledge the alert.
3. Select **Hospital, Police** or **Fire Department**.
4. Select a location from the list.
5. See Figure 140. Select **Go**.



Figure 140. Route To Destination: Emergency

ROUTE TO DESTINATION: COORDINATES

1. Select **Home > Nav > Where To**.
2. Select **Geo**.
3. See Figure 141. Use the multiselect button to adjust the format for the coordinates if necessary. The formats can include heading (h) such as North, degrees (d), minutes (m), and seconds (s).
 - a. **h ddd.ddddd°**
 - b. **h ddd° mm" ss.s'**
 - c. **h ddd° mm.mmm'**
4. Enter the latitude and longitude coordinates.
5. Select **OK**.




Figure 141. Route To Destination: Coordinates

ROUTE TO DESTINATION: SIRIUSXM FUEL PRICES FEATURE

For motorcycles equipped and subscribed to the SiriusXM Fuel Prices feature, routing can be made to a nearby gas station based on current fuel prices. See SiriusXM Fuel Prices (Page 132).

ROUTE TO DESTINATION: VOICE COMMAND

1. With route active, press the VOICE RECOGNITION switch.

2. Select one of the following options:
 - a. **Route to address:** Say **DESTINATION** followed by the address into the microphone.
 - b. **Route to saved destination:** Say **FAVORITE** followed by the saved destination name into the microphone.
 - c. **Route to POI:** Say **FIND NEXT** followed by the type of destination or brand name (such as **BANK** or **GAS STATION**).

CANCELING A ROUTE: USING MENUS

1. While the map is displayed, select the option button.
2. Select **Stop**.

NOTE

When selecting a new route, the system provides a notification to either add or replace the existing route. There is no need to manually cancel the current route when adding or replacing it with a new route.

CANCELING A ROUTE: VOICE COMMAND

1. With route active, press the **VOICE RECOGNITION** switch.
2. Say **CANCEL ROUTE GUIDANCE** into the microphone.

TRIPS

Trips are useful when visiting a number of POIs during an extended ride, planning rides with intermediate destinations (waypoints) or when planning a ride with restaurants and overnight lodging. A total of 17 trips can be stored in the system. Each trip can include up to 100 destinations.

A trip can be created using the navigation menus or by creating a trip on the map screen. Trips can also be imported from Ride Planner. See Importing a Route (Page 161).

CREATING A TRIP: USING MENUS

1. Select **Home > Nav > Where To**.
2. Select **Trip**.
3. Enter a name for the trip. Use a name that is easy to pronounce when using voice recognition features. Select **OK**.
4. Enter a destination (address, POI, recent destination, saved location or intersection).
5. Select **Add**. When prompted to add more destinations, select **Yes** to add more destinations or select **No** when finished.
6. The trip itinerary is displayed.

7. **To start the trip:** Select **Start**. **To edit the trip:** Select the edit button (pencil icon). See Editing a Trip: Adding Waypoints in Menu (Page 158).

CREATING A TRIP: USING MAP

1. With map displayed, press the touchscreen.
2. Scroll to a POI or location on the map. Select the center circle to calculate a route to the destination. Select **Go**.
3. Repeat the previous step to add more destinations to the route. Up to nine destinations can be added to a trip.
4. After all destinations have been chosen, select the option button on the map.
5. Select **Destinations**. Select the edit button (pencil) to reorder the waypoints as needed.
6. Select **Save As Trip**.
7. Enter a name for the trip. Select **OK**.

ROUND TRIP

When the round trip function is enabled, the system calculates a return route to the original position of the vehicle. The round trip feature can only be enabled before a route is activated.

1. With no route active, access the route calculation settings.
 - a. **From setup menu:** Select **Home > Navigation Setup > Route Calculation**.

b. **During route calculation:** Select option button. Select **Route Calculation**.

2. Check the **Round Trip** checkbox. When a new route is created, the map will include a return route back to the original location of the vehicle.

EDITING A TRIP: ADDING WAYPOINTS IN MENU

1. With a trip selected, press the edit button (pencil).
2. Select **Add Destination**.
3. Enter a destination (address, POI, recent destination, saved location or intersection).
4. Select **Add**. When prompted to add more destinations, select **Yes** to add more destinations, or select **No** when finished.
5. The trip itinerary is displayed.

EDITING A TRIP: ADDING WAYPOINTS ON MAP

1. With active route on the map, press the touchscreen.
2. Scroll to a POI or location on the map. Select the center circle on the destination to add.
3. Select **Add**.

EDITING A TRIP: REORDERING WAYPOINTS

1. With a trip selected, press the edit button (pencil).
2. Select **Reorder**.
3. See Figure 142. Select a destination to reorder.
4. Select the reorder button on the right side of the screen. The item being moved is highlighted.
5. Select the place to move the highlighted item. The item will be moved **before** the selected place (if higher on the list) or **after** the selected place (if lower on the list).
6. Change the order of other destinations as needed. When finished, select **Back**.



Figure 142. Editing a Trip (Reordering Waypoints)

EDITING A TRIP: SKIPPING NEXT WAYPOINT

1. With active route on the map, select the option button.
2. Select **Skip Next Waypoint**.
3. Select **Yes**.

EDITING A TRIP: SKIPPING WAYPOINTS FROM LIST

1. With active route on the map, select the option button.
2. Select **Destinations**.

3. Select the destination to skip.
4. Select the options button.
5. Select **Stop**. The system removes the waypoint from the current route. However, the waypoint is not removed from the originally stored trip.

TRAILS

See Figure 143. A trail is a specific path which is recorded during your ride. While the trail is recording, the system stores ongoing location points along the ride. This is different than saving a destination or trip, which only store a number of locations rather than a specified path.

A trail can be used to repeat the ride along the same path in the future or to route back to the start of the trail using the same path.

A trail can be recorded at any time. A route does not need to be active to begin recording a trail.




Figure 143. Recording a Trail

RECORD A TRAIL: OPTIONS MENU

1. With the map displayed, select the option button.
2. **Start trail:** Check the **Record On** checkbox. The trail begins recording.
3. **End trail:** Uncheck the **Record On** checkbox. The trail stops recording and is stored in the list of trails.

RECORD A TRAIL: TRAILS MENU

1. From the Navigation menu, select **Where To > More > Trails**.
2. **Start trail:** Select **New**. If a previous trail was being recorded, it is saved to the trail list. The new trail begins recording.

3. **End trail:** Uncheck the **Record On** checkbox. The trail stops recording and is stored in memory with the current date and time.

RENAME A TRAIL

The system names trails as "trl" followed by a string of numbers. Trails can be renamed with more meaningful names.

1. From the Navigation menu, select **Where To > More > Trails**.
2. Select the trail from the list.
3. Select **Rename**.
4. Use the keyboard to enter a new name for the trail. Select **OK**.

NAVIGATING A TRAIL

A trail can be used to ride the originally recorded route (from start to end) or a return route (from end to start). When selecting a trail, the route includes navigation from your current location to the beginning of the trail.

1. From the Navigation menu, select **Where To > More > Trails**.
2. Select the trail from the list.

3. Select:
 - a. **Take original route (start to end):** Select Route to End.
 - b. **Take return route (end to start):** Select Route to Start.

DELETING A TRAIL

1. From the Navigation menu, select **Where To > More > Trails**.
2. Select the trail from the list.
3. Select the trash can button.
4. Select **Yes** to confirm.

EXPORTING A ROUTE

A trip, trail or saved destination can be exported to a USB storage device. The system exports the set of routes as a GPX file named "H-D_NavData.gpx". If needed, the system adds a sequential number to prevent overwriting other previously saved files (such as "H-D_NavData(1).gpx"). Multiple trips or destinations can be contained in a single GPX file.

The export feature is designed to back up routes or share routes with other riders that have a Boom! Box system. While

the GPX file may be imported into other GPS devices, there may be limitations on compatibility.

1. While stopped, connect a USB device to store the files. The USB device must be formatted to FAT16 or FAT32 (typical format used by PCs) to support data exports. NTFS-formatted devices are read-only and do not support GPX export.
2. From the Navigation menu, select **Menu**.
3. Select **Export**. A list of trips, trails and saved destinations are displayed.
4. Check the checkboxes for all items to be exported, or choose **Select All**.
5. Select the **USB Export** button on the right side of the screen.
6. Select **OK** when the export completes. The USB device can be removed.

IMPORTING A ROUTE

The system can import trip, trail and destination files saved in GPS Exchange Format (GPX). The files may have been exported by another motorcycle equipped with a Boom! Box or created by Ride Planner (www.h-d.com/rideplanner). A single GPX file may contain multiple trips and destinations.

The system can use GPX files exported by other GPS devices or mapping websites. While GPX is a standard format for navigation files, there may be some limited compatibility when importing these routes. Review the route before riding.

Imported routes are stored in respective locations within the radio. Destinations are stored in the Saved list. Imported trips are stored in the Trips list. Imported phone book contact files (V-card files, VCF) are added to the Book list in the navigation menu.

1. While stopped, connect a USB device to store the files.
2. From the Navigation menu, select **Menu**.
3. Select **Import**. A list of GPX and VCF files are displayed.
4. Select a GPX or VCF file from the list. A list of all trips, trails and destinations within the GPX file are displayed.
5. Select the trips, trails and destinations to import.
6. Select the **Import** button on the right side of the screen.
7. Select **OK** when completed. The USB device can be removed.

EXPORTING A RIDE PLANNER ROUTE


1. Connect a USB drive to the computer. The USB drive must be formatted to FAT16 or FAT32 (commonly used by most PCs).

2. Open Ride Planner (**www.h-d.com > Owners > Ride Planner**).
3. Create a new route or select an existing route (H-D Great Road, rider-submitted road or personally saved road).
 - a. See Figure 144. Add locations for major destinations, such as the start point and end point.
 - b. Add waypoints for other minor stopping points or desired roadways to be traveled.
4. Select **GPS Sync**.
5. Select **Manual Mode**.
6. Select **Save As GPX File**.
7. Add a unique name for the route, and select **Export Stops and Waypoints**.
8. Save the GPX file to the USB drive. By default, Ride Planner will name the file as "HDRoute.gpx". Rename the file to a unique name as necessary.
9. Remove the USB drive and import the file into the radio. See Importing a Route (Page 161).

NOTE

- See Figure 145. Ride Planner exports each pair of locations as a separate trip (even though the entire Ride Planner route is exported as a single GPX file). In the example, the route from Location 1 to Location 2 (with the intermediate waypoints) is exported as a trip. The route from Location 2 to Location 3 is exported as a separate trip.
- The Boom! Box navigation system does not differentiate between locations and waypoints. All items are imported as destinations. When plotting a route, remember that each trip can only include a total of nine destinations.
- Ride Planner exports locations and waypoints into the GPX file. It does not export the highlighted route. The exact routing between destinations may be calculated differently within the radio than shown in Ride Planner. To plot a particular path, you may need to add waypoints along the desired route. Also, the route calculation can be affected by system settings such as route preferences (scenic, fastest, shortest or twisty) and avoidances (such as toll roads, unpaved roads and so on). See Route Preferences and Avoidances (Page 146).

om02058



- 1. Locations
- 2. Waypoints

- 3. GPS Sync (export to GPX file)

Figure 144. Ride Planner




Figure 145. Ride Planner Example

MANEUVERS: TURN-BY-TURN INSTRUCTIONS

1. See Figure 146. While a route is active, select the next turn displayed at the bottom of the map. A list of all turns in the route are displayed.
2. Selecting a maneuver provides the following options:
 - a. **Avoid:** The system calculates new directions to avoid the selected road.
 - b. **Zoom:** The map displays the selected maneuver on the map.
 - c. **OK:** Returns to the list of maneuvers.
3. To restore an avoided road, select the **Avoided Segments** button. Select the avoided turn from the list. See Restoring an Avoided Road (Page 167).



1. Type of turn/maneuver
2. Distance to maneuver
3. Road/exit/street sign (select to show or avoid maneuver)
4. Show all avoided roads/turns

Figure 146. Maneuver List: Turn-By-Turn Instructions

DISPLAYING A MANEUVER: ZOOM

1. Select the next turn displayed at the bottom of the map. A list of all turns in the route are displayed.
2. Select a road from the list.
3. See Figure 147. Select **Zoom**. The map shows the maneuver, with details on the bottom of the screen.

4. Continue:
 - a. **Return to list:** Select **Back** button.
 - b. **Display previous/next maneuver:** Select previous/next maneuver buttons on screen.
 - c. **Avoid the road:** Select Avoid/Restore button.



1. Maneuver display
2. Show previous/next maneuver
3. Currently selected maneuver
4. Avoid/restore selected maneuver

Figure 147. Displaying a Maneuver: Zoom

AVOIDING A ROAD

1. Select the next turn displayed at the bottom of the map. A list of all turns in the route are displayed.
2. Select a road from the list.

3. Select **Avoid**.
4. Select **Yes** to confirm. The system calculates new directions to avoid the selected road.

RESTORING AN AVOIDED ROAD

1. Select the next turn displayed at the bottom of the map. A list of all turns in the route are displayed.
2. See Figure 146. Select the **Avoided Segments** button. A list of all avoided roads is displayed.
3. Select the road to be restored. The system displays a map of the maneuver.
4. See Figure 147. Select the **Avoid/Restore** button on the right side of the map.
5. Select **Yes** to confirm. The system recalculates directions. The restored road is considered in the calculation.

LANE GUIDANCE

See Figure 148. When an upcoming turn or road divergence is required on a multi-lane highway, the map displays lane guidance arrows to suggest the proper lanes to use. Safely change to the suggested lane and follow the direction of the bright orange arrows.

See Figure 149. When approaching the turn, the system shows a representation of the signposts and upcoming road

junction. Continue to follow the guidance of the bright orange arrows.



Figure 148. Lane Guidance



Figure 149. Signpost and Junction View

SAVING A DESTINATION: SAVED, PREFERRED OR HOME

A destination can be added to the saved list or defined as the home destination.

1. Select a destination (such as a POI, address, recent destination or GPS coordinate).
2. After the route is calculated (but before selecting Go), select the option button.
3. Select **Save**.

4. Select from one of the following options:
 - a. **Add to Saved list:** Select **Saved**. Enter a name for the currently selected location. Select **OK**. See Route To Destination: Saved (Page 153).
 - b. **Add to Preferred list (POIs only):** Select **Preferred**. Instead of saving a specific destination, the system saves the POI (such as a particular restaurant chain or gas station brand). The system can later search for the same preferred chain or brand when riding in other locations. See Route To Destination: POI (Page 153).
 - c. **Set as Home destination:** Select **Home**. The current location is stored as your home destination. See Route To Destination: Home (Page 152).

SAVING CURRENT LOCATION

The current location can be stored to the Saved destination list, or configured as the home destination.

1. Select **Home > Nav > Menu**.
2. Select **Location**. The current GPS coordinates and signal strength are displayed. Address is displayed if available.
3. Select the option button.
4. Select **Save**.

5. Select from the following options:
 - a. **Add to Saved list:** Select **Saved**. Enter a name for the current location. Select **OK**. See Route To Destination: Saved (Page 153).
 - b. **Set as Home destination:** Select **Home**. The current location is stored as your home destination. See Route To Destination: Home (Page 152).

SHOWING A PLANNED ROUTE

An entered route can be displayed before committing to the route.

1. When a destination has been selected, select the option button (before pressing Go).
2. Select **Show Route**. The map shows the entire highlighted route.
3. To commit to the route, select the **Back** button twice. Select **Go**.

SIMULATING A ROUTE

A route simulation can be viewed before committing to the route. The route simulation can only be used while the motorcycle is not moving.

1. When a destination has been selected, select the option button (before pressing Go).

2. Select **Simulate Route**. The route simulation will be played on the map. Audible turn guidance will also be played.
3. To exit route simulation, select the **Back** button.
4. To commit to the route, select the **Back** button again. Select **Go**.

CALLING A DESTINATION: ROUTE ACTIVE

There are occasions when calling a destination is helpful to determine operating hours or get information.

1. With a phone connected and the route active on the map, select the option button.
2. Select **Destinations**.
3. Select the option button.
4. Select **Call**. Select **OK** to confirm.

CALLING A DESTINATION: ROUTE NOT ACTIVE

1. With a phone connected, select a destination (such as a POI).
2. After the route is calculated (but before selecting Go), select the option button.
3. Select **Call**. Select **OK** to confirm.

TRIP SUMMARY

A summary of the current route can be displayed at any point during a ride. The summary shows start and end time, mileage information and other data.

1. During an active route, select the option button on the map.
2. See Figure 150. Select **Trip Summary**.




Figure 150. Trip Summary

LOW FUEL ALERT

See Figure 151. When the vehicle detects low fuel, the radio shows an alert and prompts with a list of nearby gas stations. The low fuel alert automatically displays even when the radio is turned off.




Figure 151. Low Fuel Alert

GPS INFORMATION

1. Select **Home > Nav > Menu**.
2. Select **Location**. The system displays the GPS signal strength, coordinates and address for the current location (if available) as shown in Figure 152.
3. Select the option button.
4. Select **GPS**. The system displays coordinates, elevation, signal and position information as shown in Figure 153.




Figure 152. GPS Location




Figure 153. GPS Information

TRAFFIC

See Figure 154. The navigation system can provide traffic information when RDS Traffic (TMC) or SiriusXM Traffic is equipped on the vehicle and available in the region. When traffic is enabled, the map shows traffic flow and events along the currently selected route. Refer to Table 42 for traffic icon descriptions.

The system also stores a list of all traffic events that are nearby or along the active route. When an event (such as an accident or lane closure) is discovered along the current route, the navigation system notifies of the event and may attempt to calculate an alternate route. The system will either prompt to make the change or will automatically adjust the route, according to the system settings.




Figure 154. Traffic

Table 42. Traffic Conditions

ICON	DESCRIPTION	ICON	DESCRIPTION
	Free flowing traffic		Heavy traffic
	Slow traffic		Accident
	Stopped traffic		Construction
	Slippery		Narrow
	Weather		Warning

Table 42. Traffic Conditions

ICON	DESCRIPTION	ICON	DESCRIPTION
	Wind		Blockage
	Frost		Security checkpoint
	Traffic		Information

TURNING TRAFFIC ON/OFF

On equipped vehicles, traffic automatically turns on when selecting the RDS traffic feature from the Home screen or when selecting the SiriusXM traffic feature.

1. Select **Home** > **Setup** > **Traffic**.
2. Check the **Traffic** checkbox to turn on.

TRAFFIC NOTIFICATION SETTINGS

1. Select **Home** > **Setup** > **Traffic** > **Notification**.
2. **Beep when traffic popup is displayed:** Check **Popup Beep** checkbox.
3. **Traffic event range:** Select **Message Filter**. Choose the maximum distance of traffic events to be displayed in the event list.

REROUTING

The system can be configured to manually or automatically select a new route based on traffic data. The system will only provide a new route when it is calculated to be at least five minutes faster than the current route.

1. Select **Home > Setup > Traffic**.
2. Choose the rerouting setting.
 - a. **Automatic:** The system will automatically adjust the route according to traffic data.
 - b. **Manual:** The system will provide a popup when a new route is suggested. The rider can choose to accept or reject the recalculated route.
 - c. **Off:** The system will not prompt with any new routes based on traffic data.

TRAFFIC EVENT LIST: RDS TRAFFIC

NOTE

For SiriusXM traffic, see *SiriusXM Traffic* (Page 134).

1. See Figure 155. Select **Home > Traffic**. If a route is active, the system displays traffic events along the route. If a route is not active, the system displays all nearby traffic events.

2. Select an item from the list. The traffic message is displayed. The text to speech feature reads the message over the speakers or headset.
3. Select the map button to display the event location on the map.




Figure 155. Traffic Event List

NAVIGATION PROMPTS: TURNING ON/OFF

1. Select **Home > Setup > Feedback Settings**.

2. Check or uncheck the **Enable Nav Prompts** checkbox.

NAVIGATION PROMPTS: ADJUSTING VOLUME USING MENUS

1. Select **Home > Setup > Feedback Settings**.
2. Adjust the prompt volume level. All prompts can be adjusted to the selected level (navigation, voice recognition, and so on).

NAVIGATION PROMPTS: ADJUSTING VOLUME WITH HAND CONTROLS

While a prompt is being heard, adjust the volume in the left hand controls. All prompts are adjusted to the selected level (navigation, voice recognition, and so on).

NAVIGATION PROMPTS: SPEAKER/HEADSET SELECTION

1. Select **Home > Setup > Speaker/Headset**.
2. For Prompts, select **Speaker** or **Headset**. All prompts (including navigation guidance) are played over the selected audio output.

NAVIGATION DATABASE

Update, replacement and restoration map databases are downloaded from harley-davidson.naviextras.com. This

website can be accessed through a link on www.h-d.com/boom.

Update: Motorcycles are delivered with the latest map database. Newer database versions are periodically released and are made available for purchase.

Intercontinental Replacement: Riders traveling outside of their home navigation database area can purchase a replacement database which covers the intended area of travel.

Intercontinental Restoration: After returning from extended travel in a different continent or in a region requiring a unique database, the navigation database can be restored to its home database.

Verifying Database Version

1. Turn on ignition.
2. Select **Home > Setup > System Information > Navigation > Database** to show the currently installed database version.
3. See Figure 156. Record the database version number.



Figure 156. Navigation Database Version

Download Hardware/System Requirements

- Downloading update, replacement or restoration databases from Naviextras requires a computer platform loaded with specific Windows operating systems and a minimum resolution display. See the Naviextras website for supported platforms and display resolution.
- A USB flash drive with a minimum of 16 GB is required. The flash drive must be formatted FAT32 not NTFS.
- The flash drive must be able to accept files in its root directory. Flash drives with security features or password requirements are not suitable for transfer of database files.
- Map databases are large files. Allow sufficient time to complete all uploads, downloads or unzipping of files. Do not interrupt an operation.

Updating Database

NOTE

- *The Naviextras website hosts a set of HOW-TO-GUIDE files to walk you through each step of the update procedure. Select and read the matching guide to complete each of the following tasks.*
 - *Naviextras may indicate that a free update is available. Make sure that the update version is newer than the database version in the motorcycle before attempting to download or install the update.*
 - *For CVO models, three navigation map database updates can be downloaded for free over a five-year period. Intercontinental replacements require additional charges for all models.*
1. Register with the harley-davidson.naviextras.com web site.
 2. Install the Naviextras Toolbox Windows utility on a compatible computer.
 3. Create a "fingerprint" of your Boom! Box on a USB flash drive.
 - a. Install a USB flash drive to the USB port in the storage compartment.
 - b. Go to **Home > Setup > System Information > Navigation > Export for Update.**

- c. Select the USB flash drive from the list.
 - d. When the export for update completes, select **OK**.
 - e. Remove the flash drive.
4. Connect the USB flash drive to the PC.
 5. Compare the recorded version number to the information on the website. If there is a database with the same number but with a date code later than the recorded number, continue with this process.
 6. Use the Toolbox utility to log in, select and purchase an available update to the navigation database. Download the database.
 7. If necessary, extract or unzip any .zip files.
 8. Download the unzipped updated database to the root directory of the USB flash drive.
 9. Connect the USB flash drive to the USB port in the storage compartment.

NOTE

The updated database automatically uploads to the Boom! Box.

Replacing the Intercontinental Database

NOTE

The Naviextras website hosts a set of HOW-TO-GUIDE files to walk through each step of the replacement procedure.

1. With the Naviextras Toolbox Windows utility loaded on your PC, select and download a replacement package.
2. Extract or unzip the .zip files.
3. Copy the unzipped files onto the root directory of a USB flash drive.
4. Install the USB drive to the USB port on the motorcycle.
5. Wait until the Boom! Box recognizes the USB drive. Record the "request code" displayed on the touchscreen.
6. In the Naviextras Toolbox, navigate to the code redemption page, enter the request code and complete the transaction. Record the "activation code".
7. Enter the activation code into the Boom! Box. Allow time for the Boom! Box to replace the current map database with the replacement.

Restoring an Intercontinental Database

NOTE

- *You can restore your original package at any time for no extra charge.*

- *Likewise, any previously purchased updates can be downloaded to the USB flash drive from the Toolbox utility.*
1. With the Naviextras Toolbox Windows utility loaded on your PC, select and download the restoration package.
 2. Extract or unzip the .zip files.
 3. Copy the unzipped files onto the root directory of a USB flash drive.
 4. Install the USB drive to the Boom! USB port.
 5. Wait until the Boom! Box recognizes the USB drive. Record the "request code" displayed on the touchscreen.
 6. In Naviextras, navigate to the code redemption page, enter the request code. Record the "activation code".
 7. Enter the activation code in the Boom! Box. Allow time for the Boom! Box to restore the original database.

NOTES

VOICE RECOGNITION

Voice recognition provides a hands-free alternative to operate many Boom! Box functions. Commands spoken into a headset microphone can instruct the system to play a media file, make a phone call, navigate to a destination, tune to a frequency or perform other features. Voice commands can be used to access functions that are otherwise locked out while the motorcycle is in motion.

To make full use of the system and to reduce distraction while riding, take time to learn voice commands for features that you commonly use.

NOTE

- *Voice recognition on 4.3 models is only supported for phone functions. The 4.3 phone commands are available in English only. Refer to Table 46.*
- *Some vehicles do not have headset connectors. A P&A headset connection kit must be installed on the vehicle to use voice command functions.*

ACTIVATING VOICE RECOGNITION

1. Press the VOICE RECOGNITION hand control switch. The system beeps and prompts for a command. The system shows a list of commands (teleprompter). The voice recognition icon appears in the status bar.

2. After the beep, speak a command into the headset microphone.
3. Respond to the system with additional information if needed.
 - a. **Prompts:** The system prompts if additional information is required to complete a command.
 - b. **Multiple options:** If multiple options are available for your command, the system displays a numbered list of options to choose from. Speak the appropriate line number, such as **LINE TWO**.
 - c. **Barging in:** To interrupt the prompt, press the VOICE RECOGNITION switch during the prompt and speak the desired command after the beep.

NOTE

Voice commands are universal rather than mode-specific. For example, a media command can be used while in tuner mode. The system will switch to media mode and carry out the command.

CANCELLING VOICE RECOGNITION

Hand control: Press and hold the VOICE RECOGNITION switch.

Voice command: At any time, say **CANCEL** to terminate the current session.

No valid input: If the system does not recognize a voice command, a response to a prompt, or if an extended period of time elapses before a command is spoken, the session automatically cancels.

TELEPROMPTER

See Figure 157. The teleprompter is shown when the VOICE RECOGNITION switch is pressed. The teleprompter screen shows commonly used commands, along with a line item to display more commands.

The CURSOR/SELECT switch can be used to select a command. Speaking or selecting **MORE COMMANDS** displays a list of all commands.



Figure 157. Teleprompter (Typical)

COMMAND LIST

See Figure 158. If a command is not spoken or recognized while the teleprompter is displayed, the system shows a list of command categories. Speak one of the categories into the microphone, or use the CURSOR/SELECT switch to show all commands related to a selected category.




Figure 158. Command List (typical)

PICK LIST

See Figure 159. Pick lists are presented in the following situations.

- More than one reasonable recognition of a word is available.
- Multiple choices are available.
- Navigation is attempting to refine a location.

When presented with a pick list, speak the desired line item into the microphone such as **LINE THREE**.




Figure 159. Pick List Example

PROMPTER RESPONDS "PARDON?"

Microphone: Speak voice commands into the microphone of the headset. Proper placement of the microphone is critical to the effectiveness of voice commands.

Speech: Speak naturally into the headset microphone. Articulate each word in a voice command. Do not pause between words. The system cannot recognize rapid speech or a raised voice level.

Numbers: Pronounce numbers as individual numerals. Speak the number 88 as "eight, eight" rather than "eighty-eight". Speak zeros as "zero" or "oh". Pronounce decimal points in frequency numbers as "point".

VOICE RECOGNITION COMMANDS

Table 43. Voice Recognition: General Commands

COMMAND	DESCRIPTION
ALL COMMANDS	List all available voice recognition commands.
CANCEL	Cancel voice recognition session.
LINE <NUMBER>	Select line number from list.
LIST	Show list of options.
YES	Acknowledge or continue.
NO	Decline or end.

Table 44. Voice Recognition: Tuner Commands

COMMAND	DESCRIPTION
A M	Set tuner to AM band.
F M	Set tuner to FM band.
WEATHER BAND	Set tuner to weather band.
MEDIUM WAVE	Set tuner to MW band.
LONG WAVE	Set tuner to LW band.
TUNE TO <FREQUENCY>	Tunes to a specified frequency. The radio will automatically change to the appropriate band for the selected frequency. Example: When saying TUNE TO NINETY-EIGHT POINT SEVEN, the tuner will change to the FM band and tune to 98.7 MHz.
SEEK UP/SEEK DOWN	Seeks next station up or down.
NEXT PRESET/PREVIOUS PRESET	Selects next/previous preset.
STATION <NAME>	Tunes to a selected station (European region only).

Table 45. Voice Recognition: Media Commands

COMMAND	DESCRIPTION
MEDIA	Enters media mode.
PLAY <ARTIST, ALBUM or SONG>	Plays songs from the selected artist.
ARTIST <NAME>	Plays songs from the selected artist.
ALBUM <NAME>	Plays the selected album.
PLAY ALL SONGS	Plays all songs on the media device.
GENRE <NAME or LIST ALL>	Plays songs from a selected genre or lists all available genres.
NEXT TRACK	Plays next track on media device.
PLAY PLAYLIST <NAME>	Plays a selected playlist.
PREVIOUS TRACK	Plays previous track on media device.

Table 45. Voice Recognition: Media Commands

COMMAND	DESCRIPTION
SONG <NAME>	Plays the selected song.
SEARCH FOR MUSIC	Search for a song or list all songs on a device.

Table 46. Voice Recognition: Phone Commands

COMMAND	DESCRIPTION
CALL <CONTACT NAME>	Begins a phone call to a phone book contact or locally saved contact. The system prompts if the contact has more than one phone number (home, mobile, work or other).
DIAL <PHONE NUMBER>	Dials a selected phone number.
REDIAL	Dials previous phone number.

Table 47. Voice Recognition: SiriusXM Commands

COMMAND	DESCRIPTION
X M	Plays SiriusXM radio.
CHANNEL <NUMBER or NAME>	Changes to selected channel. The system automatically changes to SiriusXM when channel commands are used.
CHANNEL UP	Changes to next channel up.
CHANNEL DOWN	Changes to next channel down.
CHANNEL SCAN	Scans through the SiriusXM channels.

Table 48. Voice Recognition: Navigation Commands

COMMAND	DESCRIPTION
DESTINATION <ADDRESS>	<p>Begins a route to the selected address. This "one-shot destination" command is not available in some regions. If not supported, the system will prompt for address elements (city, state and so on) through a series of steps.</p> <p>Example: It is recommended to say the destination as one string, such as DESTINATION 400 WEST CANAL STREET MILWAUKEE WISCONSIN.</p> <p>Note: Complex street addresses with letters and numbers (such as "N23W2345 River Run Road") may not be recognized by the voice recognition system. If a destination is not recognized, enter the address using the navigation menu.</p>
FAVORITE <SAVED>	Begins a route to a previously saved destination.
FIND NEXT <POI>	<p>Provides a list of stores or brands that match the requested POI. Select an item from the pick list to begin navigation to the POI.</p> <p>Note: POI types (such as FIND NEXT GAS STATION) and brand names (such as FIND NEXT SHELL) are read from the navigation database. Not all POI names are translated by Boom! Box software into recognizable command words. Voice recognition matching can be made more difficult when the names consist of multiple words or syllables. If a particular name does not produce recognizable results, try synonyms or other variations of a POI command.</p>
SHOW MAP	Displays the navigation map.
CANCEL ROUTE GUIDANCE	Cancels the current route.
REPEAT INSTRUCTIONS	Replays the navigation instructions for the next turn.
ENTER <COUNTRY, STATE, CITY, ZIP CODE, STREET, HOUSE NUMBER>	<p>Begins entering destination information into the address screen.</p> <p>Example: When saying ENTER STATE, the prompter responds with "Say the State Name". After providing the state name, the system continues to prompt for the remaining address fields on the screen.</p>

VEHICLE STATUS

See Figure 160. Press the VEHICLE INFORMATION switch to display various information. Press the switch again to exit the Vehicle Status screen.

NOTE

Holding the VEHICLE INFORMATION switch too long will activate the high contrast day colors on the screen.




Figure 160. Vehicle Status Screen

AIR TEMPERATURE

See Figure 160. The current air temperature of the surrounding environment is measured by a sensor in the fairing. The measurement can be affected by surrounding conditions at low speeds, such as idling in heavy traffic. This measured temperature does not necessarily indicate frost or other road conditions.

ENGINE OIL PRESSURE

See Figure 160. Engine oil pressure is displayed as OK or Check Oil. If the oil pressure lamp is on, stop the engine immediately and do not ride further. Refer to the vehicle owner's manual or see an authorized Harley-Davidson dealer for service as necessary.

ENGINE IDLE TEMPERATURE MANAGEMENT SYSTEM (EITMS)

See Figure 160. The Engine Idle Temperature Management System (EITMS) provides limited cooling of the rear cylinder during prolonged idle conditions or traffic congestion. The EITMS status is displayed as DISABLED, ENABLED or ACTIVE. See the vehicle owner's manual for more information about this feature.

Disabled: EITMS will not activate.

Enabled: EITMS will activate when the ambient or engine temperature exceeds the threshold during idling.

Active: EITMS has activated. The rear cylinder has turned off to cool the engine.

TIRE PRESSURE MONITORING SYSTEM (TPMS)

⚠ WARNING

Be sure tires are properly inflated, balanced, undamaged, and have adequate tread. Inspect your tires regularly and see a Harley-Davidson dealer for replacements. Riding with excessively worn, unbalanced, improperly inflated, overloaded or damaged tires can lead to tire failure and adversely affect stability and handling, which could result in death or serious injury. (00014b)

See Figure 161. Some vehicles have a tire pressure monitoring system (TPMS). With the Vehicle Status screen shown, select **More** to display the tire pressure data.




Figure 161. Tire Pressure Monitoring System (TPMS)

Front and rear tires: Each tire is shown as either white (to indicate normal tire pressure) or amber (to indicate a low tire pressure condition).

Tire pressure data: Tire pressure is displayed as psi or kPa, according to the unit settings for the radio. Dashes (--) indicate that there is no current data for the tire pressure.

Sensor battery low icon: The TPMS sensor battery is low for the indicated tire. See a Harley-Davidson dealer for service.

Low tire pressure icon: The system detects low pressure for the indicated tire. Safely stop the vehicle and use a tire pressure gauge to check the pressure of each affected tire. Inflate the tires according to specifications in the vehicle owner's manual or as specified on the label on the frame downtube.

Low Tire Pressure Alert

See Figure 162. An alert is displayed when a low tire pressure condition has been detected.

Search for fuel station: For vehicles with navigation, the radio will prompt to navigate to a nearby fuel station. Select **Yes** to display a list of nearby fuel stations.

Details: Displays the TPMS screen.

An alert will be displayed only once for each tire. Turn off and restart the motorcycle to reset the alert feature.



Figure 162. Low Tire Pressure Alert

NOTES

WHAT EVERY RESPONSIBLE CITIZENS BAND (CB) STATION OPERATOR SHOULD KNOW AS PREPARED BY THE FEDERAL COMMUNICATIONS COMMISSION, WASHINGTON, D.C.

Subpart D-Citizens Band (CB) Radio Service General Provisions

Sec. 95.401 (CB Rule 1) What is the Citizens Band Radio Services?

The Citizens Band (CB) Radio Service is a private, two-way, short-distance voice communications service for personal or business activities of the general public. The CB Radio Service may also be used for voice paging.

Sec. 95.401 (CB Rule 2) How do I use these rules?

(a) You must comply with these rules (See CB Rule 21 Sec. 95.421, for the penalties for violations) when you operate a station in the CB Service from:

1. Within or over the territorial limits of places where radio services are regulated by the FCC (see CB Rule 5, Sec. 95.405);
2. Aboard any vessel or aircraft registered in the United States; or

3. Aboard any unregistered vessel or aircraft owned or operated by a United States citizen or company.

(b) Your CB station must comply with technical rules found in subpart E of part 95.

(c) Where the rules use the word "you", "you" means a person operating a CB station.

(d) Where the rules use the word "person," the rules are concerned with an individual, a corporation, a partnership, an association, a joint stock company, a trust, a state, territorial or local government unit, or other legal entity.

(e) Where the rules use the term "FCC", that means the Federal Communications Commission.

(f) Where the rules use the term "CB station", that means a radio station transmitting in the CB Radio Service.

Sec. 95.403 (CB Rule 3) Am I eligible to operate a CB station?

You are authorized to operate a CB station unless:

(a) You are a foreign government, a representative of a foreign government, or a federal government agency; or

(b) The FCC has issued a cease and desist order to you, and the order is still in effect.

Sec. 95.404 (CB Rule 4) Do I need a license?

You do not need an individual license to operate a CB station. You are authorized by this rule to operate your CB station in accordance with the rules in this subpart.

Sec. 95.405 (CB Rule 5) Where may I operate my CB station?

You are authorized to operate your CB station from:

(a) Within or over any area of the world where radio services are regulated by the FCC. Those areas are within the territorial limits of:

1. The fifty United States.
2. The District of Columbia.

Caribbean Insular areas:

3. Commonwealth of Puerto Rico.
4. Navassa Island.
5. United States Virgin Islands (50 islets and cays).

Pacific Insular areas:

6. American Samoa (seven islands).
7. Baker Island.
8. Commonwealth of Northern Mariana Islands.
9. Guam Island.

10. Howland Island
11. Jarvis Island.
12. Johnston Island (Islets East, Johnston, North and Sand).
13. Kingman Reef.
14. Midway Island (Islets Eastern and Sand).
15. Palmyra Island (more than 50 islets).
16. Wake Island (Islets Peale, Wake and Wilkes).

(b) Any other area of the world, except within the territorial limits of areas where radio services are regulated by - An agency of the United States other than the FCC. (You are subject to its rules.) Any foreign government. (You are subject to its rules.)

(c) An aircraft or ship, with the permission of the captain, within or over any area of the world where radio services are regulated by the FCC or upon or over international waters. You must operate your CB station according to any applicable treaty to which the United States is a party.

(d) Anyone intending to operate a CB station on the islands of Puerto Rico, Desecheo, Mona, Vieques, and Culebra in a manner that could pose an interference threat to the Arecibo Observatory shall notify the Interference Office, Arecibo Observatory, Post Office Box 995, Arecibo, Puerto Rico 00613, in writing or electronically, of the location of the unit. Operators may wish to consult interference guidelines, which

will be provided by Cornell University. Operators who choose to transmit information electronically should e-mail to: prcz@naic.edu.

1. The notification to the Interference Office, Arecibo Observatory shall be made 45 days prior to commencing operation of the unit. The notification shall state the geographical coordinates of the unit.
2. After receipt of such notifications, the Commission will allow the Arecibo Observatory a period of 20 days for comments or objections. The operator will be required to make reasonable efforts in order to resolve or mitigate any potential interference problem with the Arecibo Observatory. If the Commission determines that an operator has satisfied its responsibility to make reasonable efforts to protect the Observatory from interference, the unit may be allowed to operate.

Sec. 95.406 (CB Rule 6) Are there any special restrictions on the location of my CB station?

(a) If your CB station is located on premises controlled by the Department of Defense you may be required to comply with additional regulations imposed by the commanding officer of the installation.

(b) If your CB station will be constructed on an environmentally sensitive site, or will be operated in such a manner as to raise environmental problems, under Sec. 1.1307 of this chapter,

you must provide an environmental assessment, as set forth in Sec. 1.1311 of this chapter, and undergo the environmental review, Sec. 1.1312 of this chapter, before commencement of construction.

How to Operate a CB Station

Sec. 95.407 (CB Rule 7) On what channels may I operate?

(a) Your CB station may transmit only on the following channels (frequencies):

Channel.....	Frequency (megahertz - MHz)
1.....	26.965
2.....	26.975
3.....	26.985
4.....	27.005
5.....	27.015
6.....	27.025
7.....	27.035
8.....	27.055
9.....	*27.065
10.....	27.075
11.....	27.085
12.....	27.105
13.....	27.115
14.....	27.125
15.....	27.135
16.....	27.155
17.....	27.165
18.....	27.175
19.....	27.185
20.....	27.205
21.....	27.215
22.....	27.225
23.....	27.255
24.....	27.235
25.....	27.245
26.....	27.265
27.....	27.275
28.....	27.285
29.....	27.295
30.....	27.305

31.....	27.315	32.....	27.325
33.....	27.335	34.....	27.345
35.....	27.355	36.....	27.365
37.....	27.375	38.....	27.385
39.....	27.395	40.....	27.405
.....	*See	paragraph	(b) of this
section.....			

(b) Channel 9 may be used only for emergency communications or for traveler assistance.

(c) You must, at all times and on all channels, give priority to emergency communication messages concerning the immediate safety of life or the immediate protection of property.

(d) You may use any channel for emergency communications or for traveler assistance.

(e) You must share each channel with other users.

(f) The FCC will not assign any channel for the private or exclusive use of any particular CB station or group of stations.

(g) The FCC will not assign any channel for the private or exclusive use of CB stations transmitting single sideband or AM.

Sec. 95.408 (CB Rule 8) How high may I put my antenna?

(a) Antenna means the radiating system (for transmitting, receiving or both) and the structure holding it up (tower, pole or mast). It also means everything else attached to the radiating system and the structure.

(b) If your antenna is mounted on a hand-held portable unit, none of the following limitations apply.

(c) If your antenna is installed at a fixed location, it (whether receiving, transmitting or both) must comply with either one of the following:

1. The highest point must not be more than 6.10 meters (20 feet) higher than the highest point of the building or tree on which it is mounted; or
2. The highest point must not be more than 18.3 meters (60 feet) above the ground.

(d) If your CB station is located near an airport, and if your antenna structure is more than 6.1 meters (20 feet) high, you may have to obey additional restrictions. The highest point of your antenna must not exceed one meter above the airport elevation for every hundred meters of distance from the nearest point of the nearest airport runway. Differences in ground elevation between your antenna and the airport runway may complicate this formula. If your CB station is near an airport, you may contact the nearest FCC field office for a worksheet to help you figure the maximum allowable height of your antenna. Consult part 17 of the FCC's Rules for more

information. Warning: Installation and removal of CB station antennas near powerlines is dangerous. For your safety, follow the installation directions included with your antenna.

Sec. 95.409 (CB Rule 9) What equipment may I use at my CB station?

(a) You must use an FCC certificated CB transmitter at your CB station. You can identify an FCC certificated transmitter by the certification label placed on it by the manufacturer. You may examine a list of certificated equipment at any FCC Field Office or at FCC Headquarters. Use of a transmitter which is not FCC certificated voids your authority to operate the station.

(b) You must not make, or have made, any internal modification to a certificated CB transmitter. (See CB Rule 25, Sec. 95.425). Any internal modification to a certificated CB transmitter cancels the certification, and use of such a transmitter voids your authority to operate the station.

Sec. 95.410 (CB Rule 10) How much power may I use?

(a) Your CB station transmitter power output must not exceed the following values under any conditions: AM (A3)- 4 watts (carrier power) SSB- 12 watts (peak envelope power)

(b) If you need more information about the power rule, see the technical rules in subpart E of part 95.

(c) Use of a transmitter which has carrier or peak envelope power in excess of that authorized voids your authority to operate the station.

Sec. 95.411 (CB Rule 11) May I use power amplifiers?

(a) You may not attach the following items (power amplifiers) to your certificated CB transmitter in any way:

1. External radio frequency (RF) power amplifiers (sometimes called linears or linear amplifiers); or
2. Any other devices which, when used with a radio transmitter as a signal source, are capable of amplifying the signal.

(b) There are no exceptions to this rule and use of a power amplifier voids your authority to operate the station.

(c) The FCC will presume you have used a linear or other external RF power amplifier if:

1. It is in your possession or on your premises; and
2. There is other evidence that you have operated your CB station with more power than allowed by CB Rule 10, Sec. 95.410.

(d) Paragraph (c) of this section does not apply if you hold a license in another radio service which allows you to operate an external RF power amplifier.

Sec. 95.412 (CB Rule 12) What communications may be transmitted?

(a) You may use your CB station to transmit two-way plain language communications. Two-way plain language communications are communications without codes or coded messages. Operating signals such as 'ten codes' are not considered codes or coded messages. You may transmit two-way plain language communications only to other CB stations, to units of your own CB station or to authorized government stations on CB frequencies about-

1. Your personal or business activities or those of members of your immediate family living in your household;
2. Emergencies (see CB Rule 18, Sec. 95.418);
3. Traveler assistance (see CB Rule 18, Sec. 95.418); or
4. Civil defense activities in connection with official tests or drills conducted by, or actual emergencies announced by, the civil defense agency with authority over the area in which your station is located.

(b) You may use your CB station to transmit a tone signal only when the signal is used to make contact or to continue communications. (Examples of circuits using these signals are tone operated squelch and selective calling circuits.) If the signal is an audible tone, it must last no longer than 15 seconds at one time. If the signal is a subaudible tone, it may be transmitted continuously only as long as you are talking.

(c) You may use your CB station to transmit one-way communications (messages which are not intended to establish communications between two or more particular CB stations) only for emergency communications, traveler assistance, brief tests (radio checks) or voice paging.

Sec. 95.413 (CB Rule 13) What communications are prohibited?

(a) You must not use a CB station:

1. In connection with any activity which is against federal, state or local law;
2. To transmit obscene, indecent or profane words, language or meaning;
3. To interfere intentionally with the communications of another CB station;
4. To transmit one-way communications, except for emergency communications, traveler assistance, brief tests (radio checks), or voice paging;
5. To advertise or solicit the sale of any goods or services;
6. To transmit music, whistling, sound effects or any material to amuse or entertain;
7. To transmit any sound effect solely to attract attention;

8. To transmit the word "MAYDAY" or any other international distress signal, except when your station is located in a ship, aircraft or other vehicle which is threatened by grave and imminent danger and you are requesting immediate assistance;
9. To communicate with, or attempt to communicate with, any CB station more than 250 kilometers (155.3 miles) away;
10. To advertise a political candidate or political campaign; (you may use your CB radio for the business or organizational aspects of a campaign, if you follow all other applicable rules);
11. To communicate with stations in other countries, except General Radio Service stations in Canada; or
12. To transmit a false or deceptive communication.

(b) You must not use a CB station to transmit communications for live or delayed rebroadcast on a radio or television broadcast station. You may use your CB station to gather news items or to prepare programs.

Sec. 95.414 (CB Rule 14) May I be paid to use my CB station?

(a) You may not accept direct or indirect payment for transmitting with a CB station.

(b) You may use a CB station to help you provide a service, and be paid for that service, as long as you are paid only for the service and not for the actual use of the CB station.

Sec. 95.415 (CB Rule 15) Who is responsible for communications I make?

You are responsible for all communications which are made by you from a CB station.

Sec 95.416 (CB Rule 16) Do I have to limit the length of my communications?

(a) You must limit your CB communications to the minimum practical time.

(b) If you are communicating with another CB station or stations, you, and the stations communicating with you, must limit each of your conversations to no more than five continuous minutes.

(c) At the end of your conversation, you, and the stations communicating with you, must not transmit again for at least one minute.

Sec. 95.417 (CB Rule 17) Do I identify my CB communications?

(a) You need not identify your CB communications.

(b) [You are encouraged to identify your CB communications by any of the following means:

1. Previously assigned CB call sign;
2. K prefix followed by operator initials and residence zip code;
3. Name; or
4. Organizational description including name and any applicable operator unit number.]

(c) [You are encouraged to use your "handle" only in conjunction with the methods of identification listed in paragraph (b) of this section.]

Sec. 95.418 (CB Rule 18) How do I use my CB station in an emergency to assist a traveler?>

- (a) You must at all times and on all channels, give priority to emergency communications.
- (b) When you are directly participating in emergency communications, you do not have to comply with the rule about length of transmissions (CB Rule 16, Sec. 95.416). You must obey all other rules.
- (c) You may use your CB station for communications necessary to assist a traveler to reach a destination or to receive necessary services. When you are using your CB station to assist a traveler, you do not have to obey the rule about length of transmissions (CB Rule 16, Sec. 95.416). You must obey all other rules.

(d) You may use your CB station to transmit one-way communications concerning highway conditions to assist travelers.

Sec. 95.419 (CB Rule 19) May I operate my CB station transmitter by remote control?

- (a) You may not operate a CB station transmitter by radio remote control.
- (b) You may operate a CB transmitter by wireline remote control if you obtain specific approval in writing from the FCC. To obtain FCC approval, you must show why you need to operate your station by wireline remote control. If you receive FCC approval, you must keep the approval as part of your station records. See CB Rule 27, Sec. 95.427.
- (c) Remote control means operation of a CB transmitter from any place other than the location of the CB transmitter. Direct mechanical control or direct electrical control by wire from some point on the same premises, craft or vehicle as the CB transmitter is not considered remote control.

Sec. 95.420 (CB Rule 20) May I connect my CB station transmitter to a telephone?

- (a) You may connect your CB station transmitter to a telephone if you comply with all of the following:
 1. You or someone else must be present at your CB station and must-

- (i) Manually make the connection (the connection must not be made by remote control);
 - (ii) Supervise the operation of the transmitter during the connection;
 - (iii) Listen to each communication during the connection; and
 - (iv) Stop all communications if there are operations in violation of these rules.
2. Each communication during the telephone connection must comply with all of these rules.
 3. You must obey any restriction that the telephone company places on the connection of a CB transmitter to a telephone.
- (b) The CB transmitter you connect to a telephone must not be shared with any other CB station.
- (c) If you connect your CB transmitter to a telephone, you must use a phone patch device with has been registered with the FCC.

OTHER THINGS YOU NEED TO KNOW

Sec. 95.421 (CB Rule 21) What are the penalties for violating these rules?

- (a) If the FCC finds that you have willfully or repeatedly violated the Communications Act or the FCC Rules, you may

have to pay as much as \$10,000 for each violation, up to a total of \$75,000. (See section 503(b) of the Communications Act.)

(b) If the FCC finds that you have violated any section of the Communications Act or the FCC Rules, you may be ordered to stop whatever action caused the violation. (See section 312(b) of the Communications Act.)

(c) If a Federal court finds that you have willfully and knowingly violated any FCC Rule, you may be fined up to \$500 for each day you committed the violation. (See section 502 of the Communications Act.)

(d) If a Federal court finds that you have willfully and knowingly violated any provision of the Communications Act, you may be fined up to \$10,000 or you may be imprisoned for one year, or both. (See section 501 of the Communications Act.)

Sec. 95.422 (CB Rule 22) How do I answer correspondence from the FCC?

(a) If it appears to the FCC that you have violated the Communications Act or these rules, the FCC may send you a discrepancy notice.

(b) Within the time period stated in the notice, you must answer with:

1. A complete written statement about the apparent discrepancy;

2. A complete written statement about any action you have taken to correct the apparent violation and to prevent it from happening again; and
3. The name of the person operating at the time of the apparent violation.

(c) If the FCC sends you a letter asking you questions about your CB radio station or its operation, you must answer each of the questions with a complete written statement within the time period stated in the letter.

(d) You must not shorten your answer by references to other communications or notices.

(e) You must send your answer to the FCC office which sent you the notice.

(f) You must keep a copy of your answer in your station records. (See CB Rule 27, Sec. 95.427.)

Sec. 95.423 (CB Rule 23) What must I do if the FCC tells me that my CB station is causing interference?

(a) If the FCC tells you that your CB station is causing interference for technical reasons you must follow all instructions in the official FCC notice. (This notice may require you to have technical adjustments made to your equipment.)

(b) You must comply with any restricted hours of CB station operation which may be included in the official notice.

Sec. 95.424 (CB Rule 24) How do I have my CB station transmitter serviced?

(a) You may adjust an antenna to your CB transmitter and you may make radio checks. (A radio check means a one way transmission for a short time in order to test the transmitter.)

(b) You are responsible for the proper operation of the station at all times and are expected to provide for observations, servicing and maintenance as often as may be necessary to ensure proper operation. You must have all internal repairs or internal adjustments to your CB transmitter made in accordance with the Technical Regulations (see subpart E). The internal repairs or internal adjustments should be performed by or under the immediate supervision and responsibility of a person certified as technically qualified to perform transmitter maintenance and repair duties in the private land mobile services and fixed services by an organization or committee representative of users in those services.

(c) Except as provided in paragraph (d) of this section, each internal repair and each internal adjustment of a CB transmitter in which signals are transmitted must be made using a nonradiating ("dummy") antenna.

(d) Brief test signals (signals not longer than one minute during any five minute period) using a radiating antenna may be transmitted in order to:

1. Adjust an antenna to a transmitter;
2. Detect or measure radiation of energy other than the intended signal; or
3. Tune a receiver to your CB transmitter.

Sec. 95.425 (CB Rule 25) May I make any changes to my CB station transmitter?

(a) You must not make or have any one else make any internal modification to your CB transmitter.

(b) Internal modification does not include:

1. Repair or servicing of a CB station transmitter (see CB Rule 24, Sec. 95.424); or
2. Changing plug-in modules which were certificated as part of your CB transmitter.
3. You must not operate a CB transmitter which has been modified by anyone in any way, including modification to operate on unauthorized frequencies or with illegal power. (See CB Rules 9 and 11, Secs. 95.409 and 95.411.)

Sec. 95.426 (CB Rule 26) Do I have to make my CB station available for inspection?

(a) If an authorized FCC representative requests to inspect your CB station, you must make your CB station and records available for inspection.

(b) A CB station includes all of the radio equipment you use.

Sec. 95.427 (CB Rule 27) What are my station records?

Your station records include the following documents, as applicable.

(a) A copy of each response to an FCC violation notice or an FCC letter. (See CB Rule 22, Sec. 95.422.)

(b) Each written permission received from the FCC. (See CB Rule 19, Sec. 95.419.)

Sec. 95.428 (CB Rule 28) How do I contact the FCC?

(a) FCC National Call Center at 1-888-225-5322.

(b) FCC World Wide Web homepage: <http://www.fcc.gov>.

(c) In writing, to FCC, Attention: CB, 1270 Fairfield Road, Gettysburg, PA 17325-7245.

Source: 48 FR 24894, June 3, 1983, unless otherwise noted.

NOTES

2018 LIMITED RADIO WARRANTY

Harley-Davidson warrants that your Harley-Davidson radio will be free from factory defects in factory materials and workmanship, under normal use and service, for a period of twenty-four (24) months starting from the earlier of (a) the date of initial retail purchase of the motorcycle on which the radio is installed, or (b) the third anniversary of the last day of the model year of the motorcycle on which the radio is installed. Any unexpired portion of this limited warranty will be transferred to subsequent owner(s), upon the resale of the motorcycle during the limited warranty period. If the motorcycle was used as a demonstrator or company motorcycle, then the limited warranty period may have started and/or expired prior to the initial retail sale. See an authorized Harley-Davidson Dealer for details.

This limited warranty does not cover defects or damage due to abuse, misuse or improper installation, or any radio on a motorcycle which has been registered with Harley-Davidson as a collector's vehicle. Radios with a touchscreen have a replaceable protective film. Damage to the radio due to use without this screen protector is not covered under warranty. The screen protector itself is a serviceable wear part which can be purchased at an authorized Harley-Davidson dealer. Wear or subsequent damage to the screen protector is not covered under warranty. Also, the limited warranty does not cover syncing issues or an improper functioning radio caused by an incompatible phone or other media storage device (MP3,

jump drive, etc.). See an authorized Harley-Davidson dealer for details. Use of aftermarket parts may void all or parts of your limited warranty.

This limited warranty does not cover repairs under certain conditions. Examples include:

- Loss of personal media, software or data.
- Failure to provide proper installation environment.
- Damage caused by abnormal use, unauthorized modification, computer viruses, or installation of unauthorized software, peripherals and attachments; unauthorized, unapproved or incompatible devices or upgrades; or malfunction of a mobile phone or digital media device, including inadequate signal reception by the external antenna, viruses or other software problems.

To obtain warranty service, return your motorcycle with sound system intact, at your expense, within the limited warranty period to an authorized Harley-Davidson dealer. Authorized Harley-Davidson dealers should be able to provide warranty service during normal business hours depending upon the workload of the authorized dealer's service department and the availability of necessary parts.

The remedy for breach of this warranty is expressly limited to the repair or replacement (**which may include a refurbished replacement radio**), without charge for parts and labor, of any part that proves to be defective, AND DOES

NOT EXTEND TO LIABILITY FOR CONSEQUENTIAL DAMAGES, COSTS OR EXPENSES, INCLUDING LOSS OF TIME, INCONVENIENCE, COMMERCIAL LOSS, OR LOSS OF USE OF THE VEHICLE, RESULTING FROM ANY PART THAT PROVES TO BE DEFECTIVE.

THERE IS NO OTHER EXPRESS WARRANTY ON THE RADIO. ANY IMPLIED WARRANTY RELATING TO THIS RADIO, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS EXPRESSLY LIMITED TO THE DURATION OF THIS LIMITED WARRANTY.

TO THE FULLEST EXTENT ALLOWED BY LAW, HARLEY-DAVIDSON AND ITS AUTHORIZED DEALERS SHALL NOT BE LIABLE FOR LOSS OF TIME, INCONVENIENCE, LOSS OF MOTORCYCLE USE, COMMERCIAL LOSS OR ANY OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Other Rights

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

2018 AUSTRALIA/NEW ZEALAND LIMITED RADIO WARRANTY

Your Consumer Rights

The benefits given to you under this H-D Radio Warranty are additional to, and do not detract from, other rights and remedies that you may have in respect of the radio or its installation under Australian and New Zealand laws, including consumer protection laws.

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

In New Zealand, our goods also come with guarantees that cannot be excluded under the New Zealand Consumer Guarantees Act.

Warranty

This warranty is provided by Harley-Davidson Motor Company P.O. Box 653, Milwaukee, Wisconsin 53201, U.S.A, phone: +1 (414 343-4056) ("Harley-Davidson").

Harley-Davidson warrants that an authorised Harley-Davidson dealer will repair or replace your Harley-Davidson radio if it is found to be defective in factory materials or workmanship, under normal use and service, during the warranty period set out below.

Such repair or replacement will be Harley-Davidson's sole obligation and your sole remedy under this H-D Radio Warranty, however you may have other rights under Australian and New Zealand laws, as described above.

Note that goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair goods.

Warranty Period

The warranty period is a period of twenty-four (24) months starting from the earlier of:

- (a) the date of delivery of the motorcycle on which the radio is installed by an authorised Harley-Davidson dealer to the first retail purchaser; or
- (b) the third anniversary of the last day of the model year of the motorcycle on which the radio is installed (if not sold to a retail purchaser before that date).

Any unexpired portion of this H-D Radio Warranty will be transferred to subsequent owners, upon the resale of the motorcycle during the limited warranty period. See the

OWNER CONTACT INFORMATION section of this Owner's Manual for information regarding notification of ownership changes.

Note: If the motorcycle was used as a demonstrator or company motorcycle, then the warranty period may have started and/or expired prior to the initial retail sale. See an authorised Harley-Davidson dealer for details.

Exclusions

This H-D Radio Warranty does not cover defects or damage due to abuse, misuse or improper installation, or any radio on a motorcycle which has been registered with Harley-Davidson as a collector's vehicle. Radios with a touchscreen have a replaceable protective film. Damage to the radio due to use without this screen protector is not covered under warranty. The screen protector itself is a serviceable wear part which can be purchased at an authorized Harley-Davidson dealer. Wear or subsequent damage to the screen protector is not covered under warranty. Also, the limited warranty does not cover syncing issues or an improper functioning radio caused by an incompatible phone or other media storage device (MP3, jump drive, etc.). See an authorised Harley-Davidson dealer for details.

Obtaining Warranty Service

To obtain warranty service, return your motorcycle with sound system intact, at your expense, within the warranty period to an authorised Harley-Davidson dealer.

Harley-Davidson's network of authorised dealers is large, and continues to expand. To find current contact information for your nearest authorised dealer, visit our website at www.h-d.com.au.

Index

A

A2DP/AVRCP Profile (AV/Music).....	83
Accessory Mode.....	30
Air Temperature.....	185
Alternate Frequency Switching (AF).....	63
Amplifier.....	28
Antenna.....	28
Audio.....	18
Audio Functions.....	5, 18, 21
Audio Settings (Bass/Treble).....	45
Audio Settings: Bass/Treble.....	45
Automatic Volume Control (AVC).....	47

B

Background Color.....	43
Bass.....	45
Bluetooth.....	5, 29, 69, 79, 80, 81, 83
Brightness.....	41
Buttons.....	32

C

CB.....	5, 113, 114, 115, 116, 117, 118, 189
---------	--------------------------------------

CURSOR/SELECT Switch.....	20
Care and Cleaning.....	77
Categories (Cat).....	60
Charging a Phone.....	83
Checkbox.....	32
Cleaning.....	77
Clock.....	44
Colors.....	42, 43
Compass.....	147
Controls.....	5, 15, 16, 17, 19, 20, 21, 48

D

Day/Night Colors Mode.....	42
Daylight Savings Time (DST).....	44
Disconnecting the Vehicle Battery.....	30

E

Emergency CB Operation.....	4
Emergency Phone Number.....	4
Enabling Rear Controls.....	21
Engine Idle Temperature Management System (EITMS).....	185
Engine Oil Pressure.....	185
English Units of Measurement.....	43

Index

F		I	
FCC CB Rules.....	189	Intercom.....	5, 119, 120, 121, 122
Factory Restore.....	53		
Fade.....	46	K	
Favorite (FAV) Switch.....	16	Keyboard.....	33, 44
Favorites.....	16, 55		
G		L	
GPX Files.....	161	Language.....	40
Global Presets.....	49		
H		M	
HFP+PBAP+AV Profile.....	83	MAP.....	142, 144, 149, 153
Hand Controls.....	18	Map Database.....	174
Hands-Free Calling Profile (HFP).....	83	Media.....	5, 67, 69, 70, 71, 72, 73, 74, 75, 76
Headset.....	22, 45	Media Compartment (USB Port).....	25
High Contrast Day Colors.....	42	Media Compartment: USB Port.....	25
Home Screen.....	31	Message Access Profile (MAP).....	83
		Metric Units of Measurement.....	43
		Microphone.....	22
		Multiselect Button.....	32

Index

Muting Audio.....15

N

NAVIGATION Switch.....17

National Oceanic and Atmospheric Administration (NOAA).....64

National Weather Radio (NWR).....64

Navigation...3, 5, 47, 50, 141, 142, 144, 145, 146, 147, 149, 151, 152, 153, 154, 155, 156, 157, 158, 159, 160, 161, 162, 165, 166, 167, 168, 169, 170, 171, 172, 173, 174

O

Operating.....18

P

POWER/MUTE Switch.....15

PREVIOUS/NEXT Switch.....19

Part Number.....50

Passenger Controls.....21

Pausing Media.....15

Phone...5, 76, 83, 84, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99

Phonebook Access Profile (PBAP).....83

Popup Screens.....36

Pre-Ride Checklist.....4

Presets.....49

Privacy Reset.....53

Program Types (PTYs).....60

Prompts.....47

Push-To-Talk (PTT) Switch.....20

R

RBDS/RDS.....63

Radio.....77

Radio Broadcast Data System (RBDS).....63

Radio Data System (RDS).....63

Rear (Passenger) Controls.....21

Regionalization (REG).....63

Regulatory Compliance.....189

Replaceable Screen Protector.....77

Reset.....53

Ride Planner.....162

Rider Planner.....161

Index

S		Supplier Part Number.....	50
SMS.....	94	System Information.....	50
Safety.....	1, 3, 4	T	
Scan.....	59, 70, 127	Text Messaging.....	94
Screen.....	31, 36	Time.....	44
Screen Brightness.....	41	Time Zones.....	44
Scroll Controls.....	32	Total Harmonic Distortion (THD).....	28
Seek.....	59	Trademarks.....	139
Serial Number.....	50	Traffic.....	134, 173
Settings.....	39, 40, 41, 43, 44, 45, 46, 47, 48, 49	Traffic Program/Traffic Announcement (TP/TA).....	63
Setup.....	39, 42	Trails.....	159
Short Message Service (SMS).....	94	Treble.....	45
SiriusXM.....	5, 123, 124, 125, 126, 127, 128, 129, 130, 131, 132, 133, 134, 135, 137, 138	Trips.....	157
Smart Speller.....	35	Tuner.....	5, 57, 58, 59, 60, 62, 63, 64
Soft Keys.....	17	Turning Motorcycle On/Off.....	30
Software.....	50, 52	U	
Speaker/Headset Selection.....	45	USB Devices.....	67
Speakers.....	27, 45, 77	USB Drive.....	25, 67
Specifications.....	5	Units of Measurement.....	43
Speed volume.....	47		
Squelch (SQ+/SQ-) Switch.....	20		
Station List.....	62		
Status Bar.....	36		

Index

V

VOICE RECOGNITION Switch.....	20
VOX (Microphone Sensitivity).....	120
Vehicle Information Switch.....	21
Vehicle status.....	5, 185, 186
Voice Commands.....	179, 180, 181
Voice recognition.....	5, 179
Volume.....	19, 35, 47
Volume Controls.....	35
Volume Switch.....	19

W

Weather Alert.....	64
Weather Band.....	64
Weather Map.....	137, 138
Weatherradio Canada.....	64

NOTES
