



# **BOOM!™ BOX INFOTAINMENT SYSTEM QUICK START GUIDE**



**Just when you thought you couldn't love the sound  
of your Harley-Davidson® motorcycle any better...**

**Welcome to Boom!™ Box.**

Congratulations! You're about to experience your  
favorite tunes the way they should be enjoyed,  
with more volume, more clarity,  
and more richness.

The best-in-class **Boom!™ Box** audio and  
infotainment system blows away anything  
you'll find in a car. You'll see and hear the  
powerful difference the minute you turn it on.

This Quick Start Guide explains how to set-up simple  
operations for your **Boom! Box** Infotainment System.

See your **Boom! Box** Infotainment System  
owner's manual and *Harley-Davidson.com/owners*  
for more detailed information.

*Note: 6.5 Models shown unless otherwise indicated.*



## SAFETY

Follow all the warnings, cautions and safety tips in this Quick Start Guide, your vehicle owner's manual and your **Boom!™ Box** owner's manual.

*Note: Some features are disabled while the vehicle is in motion.*

### WARNING

Set volume levels and other controls on audio and electronic devices before riding. Distractions can lead to loss of control, resulting in death or serious injury. (00088b)

### WARNING

Set CB channel, squelch threshold and volume before riding to minimize adjustments on the road. Distractions can lead to loss of control, resulting in death or serious injury. (00089a)

### WARNING

Do not select a volume level that blocks out traffic noise or interrupts the concentration necessary for safe operation of the motorcycle. Distractions or a volume level that blocks out traffic noise could cause loss of control resulting in death or serious injury. (00539b)

This feature is not  
available while in motion

Cancel

OK


## CONTROLS

6.5 Models use touch screen, cursor or buttons to make selections.


4.3 Models use soft keys, cursor or buttons to make selections.

### FACEPLATE

1. HOME screen
2. FAVORITE
3. POWER or MUTE
4. NAV/COMPASS
5. Soft key  
(4.3 Models only)



6.5 Models




4.3 Models


## HAND CONTROLS

### Right – Controls Cursor

om01667





ITEM	ICON	NAME	FUNCTION
1		Information	Displays or exits Vehicle Information
2	<b>SQ +</b>	CB Squelch +	<b>If Equipped:</b> Increases CB squelch level
3	<b>SQ -</b>	CB Squelch -	<b>If Equipped:</b> Decreases CB squelch level
4	<b>PTT</b>	CB Push to Talk	<b>If Equipped:</b> Press and hold to transmit over CB.
5		Cursor Up	Moves the highlighting up through the selections.
6		Cursor Right	Moves the highlighting right through the selections.
7		Cursor Down	Moves the highlighting down through the selections.
8		Cursor Left	Moves the highlighting left through the selections.
9		Select /Enter	Selects the highlighted item or used to indicate data entry is complete.



### Left – Controls Device

ITEM	ICON	NAME	FUNCTION
1		Home	Toggles between current screen and Home screen
2		Previous /Seek Down	Tuner: Seek down. Media: Previous file
3		Next/Seek Up	Tuner: Seek up. Media: Next file
4		Volume Up	Increases volume
5		Volume down	Decreases volume
6		Voice Recognition (if equipped)	Initiates a voice command session




# LAYOUT

## OPERATION


### Screen Menu Bar

Located at top of most screens. Use CURSOR UP arrow on right hand control to access options.



### Option Menu



Indicates additional options are available for that function.



## OPERATION

### Toggle Buttons

Use the SELECT/ENTER key to toggle through options for that function.



### Checkboxes


Enables (if checked) or disables (unchecked) that feature.




## BASIC OPERATION

### TURNING SYSTEM ON/OFF

1. Turn ignition to ON or to ACC.
2. If radio is OFF, press POWER.



6.5 Models



4.3 Models

3. Read the warning and select Accept.



**Quick Tip:** On 6.5 Models you can use **SELECT/ENTER** or **press touch screen**.






## ADJUSTING VOLUME/MUTE

Press VOLUME UP (1)  
or VOLUME DOWN (2)  
on left hand control.




Briefly press MUTE to  
mute or un-mute audio.

*Note: Pressing MUTE for  
more than 3 seconds will  
turn radio off.*



6.5 Models



4.3 Models

SETUP


ACTIVATING  
HEADSETS OR  
SPEAKERS  
(if equipped  
with headsets)

- 1. Select SETUP on HOME screen

**Quick Tip:** On some vehicles, use the CURSOR UP arrow on right hand control to access Menu bar.



6.5 Models



4.3 Models

Select SPEAKER/  
HEADSET.




Select speaker or headset  
icon for each audio type.



## AUDIO SETUP

1. Select SETUP on HOME screen.




6.5 Models (typical)

2. Select AUDIO SETUP.



3. Adjust BASS, TREBLE, FADE and SPEED VOLUME. Segments will increase or decrease.


**Quick Tip:** Use the UP/DOWN arrows on the right hand control to select the feature to adjust. Use the LEFT/RIGHT arrow on right hand control to select and adjust the volume up or down.




# RADIO

## SELECTING BAND

1. Select Tuner from Home screen



2. Select desired band.



*FM shown*

## SELECTING A RADIO STATION

1. Use CURSOR UP to access Menu bar. Select MENU.





2. Select SEEK search mode.

**Quick Tip:** If default view is Presets or Tune, use the Enter/Select key to toggle through the choices.

3. Select BACK to return to radio band screen.




4. Select SEEK UP (2) or SEEK DOWN (3) on left hand control to tune station.




## BLUETOOTH®

### PAIR A PHONE OR OTHER DEVICE

1. Activate Bluetooth® on your device and make device discoverable.
2. Select COM on HOME screen.
3. Use CURSOR DOWN arrow and then select PHONE.



4. Select Bluetooth® checkbox and scroll down.
5. Select LIST PAIRED DEVICES.



6. Select ADD NEW DEVICE.



7. Select phone or device.

*Note: Go to [h-d.com/touring](http://h-d.com/touring) to see a list of approved devices.*





*Note: This screen may appear during pairing.*



8. Check that the PINs on both the audio system and the device match.

**Quick Tip:** Check your device for any pairing messages.



9. Select YES or NO to add or not add an emergency phone number to the system



## BLUETOOTH® STREAMING AUDIO

### PLAYING AUDIO VIA BLUETOOTH®

*Note: The device must first be paired with the audio system before it can be used. See BLUETOOTH® section. Device must also support Bluetooth® audio streaming profile (A2DP).*

1. Select SETUP on HOME screen.



2. Select BLUETOOTH® SETUP.

**Quick Tip:** Use the right arrow key to move cursor to the scroll bar on the right. Scroll down to Bluetooth Setup if necessary.






3. Select LIST  
PAIRED DEVICES.



4. Select your device  
from the list.



5. Select CONNECT  
MUSIC.




# PHONE

## MAKING A PHONE CALL

Note:

- The phone must first be paired with the audio system before it can be used through the **Boom!™ Box** Infotainment system. See **BLUETOOTH®** section.
- A Harley-Davidson headset with microphone is required to make and receive calls via Bluetooth®.


1. Select COM on HOME screen.



2. Select PHONE.




3. Select the phone number by selecting Contacts, Keypad, Calls or Emergency (SOS).



## RECEIVING A PHONE CALL


1. Press or  
Select **ACCEPT**.



## VOICE RECOGNITION

1. Press the voice  
recognition switch (1).
2. When the system  
beeps, speak a voice  
command calmly  
and normally into the  
headset microphone.


*Note: A list of available  
voice commands are  
displayed on the screen  
when the voice recognition  
switch is pressed.*



## NAVIGATION SYSTEM (if equipped)

### MAP DISPLAY

1. Press Navigation (Nav) on HOME screen or Nav button (3).




6.5 Models only

2. Select MAP.  
Current location or route is displayed.



3. Use Map controls on the screen to adjust the view:
  - (A) Zoom and Unzoom.
  - (B) Map Options.


See the **Boom!™**  
**Box** Infotainment  
Owner's Manual for  
additional information.



## INPUT ADDRESS OR USE TAKE ME HOME FEATURE

*Note: Keyboard functions  
are not available while  
vehicle is moving.*

1. Select Navigation (Nav)  
from HOME screen.



2. Select WHERE TO.




3. Select ADDRESS  
or HOME.

Address: Input  
the address.

Home: Input the  
address to use as the  
home address.

Select GO.

*Note: Address mapping is  
dependent on the address  
availability in the database.*





Harley-Davidson Motor Company  
Service Communications – Milwaukee, WI 53208  
Part No. 97011-14  
Printed in the U.S.A.